

## 科技无限·倡导未来





# HLP-SD100 Series Operating Manual



Tel: +86-0571-28891071 Fax: +86-0571-28891072 Service Hotline: +86-400-809-5335 Add: Room 15A03-2,14F Yefeng Modern Center,No.161 Shaoxing Road,Hangzhou,China Website: www.holip.com

Due to product upgrades or specification changes, the contents of the manual will be timely revised. It is subject to change without notice.

©Zhejiang Holip Electronic Technology Co., Ltd. | Version: 2017-01



微信公众平台:海利普变频器

ZHEJIANG HOLIP ELECTRONIC TECHNOLOGY CO., LTD.



## HLP-SD100 Series Operating Manual



#### Introduction

Thank you for purchasing and using the negeral -purpose vector driver of HLP-SD100 series.

Please read carefully the operation manual before putting the drive to use so as to correctly install and operate the drive, give full play to its functions and ensure the safety. Please keep the operation manual handy for future reference, maintenance, inspection and repair.

Due to the drive of a kind of power electronics product it must be installed, tested and adjusted with specialized electrical engineering workers.

The marks of  $\triangle$  (Danger),  $\triangle$  (Caution) and other symbols in the manual remind you of the safety and prevention cautions during the handling, installation, running and inspection. Please follow these instructions to make sure the safe use of the drive. In case of any doubt please contact our local agent for consultation. Our professional persons are willing and ready to serve you.

The manual is subject to change without notice.



## Index

	Introduction	
Chapter	1 Safety Precautions	1
	1.1 Before Power-up	1
	1.2 During the Power-up	2
	1.3 During the Operation	3
	1.4 After the Power-off	3
Chapter	2 Standards and Specifications	4
	2.1 Label Description	4
	2.2 Particular Specifications	5
	2.3 Technical Specifications	5
	2.4 Derating Specifications	8
	2.5 Accessories	8
Chapter	3 Mechanical and Electrical Installation	10
	3.1 Mechanical Installation	10
	3.1.1 Installation Environment Requirements	10
	3.1.2 External and Installation Dimensions	10
	3.1.3 Installation and Direction	12
	3.1.4 Local Control Panel External Installation	14
	3.1.5 Sieve Installation	16
	3.1.6 IP50 Box Installation	17
	3.1.7 Flange Installation	19
	3.1.8 Removal of the Front Cover	21
	3.1.9 Slide Insulating Cover Operation	22
	3.2 Peripheral Electrical Devices	24
	3.2.1 Selection of MCCB/Fuse/Contactor	25
	ring the Power-up rring the Operation ter the Power-off ndards and Specifications bel Description rticular Specifications chnical Specifications rrating Specifications rrating Specifications cessories chanical and Electrical Installation echanical Installation .1 Installation Environment Requirements .2 External and Installation Dimensions .3 Installation and Direction .4 Local Control Panel External Installation .5 Sieve Installation .6 IP50 Box Installation .7 Flange Installation .8 Removal of the Front Cover .9 Slide Insulating Cover Operation ripheral Electrical Devices .1 Selection of MCCB/Fuse/Contactor .2 Selection of Braking Unit and Braking Resistor .3 Selection of EMC Filter scription of Main Circuit	26
	3.2.3 Selection of AC Input and Output Reactor	27
	3.2.4 Selection of EMC Filter	28
	3.3 Description of Main Circuit	28
	3.3.1 Schematic of Main Circuit Terminals	28



		3.3.2 Main Circuit Terminal Screws and Wiring Recommended Specifications	30
	3.4	Description of Control Circuit	30
		3.4.1 Schematic of Control Circuit Terminals	30
		3.4.2 Control Terminals' Screws and Wiring Recommended Specifications	33
		3.4.3 Control Circuit Wiring	33
		3.4.4 Digital Input Terminals Usage Specification	34
		3.4.5 Digital Output Terminals' Usage Specification	35
	3.5	5 EMC instructions	35
		3.5.1 Introduction to EMC Standard	35
		3.5.2 Noise Abatement	35
		3.5.3 Grounding	36
		3.5.4 Leakage Current Suppression	36
		3.5.5 Induction Voltage Suppression	37
Chapter	4	Operation and Display Interface	38
	4.1	Local Control Panel	38
	4.2	2 Parameter Setting	39
	4.3	3 FWD/REV Status	40
	4.4	1 Data Read-outs	41
	4.5	5 View Alarm Record	42
	4.6	5 View State Parameter	42
	4.7	7 LED Display	43
Chapter	5	Parameter Overview	44
Chapter	6	Parameter Description	70
	6.1	l Group 00: Operation/Display	70
	6.2	2 Group 01: Load and Motor	75
	6.3	3 Group 02: Brakes	86
	6.4	4 Group 03: Reference/Ramps	91
	6.5	5 Group 04: Limits/Warnings	97
	6.6	5 Group 05: Digital In/Out	103
	6.7	7 Group 06: Analog In/Out	113
	6.8	3 Group 07: Controllers	120
	6.9	9 Group 08: Communication	123
	6.1	10 Group 13: Simple PLC	126
	6.1	11 Group 14: Special Functions	133

## 

	6.12 Group 15: Drive Information	140
	6.13 Group 16: Data Readouts	141
	6.14 Group 39: Communication User-Defined Par	149
	6.15 Group 29: winding and unwinding related parameters	153
Chapter	7 Quick Application Guide	171
	7.1 Using LCP to Start/Stop the Drive	171
	7.2 Using Digital Input Terminals to Start/Stop the Drive	171
	7.2.1 Two-line Mode 1	171
	7.2.2 Two-line Mode 2	171
	7.2.3 Three-line Mode 1	172
	7.2.4 Three-line Mode 2	172
	7.3 Multi-speed	173
	7.4 Analog Input as the Frequency Source	173
	7.5 Pulse Input as the Frequency Source	174
	7.6 Speed up/down	174
	7.7 Parameter Initialization	174
	7.8 Automatic Motor Adaption (AMA)	175
	7.9 Encoder direction estimation	175
	7.9.1 Motor direction estimation	175
	7.10 Speed mode applicaton scheme	175
	7.10.1 Close speed(start/stop, Analog setting frequency)	175
	7.10.2 Close speed loop (start/stop, Analog setting frequency, PID)	176
	7.10.3 Close speed loop (start/stop, Analog setting frequency, PID)	179
	7.10.4 Close Speed Loop(Close Speed Loop+Roll diameter calculation +PID)	181
	7.11 Torque mode application scheme	183
	7.11.1 The torque mode with speed feedback is mainly used for winding an	nd
	unwinding parts(Internal diameter calculation is done for converter)	184
Chapter	8 Faults and Solutions	188
	8.1 Fault List	188
Chapter	9 Maintenance	192
	9.1 Note	192
	9.2 Storage and Transport	192
Appendi	ix A Modbus Communication Specification	193
Appendi	ix B Copy Card Specification	204



## Chapter 1 Safety Precautions

**Caution** Indicates misuse may damage the drive or mechanical system.



Danger Indicates misuse may result in casualty.

#### 1.1 Before Power-up

!\ Caution

- Check to be sure that the voltage of the main circuit AC power supply matches the input voltage of the drive.
- Install the drive in a safe location, avoiding high temperature, direct sunlight, humid air or water.
- The drive can only be used at the places accredited by our company. Any unauthorized working environment may have the risks of fire, gas explosion, electric shock and other incidents.
- If more than one drive installed on the same control cabinet, make additional cooling fan, so that the inside temperature is lower than 40 C, in order to prevent overheating or fire occurs.
- It will affect the service life of the drive if a contactor is installed on the input side to control the start and stop. Generally it is required to control it through terminal commands. Special attention should be paid to its use in the case of the start and stop more frequently places.
- Do not install any switch component like circuit breaker or contactor at the output of the drive. If any of such components must be installed due process and other needs, it must be ensured that the drive has no output when the switch acts. In addition, it is forbidden to install any capacitor for improvement of power factor or any varistor against thunder at the output. Otherwise it will cause malfunctions, tripping protection and damages of components of the drive.
- Please use an independent power supply for the drive. Do avoid using the common power supply with an electrical welder and other equipment with strong disturbance. Otherwise it will cause the drive to protect or even damage the drive.
- Motor overload protection is not included in the default settings. If this function is desired, set C01.90 (motor thermal protection) to date value ETR trip or date value ETR



warning.

- Do not make any high voltage test with any component inside the drive. These semiconductor parts are subject to the damage of high voltage.
- The IC board of the drive are susceptible to the effect and damage of static electricity. Don't touch the main circuit board.
- Installation, commissioning and maintenance must be performed by qualified professional personnel.
- Don't carry the front cover of the drive directly when handling. It should be handled with the base to prevent the front cover off and avoid the dropping of the drive, which may possibly cause the injuries to people and the damages to the drive.



- Be sure to turn off the power supply before wiring.
- Mount the drive in the metal and other non-combustible materials to avoid the risk of fire.
- Don't install the drive in a space with explosive gas, otherwise, they lead to explosion.
- R, S, T terminals are power input terminals, never mixed with U.V.W terminals. Be sure that the wiring of the main circuit is correct. Otherwise it will cause damages of the drive when the power is applied to it.
- The terminal of must be grounded separately and never connected to N-line. Otherwise it will easily cause the protection or errors of the drive.
- Do not dissemble or modify any internal connecting cord, wiring or component of the drive by yourself.
- Never remodel it or exchange control boards and components by yourself. It may expose you to an electrical shock or explosion, etc.
- Keep the drive from the reach of children or persons not concerned.

#### 1.2 During the Power-up



- Do not plug the connectors of the drive during the power up to avoid any surge into the main control board due to plugging, which might cause the damage of the drive.
- Always have the protective cover in place before the power up to avoid electrical shock injury.

#### 1.3 During the Operation



- Do not measure the signals on circuit boards while the drive is running to avoid danger.
- The drive has been optimized before sold. Please make proper adjustments according to the desired functions.
- Do consider the vibration, noise and the speed limit of the motor bearings and the mechanical devices.



- Never connect or disconnect the motor set while the drive is in running. Otherwise it will cause over-current trip and even burn up the main circuit of the drive.
- Never remove the front cover of the drive while the drive is powered up to avoid any injury of electric shock.
- Do not come close to the machine when the Reset Function is used to avoid anything unexpected. The motor may automatically recover from fault.

#### 1.4 After the Power-off



• Even in the case of the main power, the other voltage inputs and the share load (linkage of DC intermediate circuit) all have been disconnected from the mains; the internal of the drive may still have residual energy. Before touching any potentially live parts of the drive, please wait at least 4 minutes for the drives of less than 22kW (including 22kW), and wait at least 15 minutes for the drives of more than 30kW (including 30kW). Otherwise, it may expose you to a risk of electrical shock.



## Chapter 2 Standards and Specifications

### 2.1 Label Description



Significance of the product type code:

### T/C: HLP-SD10007D543P20XBX1CX0XXXVXXX

	1-9	10-13 14-1516-18 19 20 2122 2324 25 26 27-28 29-32
1-9	HLP-SD100	Indicate Product Series
10-13	07D5	Indicate 7.5kW
14-15	21	Indicate 1-Phase AC 220V
	23	Indicate 3-Phase AC 220V
	43	Indicate 3-Phase AC 380V
16-18	P20	IP rating is 20
19	Х	Without AC choke
	А	With AC choke
20	Х	Without Brake unit
	В	With Brake unit
21	Х	Without DC choke
	В	With DC choke
22	1	Control panel with LED display and potentiometer
23	С	With coating on PCB
24	Х	Reserved
25	0	Domestic sale
	1	Overseas sale
26	В	IO board Type
27-28	XX	Reserved
29-32	VXXX	Indicate software version number, such as V235 means the
		version number is 2.35.

## 

## 2.2 Particular Specifications

		Input	Output	Rated	Power	Air flow	Net	
Model	Input voltage	current	current	power	Dissipation	rate	weight	
		(A)	(A)	(kW)	(W)	(m <sup>3</sup> /h)	(kg)	
HLP-SD1000D7543	3×380-440V	3.7	2.3	0.75	38.5	51	1.3	
1111 00100007345	3×440-480V	3.2	2.1	0.75	50.5	51	1.5	
HLP-SD10001D543	3×380-440V	6.4	4	1.5	49.0	51	1.3	
1111-50100010545	3×440-480V	5.5	3.6	1.5	49.0	51	1.5	
HLP-SD10002D243	3×380-440V	8.9	5.6	2.2	65.2	51	1.3	
11LF-3D10002D245	3×440-480V	7.7	5.1	2.2	05.2	51	1.5	
HLP-SD10004D043	3×380-440V	15.8	9.9	4.0	122.9	51	2.0	
11LF-3D10004D045	3×440-480V	13.6	9	4.0	122.9	51	2.0	
HLP-SD10005D543	3×380-440V	21.3	13.3	5.5	139.4	51	2.0	
HLF-3D10003D343	3×440-480V	18.4	12.1	5.5	139.4	51	2.0	
HLP-SD10007D543	3×380-440V	28.3	17.7	7.5	211.6	68	2.5	
11LF-3D10007D343	3×440-480V	24.4	16.1	7.5	211.0	00	2.5	
HLP-SD100001143	3×380-440V	35.9	25	11	262.4	124	5.8	
11LF-3D100001143	3×440-480V	31.4	22.7	11	202.4	124	5.8	
HLP-SD100001543	3×380-440V	43.4	32	15	339.3	170	5.8	
nLr-3D100001343	3×440-480V	38.8	29.1	15	559.5	170	5.8	
HLP-SD10018D543	3×380-440V	51.5	38	18.5	418.0	230	8	
HLF-3D10018D343	3×440-480V	46.1	34.5	16.5	410.0	230	0	
HLP-SD100002243	3×380-440V	61.0	45	22	468.2	272	8	
HLP-3D100002243	3×440-480V	54.5	40.9	22	408.2	272	0	
HLP-SD100003043	3×380-440V	73	61	30	676.3	303	19	
nLr-3D100003043	3×440-480V	64	52		070.5	303	19	
	3×380-440V	72	75					
HLP-SD100003743	3×440-480V	65	68	37	795.0	374	22	
	3×440-480V	653	678					

## 2.3 Technical Specifications

	Item	Specification
Power	Supply voltage	Single/Three phase 200~240V -20%~+10%; Three phase 380~480V -20%~+10%;
supply	Frequency	48~62Hz;
	Max. imbalance	3%;
Motor	Output voltage	Three phase 0-100% of supply voltage;
output	Output requency	V/F : 0-400Hz , VVC+: 0-200Hz;

	Item	Specification			
	Control mode	V/F, VVC+;			
	Start torque	0.5Hz 150%;			
	Overload capacity	150% 60s, 200% 1s;			
	PWM switch frequency	2~16kHz;			
Main	Speed setting resolution	Digital: 0.001Hz; Analogy: 0.5‰ of the max. operating frequency ;			
control functions	Speed open-loop control accuracy	30~4000 rpm: tolerance±8 rpm;			
	Speed close-loop control accuracy	0~6000 rpm: tolerance±0.15 rpm;			
	Control command source	LCP, digital terminal, local bus;			
	Frequency setting source	LCP, analog, pulse, local bus;			
	Ramp control	Selectable 4-speed steps ramp up and down times 0.05-3600.00s;			
Basic Functions	Speed Open-loop Control; Speed Close-loop Control,Process Closed-loop Control; Torque Open-loop Control; Torque Close-loop Control;AMA Function; Motor Magnetisation; Slip Compensation; Torque compensation; Automatic Voltage Regulation; V/F Control, DC Brake; AC brake; Speed Limit; Current Limit; Flying Start; Reset Function; Counter; Timer;				
Application Functions	SLC(including Order Control and Parallel Control): Mechanical Braking: UP/				
Protection Functions	Missing Motor Phase Protection; Low-voltage Protection; Over-voltage Protection; Over-current Protection; Output Phase Loss Protection; Output Short Circuit Protection; Output Grounding Fault Protection; Motor Thermal Protection; Live Zero Timeout Function; AMA Fails; CPU Fault; EEPROM Faults; Button freeze; Duplicate Fails; LCP Invalid; LCP Incompatible; Parameter Read-only; Reference Out of Range; Invalid While Running etc.				

\_

# 

\_\_\_\_\_

Item		Specification
IO board	Input	<ul> <li>5 digital inputs (1 supports pulse input, pulse range: 1Hz~100kHz);</li> <li>2 analog input, one supports voltage signals(0~10V/-10V~10V), other supports voltage or current signals.</li> <li>PG card Input: supports kinds of output type: open collector PNP output / open collector NPN output / voltage output / push-pull output / linear drive output;</li> </ul>
control terminals	Output	<ul> <li>2 digital output (1 supports pulse output, pulse range: 1Hz~100kHz);</li> <li>2 relay output;</li> <li>2 analog input (1 can be selected as current output or voltage output via jumper switch).</li> </ul>
	Power supply	1 +10V, max current output 10mA;
	Communication	1 +24V, max current output 200mA; RS+, RS-, max baud rate 115200bit/s;
	8 segments, 5 numeric displays	Display frequency, warnings, status and so on;
	Indicator	Light FWD, REV, HZ, A, RPM display various status of the drive;
Display	Data read-outs	Frequency setting, output frequency, feedback value, output current, DC link voltage, output voltage, output power, input terminals state, output terminals state, analogue input, analogue output, 1-10 fault records and accumulated working time etc.;
	Enclosure	IP20;
	Ambient temperature	-10 $\rm \widetilde{C}$ ~50 $\rm \widetilde{C}$ , derating use when over 50 $\rm \widetilde{C}$ ;
	Humidity	5%-85% (95% without condensation);
Environment	Vibration test	≤75kW: 1.14g; ≥90kW: 0.7g;
	Max. altitude above sea level	1000m, derating use when more than 1000 meters;
	Motor cable length	Shield cable: 50 meters, unshield cable: 100 meters;
others	DC choke	≥37kW Built-in
	Braking unit	≤22kW Built-in



#### 2.4 Derating Specifications

Derating for ambient temperature: If the drive is operated over 40  $^{\circ}$ C ambient temperature, the continuous output current should be decreased. The drive has been designed for operation at max 50° ambient temperation with one motor size smaller than normal. Continuous operation at full load at 50  $^{\circ}$ C ambient temperation will reduce the lifetime of the drive.

Derating for low air pressure: The cooling capability of air is decreased at low air pressure. Below 1000m altitude no de-rating is necessary but above 1000m the ambient temperature or the maximum output current should be decreased. Dcrease the output by 1% per 100m altitude above 1000m or reduce the max. ambient temperature by 1 degree per 200m.

#### 2.5 Accessories

Model: LCP-02 Function: Local Control Panel (LCP) is used to modify parameters, monitor status and control the drive. The standard length of extension cable is 15 meters when mounting LCP-02 on control cabinet. Note: Random device standard.
Model: LCP-03 Function: Local Control Panel (LCP) is used to modify parameters, monitor status and control the drive. The standard length of extension cable is 15 meters when mounting LCP-03 on control cabinet. LCP-03 has the same installation dimensions with HLP-A series control panel (OP-AB01). Product No: 133B5808
Model: Cradle-01 Function: For the LCP-02 is mounted on the control cabinet Product No: 133B4264.



Model: CopyCard-01 Function: Copy Card can copy parameters from one drive to another. Product No: 133B5806.
Model: Sieve-01~06 Function: Used for preventing dust sucked into the drive wind way. Product No: 133B9655, Sieve-01, for Frame A0 133B9656, Sieve-02, for Frame A1 133B9657, Sieve-03, for Frame A2 133B9658, Sieve-04, for Frame A3 133B9659, Sieve-05, for Frame A4 133B9660, Sieve-06, for Frame A5-1
Model: IP50 Box-01~05 Function: Install this option box allows the drive to achieve IP50 enclosure. Product No: 133B5835, IP50 Box-01, for Frame A0 133B5836, IP50 Box-02, for Frame A1 133B5837, IP50 Box-03, for Frame A2 133B5838, IP50 Box-04, for Frame A3 133B5839, IP50 Box-05, for Frame A4
Model: Flange-01~06 Function: Used for flange installation Product No: 133B9802, Flange-01, for Frame A0 133B9803, Flange-02, for Frame A1 133B9804, Flange-03, for Frame A2 133B9805, Flange-04, for Frame A3 133B9807, Flange-05, for Frame A4 133B6175, Flange-06, for Frame A5-1




## Chapter 3 Mechanical and Electrical Installation


#### 3.1 Mechanical Installation

#### 3.1.1 Installation Environment Requirements


- 1. Ambient temperature in the range of -10  $^\circ\text{C}\,$   $\sim\,50\,^\circ\text{C}\,$  ;
- 2. Drive should be installed on surface of flame retardant object, with adequate surrounding space for heat dissipation;
- Installation should be performed where vibration is less than 1.14g(<= 75kW) or 0.7g (>= 90kW);
- 4. Avoid from moisture and direct sunlight;
- 5. Do not expose to an atmosphere with flammable gases, corrosive gases, explosive gases or other harmful gases;
- 6. Protect the cooling fan by avoiding oil, dust and metal particles;
- 7. Prevent drilling residues, wire ends and screws falling into drive;

#### 3.1.2 External and Installation Dimensions










Frame	Voltage & Power			Dime	nsions	(mm)		
	3×380-480V	W	Н	D	W1	H1	W2	d
A0	0.75-2.2kW	125	210	152	104	194	-	4.5
A1	4.0-5.5kW	145	250	167	124	230	-	4.5
A2	7.5kW	155	263	177	133	243	-	4.5
A3	11-15kW	192	365	189	150	340	-	6.5
A4	18.5-22kW	216	420	194	150	395	-	6.5
A5	30-37kW	292	517	229	240	492	-	9

External and installation dimensions (unit: mm)

#### 3.1.3 Installation and Direction


#### 1. Single Installation

The drive must be installed vertically with smooth ventilation. Enough space must be left around the drive to ensure good cooling, as shown below:



#### 2. Side by Side Installation


The drive can be mounted side by side, a minimum space must be reserved above and below the enclosure, as shown below:



3. Upper and Lower Installation

æ

If several drives need to be installed together in one cabinet, upper and lower installation can be adopted. Enough space must be reserved to ensure effective cooling, as shown below:







#### 3.1.4 Local Control Panel External Installation

#### 1. LCP-02 Installation


The external dimensions of LCP-02 are shown below (unit: mm):



When installing LCP-02 outside, a cradle is needed. The external dimensions of the cradle are shown below (unit: mm):









## HOLIP

The installation steps of LCP-02 are shown below:



#### 2. LCP-03 Installation

The external dimensions of LCP-03 are shown below (unit: mm):



 55.8.


 of

 of
 </


#### The installation steps of LCP-03 are shown below:

#### 3.1.5 Sieve Installation

1. Sieve-01~03 Installation




Step2: Both sides use M4 screw locking, and the screw length must not exceed 10mm.



#### 2. Sieve-04~07 Installation


HOLIP

Step1: Adsorbe the sieve (with four magnets) to the inlet at the bottom of the machine directly.




#### 3.1.6 IP50 Box Installation

1. IP50 Box 01~03 Installation



Step 3: The IP50 box is installed on the drive by two snap-fits.

2. IP50 Box 04~05 Installation



æ

- 18 -

#### 3.1.7 Flange Installation

HOLIP

A4

A5

254

336


233

315

430

525

Open a hole in the device, the size of the hole and mounting hole are shown below:



\_

\_

2xM5

440

512

127.5

122.5


2xM4

2xM5


4xM4

4xM5

#### 1. Flange 01~03 Installation




Step 1: Remove the two ground screws, Step 2: Place the flange on the drive front cover, use take the nuts from the accessory kit and the four screws (in accessory kit) to fasten the flange, and install the ground screws.




Step 3: Fix the drive in the device hole by four screws.

2. Flange 04~08 Installation








#### 3.1.8 Removal of the Front Cover


It is needed to remove the front cover before wiring the main circuit and control circuit.






#### Frame A5


Use a screwdriver to loosen the screws on the front cover.



#### 3.1.9 Slide Insulating Cover Operation

Frame A0~A2 has built-in slide insulating cover between main circuit and control circuit. Its operation is shown below:








### 3.2 Peripheral Electrical Devices

The peripheral electrical devices of the drive are shown below:





Part	Mounting Location	Function Description
МССВ	Power receiving side	Interrupt the power supply when overcurrent occurs on downstream devices.
Contactor	Between MCCB and drive input side	Do not start and stop the drive frequently by switching the contactor on and off (less than twice per minute) nor use it to directly start the drive.
AC input reactor	Drive input side	Improve the power factor of the input side; Eliminate the input current unbalance due to unbalance between the power phases; Eliminate the higher harmonics of the input side effectively; prevent other devices from being damaged due to distortion of the voltage waveform;
EMC Input filter	Drive input side	Decrease the conduction interference flowing from the power end to the drive and improve the antiinterference capacity of the drive; Reduce the external conduction and radiation interference of the drive;
Braking unit Braking resistor	≤22kW Braking unit is standard configuration	Consume the motor feedback energy to achieve rapid braking.
EMC Output filter	Drive output side	Reduce the external conduction and radiation interference of the drive.
AC output reactor	Between the drive output side and the motor, close to the drive	Degrade the motor insulation performance and damage the motor in the long run; Generate large leakage current and cause frequent AC drive protection trips; If the distance between the drive and the motor is greater than 100 m, install an AC output reactor;

#### 3.2.1 Selection of MCCB/Fuse/Contactor

Model	MCCB (A)	Fuse (A)	Contactor (A)
HLP-SD1000D7543	10	10	10
HLP-SD10001D543	10	10	10
HLP-SD10002D243	16	16	10
HLP-SD10004D043	25	25	25
HLP-SD10005D543	32	32	25
HLP-SD10007D543	40	40	32
HLP-SD100001143	63	63	40
HLP-SD100001543	63	63	63
HLP-SD10018D543	100	100	63



Model	MCCB (A)	Fuse (A)	Contactor (A)
HLP-SD100002243	100	100	100
HLP-SD100003043	150	150	100
HLP-SD100003743	150	150	100

#### 3.2.2 Selection of Braking Unit and Braking Resistor

Users can select different braking resistor for different application, it is calculated as follows. But the resistance should not be less than the minimum recommended in the table, otherwise there is a risk of damage caused by the drive, the power of braking resistor can be greater. the greater system inertia, the short deceleration time, the more frequent braking, the greater the power of the braking resistor, the smaller the braking resistor value.

1. Selection of the Braking resistor value

The braking resistor value:  $R = U_{DH} \times U_{DH} \div (K_B \times P_{MN})$ 

 $U_{\mbox{\tiny DH}}$  is the limit of the DC bus, generally it is 700V for 400V model , 400V for 200V model.

PMN is rated motor power;

KB is braking torque coefficient, it is between 0.8 to 2.0. For general machine, it is 1.0, for greater inertia machine, it is 1.5 to 2.

2. Selection of the Braking resistor power

Braking power:  $P_b = U_{DH} \times U_{DH} \div R$ 

Theoretically braking resistor power and braking power can be the same, But in actual choice, it will be multiplied by a correction factor, braking resistor power

 $Pr = a P_b$ 

correction factor :  $a = 0.12 \sim 0.9$ 

For not frequent acceleration and deceleration application, a can be set as 0.12, for frequent acceleration and deceleration application, it should be increased.

3. Recommended selection

Model	Braking Resistor Recommended Power	Braking Resistor Recommended value	Braking Unit
HLP-SD1000D7543	150W	$\ge 300 \Omega$	
HLP-SD10001D543	250W	$\ge 200 \Omega$	
HLP-SD10002D243	500W	$\ge 100 \Omega$	
HLP-SD10004D043	500W	$\ge 100 \Omega$	Built-in
HLP-SD10005D543	700W	$\ge 80 \Omega$	Duint-In
HLP-SD10007D543	900W	$\ge 65 \Omega$	
HLP-SD100001143	1200W	$\ge 40 \Omega$	
HLP-SD100001543	1500W	$\ge 30 \Omega$	
HLP-SD10018D543	2000W	$\ge 25 \Omega$	
HLP-SD100002243	2500W	$\ge 20 \Omega$	

## 

For the power greater than 30kW (including) models, braking unit is optional, so the selection of braking resistor depends on the selection of braking unit.

#### 3.2.3 Selection of AC Input and Output Reactor

1. The guide of AC input reactor selection

Model	Rated current (A)	Maximum continuous current (A)	Inductance (mH) & 3% Impedance
HLP-SD1000D7543	3.7	5.55	8.74
HLP-SD10001D543	6.4	9.6	5.05
HLP-SD10002D243	8.9	13.35	3.63
HLP-SD10004D043	15.8	23.7	2.05
HLP-SD10005D543	21.3	31.95	1.52
HLP-SD10007D543	28.3	42.45	1.14
HLP-SD100001143	35.9	53.85	0.90
HLP-SD100001543	43.4	65.1	0.75
HLP-SD10018D543	51.5	77.25	0.63
HLP-SD100002243	61	91.5	0.53
HLP-SD100003043	80	120	0.45
HLP-SD100003743	80	120	0.36

2. the guide of AC output reactor selection

Model	Rated current (A)	Saturation current (A)	Inductance (mH) & 3% Impedance
HLP-SD1000D7543	2.3	3.45	14.06
HLP-SD10001D543	4	6	8.08
HLP-SD10002D243	5.6	8.4	5.77
HLP-SD10004D043	9.9	14.85	3.27
HLP-SD10005D543	13.3	19.95	2.43
HLP-SD10007D543	17.7	26.55	1.83
HLP-SD100001143	25	37.5	1.29
HLP-SD100001543	32	48	1.01
HLP-SD10018D543	38	57	0.85
HLP-SD100002243	45	67.5	0.72
HLP-SD100003043	61	129	0.362
HLP-SD100003743	75	159	0.294


	EMC Inj	out Filter	EMC Out	tput Filter
Model	Rated Current	Recommended		Rated Current
	(A)	Model *		(A)
HLP-SD1000D7543	5	NFI-005	5	NFO-005
HLP-SD10001D543	5	NFI-005	5	NFO-005
HLP-SD10002D243	10	NFI-010	10	NFO-010
HLP-SD10004D043	10	NFI-010	10	NFO-010
HLP-SD10005D543	20	NFI-020	20	NFO-020
HLP-SD10007D543	20	NFI-020	20	NFO-020
HLP-SD100001143	36	NFI-036	36	NFO-036
HLP-SD100001543	36	NFI-036	36	NFO-036
HLP-SD10018D543	50	NFI-050	50	NFO-050
HLP-SD100002243	50	NFI-050	50	NFO-050
HLP-SD100003043	65	NFI-065	65	NFO-065
HLP-SD100003743	80	NFI-080	80	NFO-080

#### 3.2.4 Selection of EMC Filter


\* Recommended models is the Shanghai Eagtop Electronic Technology Co., Ltd. products, website: http://www.eagtop.com/

### 3.3 Description of Main Circuit

#### 3.3.1 Schematic of Main Circuit Terminals



Frame A0~A4



Description of main circuit terminals:

æ

Symbol	Function	
R, S, T	Power input, Single phase connected to R, T	
U, V, W	Power output, connect to the motor	
+BR, -BR	Connect the brake resistor, make sure to set C02.10, C02.11 etc.	
+UDC, -UDC	DC bus	
PE	Ground terminal	

Note: For the power less than 22kW (including) models, +UDC and +BR is the same terminal, for the power greater than 30kW (including) models, there are no +BR,-BR Terminal.




#### 3.3.2 Main Circuit Terminal Screws and Wiring Recommended Specifications

Model	Input Cable (mm <sup>2</sup> )	Output Cable (mm²)	Input and Output Terminals' Screws	Input and Output Terminals' Torque (N·m)	Ground Terminal Screw	Ground Terminal Torque (N·m)
HLP-SD1000D7543	1	1	M3.5	0.8-1.0	M4	1.0-1.2
HLP-SD10001D543	1	1	M3.5	0.8-1.0	M4	1.0-1.2
HLP-SD10002D243	1	1	M3.5	0.8-1.0	M4	1.0-1.2
HLP-SD10004D043	1.5	1.5	M4	1.0-1.2	M4	1.0-1.2
HLP-SD10005D543	1.5	1.5	M4	1.0-1.2	M4	1.0-1.2
HLP-SD10007D543	2.5	1.5	M4	1.0-1.2	M4	1.0-1.2
HLP-SD100001143	4	2.5	M4	1.0-1.2	M6	2.0-2.5
HLP-SD100001543	6	4	M4	1.0-1.2	M6	2.0-2.5
HLP-SD10018D543	10	4	M5	1.6-2.0	M6	2.0-2.5
HLP-SD100002243	10	6	M5	1.6-2.0	M6	2.0-2.5
HLP-SD100003043	10	10	M8	8-10	M6	2.0-2.5
HLP-SD100003743	16	16	M8	8-10	M6	2.0-2.5

Note: This specification is under using single-core line VV and 25 C , if use other cables or under higher temperature environment, please refer to electrical manual.

# 3.4 Description of Control Circuit

#### 3.4.1 Schematic of Control Circuit Terminals



#### Dial switch description:

Switch	Description		Instructions		Default
S1	VO Jumper switch	Left: 0~20mA Right0-10V;	Left: 0~20mA; Right0-10V;		
S2	Digital Input jumper switch	Left: PNP Mo Right: NPN M	,		NPN
S3	RS485 termination resistor jumper switch	Left: ON Right: OFF			OFF
		S4_1	S4_2	Output	
S4_1	VOD Power jumper switch:	ON	ON	5V	
	5V/12V/24V	OFF	ON	5V	24V
S4 2	50/120/240	ON	OFF	12V	
34_2		OFF	OFF	24V	
S4_3	Incremental encoder input type jumper switch	ON: open connector PNP output OFF: open connector NPN output/voltage output/push-pull output/linear drive ouput;		OFF	
S4_4	Control board connected to PE jumper switch		ON: connect to PE OFF: disconnect to PE		OFF

Terminals' specification:

Symbol	Description	Specification
KA-KB, FA-FB	Relay output	<ol> <li>Resistive Load: 250VAC 3A/30VDC 3A;</li> <li>Inductive Load: 250VAC 0.2A/24VDC 0.1A (cos φ =0.4);</li> </ol>
RS+, RS-	RS485 communication	Max baud rate: 115200bit/s;
AI	Analog input	<ul> <li>AI can be configurated to 0-20mA or 0-10V by paramters:</li> <li>1. Input Impedance: about 10k Ω;</li> <li>2. Input Impedence: ≤ 200 Ω;</li> </ul>
VI	Analog input	VI can be configurated to -10V~10V 1. Input Impedance: about 10k $\Omega$ ;
FOR, REV, DI1, DI2, DI3,	Digital input	<ol> <li>Logic:</li> <li>&gt;DC 19V Logic: 0;</li> <li><dc 14v="" 1;<="" li="" logic:=""> <li>Voltage: DC 0-24V;</li> <li>Input resistance: 5k Ω;</li> <li>Input voltage Rang: Max ± 30V;</li> <li>Digital input can be selected to NPN or PNP mode by Jump switch S2, the default: NPN mode;</li> </dc></li></ol>




Symbol	Description	Specification
DI3	Pulse input	1. Pulse input: 0.00-100.00kHz; 2. Voltage range: 24∨ ± 20%; 3. Input duty ratio: 40%-60%;
VDD	24V power supply	Max load 200 mA, with over load and short circuit protection functions.
DO1	Pulse output	<ul> <li>DO1 can also be configured as pulse output channels:</li> <li>1. Pulse output range: 0.00-100.00kHz;</li> <li>2. Voltage range: 0-24V;</li> <li>3. Duty ratio: 40%-60%;</li> <li>4. Resistive load &gt;1kΩ, Capacitive Load &lt; 10nf;</li> </ul>
VO	Analog output	<ul> <li>VO can be selected to the current output or voltage output via S1, default is: voltage output;</li> <li>1. Output Mode: 0~20mA or 0~10V;</li> <li>2. Voltage Output: load larger than 500 Ω;</li> <li>3. Current Output: load larger than 500 Ω;</li> </ul>
+10V	10V power supply	Max load 10mA, with over load and short circuit protection functions.
GND	Analog and communication ground	Isolated from internal COM.
VOD	Encoder power	Provided power range DC5~24V 1. DC5V; 2. DC12V; 3. DC24V (150 mA) 4. Set the combined dial switch S4_1/S4_2 to the proper position and select the voltage output. Refer to the switch instructions for usage;
A+、A- B+、B- Z+、Z-	Encoder pulse input	<ul> <li>Encoder pulse input terminal</li> <li>1. Support below type of input encoder: <ul> <li>a) Open connector PNP output;</li> <li>b) Open connector NPN ouput;</li> <li>c) Voltage output;</li> <li>d) Push-pull output;</li> <li>e) Linear drive output;</li> </ul> </li> <li>2. Support encoder power VOD. Please set to the proper position to supply power for the encoder;</li> <li>3. When you use an A/B/Z type encoder, please leave A-/B-/Z- dangling ;</li> <li>4. The encoder input type is selected by dialing the code switch S3_3;</li> </ul>

## 3.4.2 Control Terminals' Screws and Wiring Recommended Specifications

Cable types	Cable specifications (mm <sup>2</sup> )	Torque (N·m)
Shielded cables	0.4	0.4


#### 3.4.3 Control Circuit Wiring






#### 3.4.4 Digital Input Terminals Usage Specification

1. Open collector NPN mode wiring



While using this mode, J3 1-2 must be connected (default state: VDD connects to OP).


#### 2. Open collector PNP mode wiring



While using this mode, J3 2-3 must be connected (COM connects to OP).

# 3.4.5 Digital Output Terminals' Usage Specification

DO supports open connector NPN output, The schematic diagram is as follows:



### 3.5 EMC instructions

#### 3.5.1 Introduction to EMC Standard

The HLP-SD100 series satisfies the requirements of standard IEC/EN61800-3: 2004 (Adjustable speed electrical power drive systems part 3: EMC requirements and specific test methods).

#### 3.5.2 Noise Abatement

- 1. When peripheral equipment and the drive share the power supply of one system, noise from the drive may be transmitted to other equipment in this system via power lines and result in misoperation and/or faults. In such a case, the following measures could be taken:
  - a. Mount input noise filter at input terminal of the drive;
  - b. Mount power supply filter at power input terminal of affected equipment;
  - c. Use isolation transformer to isolate the noise transmission path between other equipment and the drive.
- 2. As the wiring of peripheral equipment and the drive constitutes a circuit, the unavoidable earthing leakage current of drive will cause equipment misoperation and/or faults. Disconnect the grounding connection of equipment may avoid this misoperation and/or faults.
- 3. Sensitive equipment and signal lines shall be mounted as far away from drive as possible.
- 4. Signal lines should be provided with shielded layer and reliably grounded. Alternatively, signal cable could be put into metallic conduits between which the distance shall be no less than 20cm, and shall be kept as far away from drive and its peripheral devices, cables as possible. Never make signal lines in parallel with power lines or bundle them up.
- 5. Signal lines must orthogonally cross power lines if this cross inevitable.
- 6. Motor cables shall be placed in thick protective screen like more than 2mm-thick pipelines




or buried cement groove, also, power lines can be put into metallic conduit and grounded well with shielded cables.

- 7. Use 4-core motor cables of which one is grounded at close side of the drive and the other side is connected to motor enclosure.
- Input and output terminals of drive are respectively equipped with radio noise filter and linear noise filter. For example, ferrite common mode choke can restrain radiation noise of power lines.

#### 3.5.3 Grounding

Recommended ground electrode is shown in the figure below:



- 1. Use to the fullest extent the maximum standard size of grounding cables to reduce the impedance of grounding system;
- 2. Grounding wires should be as short as possible;
- 3. Grounding point shall be as close to the drive as possible;
- 4. One wire of 4-core motor cables shall be grounded at the drive side and connected to grounding terminal of motor at the other side. Better effect will be achieved if motor and drive are provided with dedicated ground electrodes;
- 5. When grounding terminals of various parts of system are linked together, leakage current turns into a noise source that may influence other equipment in the system, thus, grounding terminals of the drive and other vulnerable equipment should be separated;
- 6. Grounding cable shall be kept away from input & output of noise-sensitive equipment.

#### 3.5.4 Leakage Current Suppression

Leakage current passes through the line-to-line and ground distributed capacitors at input & output sides of drive, and its size is associated with the capacitance of distributed capacitor and the carrier frequency. Leakage current is classified into ground leakage current and line-to-line leakage current.

1. Ground leakage current not only circulates inside drive system, but may also influence other equipment via ground loop. Such a leakage current may result in malfunction of

RCD and other equipment. The higher the carrier frequency of drive is, the bigger the ground leakage current would be. The longer the motor cables and the bigger the parasitic capacitance are, the bigger the ground leakage current would be. Therefore, the most immediate and effective method for suppression of ground leakage current is to reduce carrier frequency and minimize the length of motor cables.

- 2. The higher harmonics of line-to-line leakage current that passes through between cables at output side of drive will accel the aging of cables and may bring about malfunction of other equipment. The higher the carrier frequency of drive is, the bigger the line-to-line leakage current would be. The longer the motor cables and the bigger the parasitic capacitance are, the bigger the line-to-line leakage current would be. Therefore, the most immediate and effective method for suppression of ground leakage current is to reduce carrier requency and minimize the length of motor cable. Line-to-line leakage current can also be effectively suppressed by mounting additional output reactors.
- 3. For the HLP-SD100 serials, the models which power is less than 22kW (including) can be removed RFI screws; the models which power is greater than 30kW (including) can be set C14.50 = 0 to cut RFI filter to reduce the leakage current;

#### 3.5.5 Induction Voltage Suppression


The drive outputs pulse voltage which will form induction voltage in the surface of the motor when the drive is not grounded. The induction voltage can be reduced by connecting the drive's PE terminal to the motor and closing RFI screws (models which power  $\leq 22kW$ ) or setting C14.50 = 1 (models which power  $\geq 30kW$ ).



# Chapter 4 Operation and Display Interface

#### 4.1 Local Control Panel

Local Control Panel (LCP) can do the operation of parameters modifications, status monitoring and drive control (start, stop), its appearance is shown blow:



#### 1. State LED

The drive has three operating states: HAND control state, AUTO control state and OFF state. The operating states are indicated by HAND, AUTO and OFF Led.

HAND LED: The drive is in the HAND control state when it is on. The frequency can be changed by turning the incremental potentiometer. Push "HAND" key to set the drive in the HAND state.

OFF Led: The drive is in the OFF state when it is on. Push "OFF" key to set the drive in the HAND state.

AUTO LED: The drive is in the AUTO state when it is on. In the AUTO state, the drive is controlled by control terminals or communication. Push "AUTO" key to set the drive in the AUTO state.

#### 2. Function Led

FWD, REV Led: Indicates that the drive runs forwards or reverse.

Hz, A, RPM Led: Indicates the meaning of data displayed on the screen.

Local remote running lights running lights, OFF LEDs, three LED lights indicate.

#### 3. Screen

There are 5 LED which can display reference, output frequency, monitoring data and warning/alarm code.

#### 4. Keys

Symbol	Name	Function
MENU	Programming	Enter or exit menu.
	Shift	Select the displayed parameters in turn in the stop or running state; Select the digit to be modified when modifying parameters.
HAND	Hand	Push it to set the drive in the HAND control state.
OFF	Off/Reset	Stop the drive when it is in the running state and perform the reset operation when it is in the fault state.
AUTO	Auto	Push it to set the drive in the AUTO control state.
O	Confirm	Push the incremental potentiometer. Enter the menu or confirm the parameter setting.

#### 5. Incremental Potentiometer

Increase/decrease data or parameter, clockwise to increase, counter-clockwise to decrease.

# 4.2 Parameter Setting

Example: Set C03.10 [0] to 20.5:

Key-press	LCP Display	Action Description
MENU	C00.03	Press (MENU) key to display the first basic C00.03
O	C03.00	Turn O clockwise to select parameter group C03
	C03.00	Press key to shift to fractional part

Key-press	LCP Display	Action Description
O	C03.10	Turn O clockwise to select parameter C03.10
O	[0]	Press O key show the first option of C03.10
Ô	0000	Press key to show the value of the first option of parameter C03.10
O	000.5	Turn O clockwise to change the fractional part to 5
	000.5	Press key to shift to integral part
O	020.5	Press O key to change the integral part to 20
O	END	Press O key to accept the change and save it as 20.5

æ

#### 4.3 FWD/REV Status

Confirm the direction of the motor according to the set value, as shown in the following table:

Reference:	Running status	Indicator Display
≥0	STOP	FWD REV
< 0	STOP	FWD REV
≥0	FWD	FWD REV
≥0	REV	FWD REV
< 0	FWD	FWD REV
< 0	REV	⊖ ● FWD REV

Note: A flash light denotes the status coming, Light on indicates the current state, and light off means not in this state.

Example 1: The first line of the table indicates the drive is stop and the reference is greater than or equal to 0, means the dirve at some time in the future will run forward.

## 4.4 Data Read-outs

Press ( ) key to change the display items on LCP while displaying output frequency.

Display Items	Key-press	LCP Display	Action Description
Output Frequency	Initial interface	F S C O FWD REV HZ A R/MIN	Show the output frequency C16.13 is 50.0Hz, display accuracy: 0.1
Reference		SO,OOO FWD REV HZ A RMIN	Show the reference C16.01 is 50.000, display accuracy: 0.001
Motor Current		<b>A SOU</b>	Show the motor current C16.14 is 9.00A, display accuracy: 0.01
Motor Voltage			Show the motor voltage C16.12 is 380V, display accuracy: 1
Motor Speed			Show the motor speed C16.05 is 1440rpm, display accuracy:1
DC Voltage		FWD REV HZ A RMIN	Show the DC Voltage C16.30 is 540 V, display accuracy: 1
Drive temperature			Show the drive temperature C16.34 is 45 °C , display accuracy:1
Feedback Value			Show the feedback value C16.52 is 28.000, display accuracy: 0.001
Counter A		FWD REV HZ A RANN	Show counter A C16.72 is 65535, display accuracy: 1
Counter B		PND REV BZ A RAMA	Show counter B C16.72 is 65535, diaplay accuracy: 1
Analog in VI			Show analog in VI C16.62 is 10.00V, display accuracy: 0.01
Analog in AI			Show Analog in AI C16.63 is 20.00mA, display accuracy: 0.01
Pulse Input			Show pulse input C16.68 is 50.000kHz, display accuracy: 0.001
Pulse Output			Show pulse output (C16.69) is 50000Hz, display accuracy: 1

Note: The drive only monitor output frequency, reference and output current reference by default. For monitoring other status (DC voltage, etc.), please set the parameter C00.33 (refer to



instructions).

### 4.5 View Alarm Record

If the drive trips, fault code will be showed to illustrate the reason, the drive will save the last 10 trip record.

Key-press	LCP Display	Action Description
MENU	C00.03	Press $(MENU)$ key to display the first basic C00.03.
0	C15.00	Turn Oclockwise to select par. group No. C15.
	C15.00	Press 🕢 to select parameter number.
O	C15.30	Turn Oclockwise to select C15.30
O	[0]	Press O to show the first option of C15.30
O	**	Press O to show the first fault record.
O	[1]	Press to show the second fault record, it can display up to ten recent fault records in turn.

#### 4.6 View State Parameter

By viewing the group 16th parameters can learn the current status of the drive. For example: C16.60 indicators the current state of digital input terminals.

Key-press	LCP Display	Action Description
MENU	C00.03	Press $(MENU)$ to display the first basic parameter C00.03.
O	C16.00	Turn O clockwise to select Par. group No. C16
	C16.00	Press to select parameter No.
O	C16.60	Turn Oclockwise to select C16.60
O	2	Press to view the value in C16.60, 2 indicates status of FOR, DI1, DI2, DI3, DI4 is 0, and status of REV is 1.

# 4.7 LED Display

0	1	2	3	4	5	6	7	8	9
	ł	2		Ч	5	6	٦	8	9
Α	В	С	D	Е	F	G	Н	I	J
				Ē					
ĸ	L	М	Z	0	Ρ	Q	R	S	Т
	Ľ				Ρ		١	5	
U	V	W	Х	Y	Ζ	-	+		=
U	U			IJ	2	-		-	-
а	b	с	d	е	f	g	h	i	j
	Ь	С			F			 	
k	I	m	n	0	р	q	r	s	t
	Ľ		П	O	Ρ	9	Г	5	L
u	v	w	х	у	z				
U	U			IJ					



Chapter 5	Parameter	Overview
-----------	-----------	----------


Par. Group	Par. No.	Name	Range	Unit	Default
	*C00.03	Regional Settings	0: 50Hz 1: 60Hz		0
	C00.04	Operating State at Power-up	0: Resume 1: Forced stop, ref=old 2: Forced stop, ref=0		0
	*C00.06	Grid Type	0~122		*
	C00.10	Active Set-up	1: Set-up 1 2: Set-up 2 9: Multi set-up		1
	C00.11	Edit Set-up	1: Set-up 1 2: Set-up 2		1
	*C00.12	Link Set-up	0: Not linked 20: Linked		20
	C00.31	Custom Readout Min. Value	0.00~99999.00		0.00
	C00.32	Custom Readout Max. Value	0.00~99999.00		100.00
	C00.33	LCP Display Option	0~4095		0
	C00.34	Parameter Type	0: Word mode 1: Double word mode		0
Par. Group 00:	C00.40	HAND Key Option	0: Disabled 1: Enabled		0
Operati- -on /	C00.41	OFF Key Option	0: Disabled 1: Enabled 2: Enabled reset only		1
Display	C00.42	AUTO Key Option	0: Disabled 1: Enabled		1
	C00.46	One Key Recovery Time	0: Disabled 5: 5s 10: 10s 15: 15s 20: 20s		1
	C00.47	LCP Potentiometer Step	0: 0.1 1: 1 2: 10		1
	*C00.51	Set-up Copy	0: No copy 1: Copy from set-up 1 2: Copy from set-up 2 9: Copy from factory setting		0
	C00.60	Set-up Locked	0: Disabled 1: Enabled		0
	C00.62	Password	0~65535		
	C00.63	Password Comfirm	0~65535		
	C00.64	Drive Running Time	0~65535	h	



Par. Group	Par. No.	Name	Range	Unit	Default
	C01.00	Configuration Mode	0: Speed open loop 1: Speed close loop 2: With speed feedback torque control 3: Process closed loop 4: Torque open loop		0
	*C01.01	Motor Control Principle	0: V/F 1: VVC+		0
	*C01.03	Torque Characteristics	0: Constant torque 1: Variable torque 3: Auto Energy Optimization (AEO)		0
	*C01.07	Application Configuration Mode	0: No function 3: Winding and unwinding function		0
	*C01.20	Motor Power	Motor dependant	kW	*
	*C01.22	Motor Voltage	50~1000	V	*
	*C01.23	Motor Frequency	20~400	Hz	*
	*C01.24	Motor Current	Motor dependant	A	*
	*C01.25	Motor Speed	100~9999	rpm	*
	*C01.26	Motor Torque	0. 1~10000.0	N•m	*
Par. Group	*C01.29	Automatic Motor Adaption (AMA)	0: Disabled 1: Enable complete AMA 2: Enable reduced AMA		0
01: Load	*C01.30	Stator Resistance (Rs)	Motor dependant	Ω	*
Motor	*C01.31	Rotor Resistance(Rr)	Motor dependant		
	*C01.33	Stator Leakage Reactance (X1)	Motor dependant	Ω	*
	*C01.35	Main Reactance (Xh)	Motor dependant	Ω	*
	*C01.39	Motor Poles	2~100	Р	4
	*C01.42	Motor Cable Length	0~150	m	*
	C01.50	Motor Magnetisation at Zero Speed	0~300	%	100
	C01.52	Min Speed Normal Magnetising	0.0~10.0	Hz	0.0
	C01.55	V/F Characteristic-V	0.0~999.9	V	*
	C01.56	V/F Characteristic-F	0.0~400.0	Hz	*
	C01.60	Low Speed Load Compensation	0~199	%	100
	C01.61	High Speed Load Compensation	0~199	%	100
	C01.62	Slip Compensation	-400~399	%	100
	C01.63	Slip Compensation Time Constant	0.05~5.00	s	0.10
	C01.64	Resonance Dampening	0~3000	%	50

Par. Group	Par. No.	Name	Range	Unit	Default
	C01.65	Resonance Dampening Time constant	0.005~0.050	s	0.005
	C01.71	Start Delay	0.0~10.0	s	0.0
Par. Group 01: Load / Motor	C01.72	Start Function	0: DC hold 2: Coast		2
	*C01.73	Flying Start	0: Disabled 1: Enabled		0
	*C01.75	Min. Start Frequency	0.00~50.00	Hz	0.00
	C01.76	Jump Frequency	0.0~20.0	Hz	0.0
	C01.80	Function at Stop	0: Coast 1: DC hold		0
	C01.82	Min Speed for Function at Stop	0.0~400.0	Hz	0.0
	C01.88	AC Brake Gain	1.0~2.0		1.4
	C01.90	Motor Thermal Protection	0: No protection 1: Thermistor warning 2: Thermistor trip 3: ETR warning 4: ETR trip 5: ETR warning (Self-cooling mode) 6: ETR trip (Self-cooling mode)		0
	*C01.93	Thermistor Resource	0: None 1: Terminal VI		0
	C02.00	DC Hold Current	0~150	%	50
	C02.01	DC Brake Current	0~150	%	50
	C02.02	DC Braking Time	0.0~60.0	s	10.0
	C02.04	DC Brake Cut in Speed	0.0~400.0	%	0.0
	C02.08	Motor Demagnetization	0~100	%	100
	C02.09	Motor pre excitation rate	0~100	%	0
Par. Group	C02.10	Brake Function	0: Off 1: Resistor brake 2: AC brake		0
02: Brake Function	C02.11	Brake Resistor	5~65535	Ω	*
runction	*C02.14	Brake Resistor Threshold Voltage	Grid type dependant	v	*
	C02.15	Over-voltage Control Threshold Voltage	Grid type dependant	v	*
	C02.16	AC Brake Max Current	0~150	%	100
	C02.17	Over-voltage Control	0: Disabled 2: Mode 1 3: Mode 2		0
	C02.18	Over-voltage Control Integral Time	0.01~0.10	s	0.05

- 46 -



	¢	
1	HOLIP	_

Par. Group	Par. No.	Name	Range	Unit	Default
Par. Group	C02.19	Over-voltage Control Proportional Gain	0~200	%	100
02: Brake Function	C02.20	Release Brake Current	0.00~1200.00	А	0.00
Function	C02.22	Activate Brake Speed	0.0~400.0	Hz	0.0
	C03.00	Reference Range	0: 0~C03.03 1: -C03.03~C03.03		0
	C03.03	Maximum Reference	0~6553.5		50.0
	C03.07	Main Reference Calculation	0: Preset reference + Reference source1, 2, 3 1: Preset reference priority 2: Reference source 2,3 operation 3: Switchover between Reference source 1 and Reference source 2 4: Switchover between Reference source 1 and Reference source 2,3 operation		0
	C03.08	Reference source 2,3 operation mode	0: Reference source 2 + Reference source 3 1: Reference source 2 - Reference source 3 2: Max(Reference source 2, Reference source 3) 3: Min(Reference source 2, Reference source 3)		0
Par.	C03.10	Preset Reference	-100.00~100.00	%	0.00
Group 03: Reference	C03.11	Jog speed	0.0~400.0	Hz	0.0
/	C03.12	Catch up/Slow down Value	0.00~100.00	%	0.00
Ramps	C03.13	Speed Up/Down Value	0.01~50.00	Hz	0.10
	C03.14	Preset Relative Reference	-100.00~100.00	%	0.00
	C03.15	Reference Source 1	0: No function 1: Terminal VI		1
	C03.16	Reference Source 2	2: Terminal AI		2
	C03.17	Reference Source 3	8: Pulse input DI3 10: Preset reference [0]		11
	C03.18	Relative Reference Source	11: Local bus 21: LCP potentiometer		0
	C03.19	Speed Up/Down Value Store	0: No function 1: Stop save 2: Power down save		0
	C03.39	Ramp Time Scale	0: 0.1s 1: 0.01s		1
	C03.40	Ramp 1 Type	0: Linear 2: S ramp		0
	C03.41	Ramp 1 Ramp Up Time	0.05~655.35	s	*
	C03.42	Ramp 1 Ramp Down Time	0.05~655.35	s	*

Par. Group	Par. No.	Name	Range	Unit	Default
	C03.50	Ramp 2 Type	0: Linear 2: S ramp		0
	C03.51	Ramp 2 Ramp Up Time	0.05~655.35	s	*
	C03.52	Ramp 2 Ramp Down Time	0.05~655.35	s	*
Par. Group 03:	C03.60	Ramp 3 Type	0: Linear 2: S ramp		0
Reference	C03.61	Ramp 3 Ramp Up Time	0.05~655.35	s	*
/ Pamps	C03.62	Ramp 3 Ramp Down Time	0.05~655.35	s	*
Ramps	C03.70	Ramp 4 Type	0: Linear 2: S ramp		0
	C03.71	Ramp 4 Ramp Up Time	0.05~655.35	s	*
	C03.72	Ramp 4 Ramp Down Time	0.05~655.35	s	*
	C03.80	Jog Ramp Time	0.05~655.35	s	*
	*C04.10	Motor Speed Direction	0: Clockwise 1: Counter clockwise 2: Both directions		2
	*C04.12	Motor Speed Low Limit	0.0~C04.14	Hz	0.0
	*C04.14	Motor Speed High Limit	C04.12~C04.19	Hz	65.0
	C04.16	Torque Limit Motor Mode	0~1000	%	1000
	C04.17	Torque Limit Generator Mode	0~1000	%	1000
	C04.18	Current Limit	0~300	%	150
	*C04.19	Max Output Frequency	0.0~400.0	Hz	65
Par. Group 04: Limits / Warnings	*C04.21	Frequency Upper Limit Source	0: No function 1: Terminal VI 2: Terminal AI 8: Pulse input DI3 10: Preset reference [0] 11: Local bus 21: LCP potentiometer		1
	C04.28	Low Voltage Overload Limit	5~100	%	100
	C04.29	Low Voltage Udc Limit	50~1000	V	220/380
	C04.30	Motor interrupt function	0: No function 1: Frozen output 3: Crawl 4: Maximum frequency 5: Stop and warn		5
	C04.42	Counter Store at Power down	0: Disable 1: Counter A save 2: Counter B save 3: Both counter A and B save		0



Par. Group	Par. No.	Name	Range	Unit	Default
	C04.50	Warning Current Low	0.00~C16.37	Α	0.00
	C04.51	Warning Current High	0.00~C16.37	А	*
	C04.52	Warning Frequency Low	0.0~400.0	Hz	0.0
	C04.53	Warning Frequency High	0.1~400.0	Hz	65.0
	C04.54	Warning Reference Low	-200.00~200.00	%	0.00
	C04.55	Warning Reference High	-200.00~200.00	%	100.00
	C04.56	Warning Feedback Low	-200.00~200.00	%	0.00
	C04.57	Warning Feedback High	-200.00~200.00	%	100.00
	*C04.58	Missing Motor Phase Function	0: Disable 1: Enable		1
Par. Group	C04.59	Current/Torque Limit Warning Selection	0: Disable 1: Enable		1
04: Limits	C04.61	Bypass Speed From	0.0~400.0	Hz	0.0
/ Warnings	C04.63	Bypass Speed to	0.0~400.0	Hz	0.0
	C04.70	Minimum Torque at Zero Speed	0~100	%	5
	C04.71	Minimum Torque Cut-off Frequency	0.1~50.0	Hz	3.0
	C04.72	Torque open loop stop mode	0: Torque mode 1: Speed mode		0
	C04.80	Unbalance Detection Frequency	5.0-400.0		15.0
	C04.81	Grear Ratio	1.0~100.0	%	9.0
	C04.82	Unbalance Detection Threshold Value	10~300	s	300
	C04.83	Unbalance WaitingTime	0~100	s	5
	C04.84	Unbalance DetectionTime	0~100	Hz	10
	C05.04	DI Filter Time	2~16	ms	4
	C05.05	DI Terminal Logic Selection	0~255		0
Par. Group 05: Digital	C05.06	DO/Relay Terminal Logic Selection	0~255		0
In / Out	C05.09	Function at External Alarm	0: Off 2: Stop and warning 3: Jogging and warning 4: Max. speed and warning 5: Stop and trip		0

Par. Group	Par. No.	Name	Range	Unit	Default
Par. Group 05: Digital In / Out	C05.10	Terminal FOR	0: No operation 1: Reset 2: Coast inverse 3: Coast and reset inverse 6: Stop inverse 8: Start 9: Latched start 10: Reversing 11: Start reversing 12: Enable start forward only		8
	C05.11	Terminal REV	13: Enable start reverse only 14: Jog 15: Preset ref. bit0 16: Preset ref. bit1 17: Preset ref. bit2 18: Preset ref. bit3 19: Freeze reference 20: Freeze output 21: Speed up 22: Speed down		11
	C05.12	Terminal DI1	23: Set-up select 24: Main reference calculation switchover 28: Catch up 29: Slow down 32: Pulse input 34: Ramp bit0 35: Ramp bit1 37: Latched reversing 42: Coast 43: External alarm input 46: Stop		15
	C05.13	Terminal DI2	50: Speed control/torque control switchover 60: Counter A 62: Reset counter A 63: Counter B 65: Reset counter B 110: Process control invalid 160: Diameter select bit0: 161: Diameter select bit1: 162: Diameter calculation suspend 163: Material thickness select bit0: 164: Material thickness		16
	C05.15	Terminal DI3	164: Material thickness         select bit1:         165: Broken line signal input         166: Winding start:         167: Tension lifting         168: Broken line reset         169: Roll diameter reset:         170: Pre-drive start         171: Winding and unwinding         swtich         172: PID suspend         173: Reverse running		18

Т




Par. Group	Par. No.	Name	Range	Unit	Default
Par. Group	C05.30	Terminal DO1	0: No operation 1: Drive ready 3: Remote control ready 4: Drive running/No warning 5: Drive running 7: Run in range/No warning 8: Run on reference/No warning 9: Alarm 10: Alarm or warning 12: Out of current range 13: Below current low 14: Above current high 15: Out of frequency range 16: Below frequency low 17: Above frequency low 17: Above frequency low 19: Below feedback range 19: Below feedback low 20: Above feedback high 21: Thermal warning 22: Ready		0
Par. Group 05: Digital In / Out	C05.40	Relay Function	<ul> <li>23: Remote ready</li> <li>24: Ready, voltage OK</li> <li>25: Reverse</li> <li>26: Bus OK</li> <li>32: Mech. brake control</li> <li>36: Control word bit 11</li> <li>37: Control word bit 12</li> <li>40: Out of reference range</li> <li>41: Below reference low</li> <li>42: Above reference high</li> <li>43: External alarm</li> <li>44: Unbalance warning</li> <li>51: Drive in HAND state</li> <li>52: Drive in AUTO state</li> <li>53: No alarm</li> <li>56: Drive in HAND state</li> <li>57: Drive in AUTO state</li> <li>60: Comparator 0</li> <li>61: Comparator 1</li> <li>62: Comparator 2</li> <li>63: Comparator 3</li> <li>70: Logic rule 0</li> <li>71: Logic rule 1</li> <li>72: Logic rule 3</li> <li>80: Simple PLC digital output 1</li> <li>82: Simple PLC relay 2</li> </ul>		9,5

Par. Group	Par. No.	Name	Range	Unit	Default
Tul. Group	C05.41	Relay On Delay Time	0.00~600.00	s	0.00
	C05.42	Relay Off Delay Time	0.00~600.00	s	0.00
	C05.55	Terminal DI3 Low Frequency	0.00~C05.56	кнг	0.00
	C05.56	Terminal DI3 High Frequency	C05.55~100.00	KHZ	50.00
	C05.57	Terminal DI3 Low Ref./ Feedb. Value	-200.00~200.00	%	0.00
	C05.58	Terminal DI3 High Ref./ Feedb. Value	-200.00~200.00	%	100.00
	C05.59	Terminal DI3 Filter Time	1~1000	ms	100
Par. Group 05: Digital In / Out	C05.60	Terminal DO1 Pulse Output	0: Digital output 10: Output frequency 11: Reference 12: Feedback 13: Output current 16: Power 17: Speed 18: Motor voltage 20: Bus control 21: Terminal DI4 pulse input 22: Terminal V1 input 23: Terminal AI input 26: DC link voltage 30: Output torque		0
	C05.61	Pulse Output Min. Freq.	0.00~C05.62	kHz	0.00
	C05.62	Pulse Output Max. Freq.	C05.61~100.00	kHz	50.00
	C05.63	Pulse Output Min. Scale	0.00~200.00	%	0.00
	C05.64	Pulse Output Max. Scale	0.00~200.00	%	100.00
	C05.70	Encoder resolution	0~4096		1024
	C05.71	EEncoder direction	0~ 1		0
	C06.00	Live Zero Timeout Time	1~99	s	10
	C06.01	Live Zero Timeout Function	0: Off 1: Freeze output 2: Stop 3: Jogging 4: Max. speed 5: Stop and trip		0
	C06.10	Terminal VI Low Voltage	0.00~C06.11	V	0.07
Par. Group	C06.11	Terminal VI High Voltage	C06.10~10.00	V	10.00
06: Analog	C06.12	Terminal VI Low Current	0.00~C06.13	mA	0.14
In/ Out	C06.13	Terminal VI High Current	C06.12~20.00	mA	20.00
Out	C06.14	Terminal VI Low Ref./Feedb. Value	0.00~200.00	%	0.00



Par. Group	Par. No.	Name	Range	Unit	Default
	C06.15	Terminal VI High Ref./ Feedb. Value	0.00~200.00	%	100.00
	C06.16	Terminal VI Filter Time	0.01~10.00	s	0.01
	C06.18	Terminal VI Zero Dead Band	0.0~20.00	V/ mA	0.00
	C06.19	Terminal VI Mode	0: Voltage mode		0
	C06.20	Terminal AI Low Voltage	0.00~C06.21	V	0.07
	C06.21	Terminal AI High Voltage	C06.20~10.00	V	10.00
	C06.22	Terminal AI Low Current	0.00~C06.23	mA	0.14
	C06.23	Terminal AI High Current	C06.22~20.00	mA	20.00
	C06.24	Terminal AI Low Ref./Feedb. Value	0.00~200.00	%	0.00
	C06.25	Terminal AI High Ref./ Feedb. Value	0.00~200.00	%	100.00
	C06.26	Terminal AI Filter Time	0.01~10.00	s	0.01
	C06.28	Terminal AI Zero Dead Band	0.0~20.00	V/ mA	0.00
	C06.29	Terminal AI Mode	0: Voltage mode 1: Current mode		0
Par. Group 06: Analog	C06.70	Terminal VO Mode	0: 0-20mA 1: 4-20mA 3: 0-10V		3
In/ Out	C06.71	Terminal VO Analog Output	0: Digital output 10: Output frequency 11: Reference 12: Feedback 13: Output current 16: Power 17: Speed 18: Motor voltage 20: Bus control 21: Terminal DI4 pulse input 22: Terminal VI input 23: Terminal AI input 26: DC link voltage 30: Output torque		0
	C06.73	Terminal VO Output Min. Scale	0.00~200.00	%	0.00
	C06.74	Terminal VO Output Max. Scale	0.00~200.00	%	100.00
	C06.75	Terminal VO Min. Output	0.00~C06.76		0.00 /4.00
	C06.76	Terminal VO Max. Output	C06.75~10.00/20.00		10.00 /20.00
	C06.81	LCP Pot. Min. Ref.	0.00~200.00	%	0.00
	C06.82	LCP Pot. Max. Ref.	0.00~200.00	%	100.00

Par. Group	Par. No.	Name	Range	Unit	Default
	C07.02	Speed PID Proportional Gain	0.000 ~ 1.000		0.01
	C07.03	Speed PI Integration Time	2.0 ~ 2000.0	ms	8.0
	C07.04	Speed PID Differentiation Time	0.0~200.0	s	30.0
	C07.05	Speed PID Differentiation Limit	1.000~ 20.000		5.0
	C07.06	Speed PID filter time	1.0 ~ 100.0		10.0
	C07.08	Speed PID Feed Forward Factor	0 ~ 500	%	0
	C07.12	Torque PI Proportional Gain	0~500	%	100
	C07.13	Torque PI Integration Time	0.002~2.000	s	0.020
	C07.20	Process PID Feedback Source	0: No function 1: Terminal VI 2: Terminal AI 8: Pulse input DI3 11: Local bus		0
	C07.30	Process PID Normal/Inverse	0: Normal 1: Inverse		0
Par. Group 07:	C07.31	Process PID Anti Windup	0: Disable 1: Enable		0
Controllers	C07.32	Process PID Start	0.0~200.0	Hz	0.0
	C07.33	Process PID Proportional Gain	0.00~10.00		0.01
	C07.34	Process PID Integral Time	0.01~655.35	s	655.35
	C07.35	Process PID Differentiation Time	0.00~10.00	s	0.00
	C07.38	Process PID Feed Forward Factor	0~400	%	0
	C07.39	On Reference Bandwidth	0.0~200.0	%	0
	C07.41	Process PID Output Low	-100.00~100.00	%	0.00
	C07.42	Process PID Output High	-100.00~100.00	%	100.00
	C07.45	Forward Factor Source	0: Setting value 1: Terminal VI 2: Terminal AI 3: Pulse input DI3 4: Communication 5:LCP potentiometer		
	C07.50	I Differentiation Low Limit	-100.00 ~ 100.00	%	0.00
	C07.51	I Differentiation High Limit	-100.00 ~ 100.00	%	100.00
	C07.55	Bandwidth control mode	0: Mode 0; 1: Mode 1 ; 2: Mode 12;		0





Par. Group	Par. No.	Name	Range	Unit	Default
	C08.01	Control Site	0: Digital and communication 1: Digital only 2: Communication only	s	1.0
	C08.03	Communication Timeout Time	0.01~650.0		0
	C08.04	Communication Timeout Function	0: Off 1: Freeze output 2: Stop 3: Jogging 4: Max. speed 5: Stop and trip		0
	C08.06	Reset Communication Timeout	0: Do not reset 1: Do reset		0
	C08.29	Communication Warning Mode	0: Bit mode 1: Alarm number mode		0
	C08.30	Protocol	0: FC 2: Modbus RTU 6: Modbus ASCII		1
	C08.31	Address	0~247	bit/s	
Par. Group 08: Commu niction	C08.32	Baud Rate	0: 2400 1: 4800 2: 9600 3: 19200 4: 38400 5: 57600 6: 76800 7: 115200 8~9: Reserved		2
	C08.33	Parity/Stop Bits	0: Even parity (1 stop bit) 1: Odd parity (1 stop bit) 2: No parity (1 stop bit) 3: No parity (2 stop bit)		2
	C08.35	Min. Response Delay	0.000~0.500	s	0.002
	C08.36	Max. Response Delay	0.010~10.000	s	5.000
	C08.38	Message Response	0: Normal 1: Only response exception message 2: Not response		0
	C08.39	Modbus Parameter Write Store	0: Not saved at power down 1: Saved at power down		0
	C08.50	Coasting Select			3
	C08.53	Start Select	0: Digital input		3
	C08.54	Reversing Select	1: Bus 2: Logic AND		3
	C08.55	Set-up Select	3: Logic OR		3
	C08.56	Preset Reference Select			3

Par. Group	Par. No.	Name	Range	Unit	Default
			0: Off		
	C13.00	Simple PLC Mode	1: Order execution		0
			2: Parallel execution		
			0: False		
			1: True		
			2: Running		
			3: In current range-No warning		
			4: On reference-No warning		
			7: Out of current range		
			8: Below current low		
			9: Above current high		
			10: Out of frequency range		
			11: Below frequency low		
			12: Above frequency high		
			13: Out of feedback range		
			14: Below feedback low		
			15: Above feedback high		
			16: Thermal warning		
		Start Event	17: Mains out of range		
			18: Reversing		
			19: Warning		
			20: Alarm (trip)		
			21: Alarm (trip lock)		
Par. Group	012.01		22: Comparator 0		
13: Simple	C13.01		23: Comparator 1		39
PLC			24: Comparator 2		
			25: Comparator 3		
			26: Logic rule 0		
			27: Logic rule 1		
			28: Logic rule 2 29: Logic rule 3		
			30: Simple PLC time-out 0		
			31: Simple PLC time-out 1		
			32: Simple PLC time-out 2		
			33: Terminal FOR		
			34: Terminal REV		
			35: Terminal DI1		
			36: Terminal DI2		
			37: Terminal DI3		
			39: Start command		
			40: Drive stopped		
			50: Simple PLC time-out 3		
			51: Simple PLC time-out 4		
			52: Simple PLC time-out 5		
			53: Simple PLC time-out 6		
			54: Simple PLC time-out 7		
	C13.02	Stop Event	See C13.01		40
	C12.02	Denet Simula DI C	0: Do not reset		0
	C15.03	Reset Simple PLC	1: Do reset		0



Par. Group	Par. No.	Name	Range	Unit	Default
	C13.04	Simple PLC Store	0: No function 1: Power down save 2: Stop save 3: Both power down and stop save		0
	C13.10	Comparator Operand	0: Disabled 1: Reference 2: Feedback 3: Motor speed 4: Motor current 6: Motor power 7: Motor voltage 12: Terminal VI input 13: Terminal AI input 20: Fault number 30: Counter A 31: Counter B		0
Par. Group	C13.11	Comparator Operator	0: Less than 1: Approx. Equal 2: Greater than		1
13: Simple PLC	C13.12	Comparator Value	-9999.0~9999.0		0.0
	C13.20	Simple PLC Timer	0.0~99999.0	s	0.0
	C13.40	Logic Rule Boolean 1	See C13.01		0
	C13.41	Logic Rule Operator 1	0: Disabled 1: AND 2: OR 3: AND NOT 4: OR NOT 5: NOT AND 6: NOT OR 7: NOT AND NOT 8: NOT OR NOT		0
	C13.42	Logic Rule Boolean 2	See C13.01		0
	C13.43	See C13.01	See C13.41		0
	C13.44	Logic Rule Boolean 3	See C13.01		0
	C13.51	Simple PLC Event	See C13.41		0

### HLP-SD100 Series

	C
1	HOLIP

Par. Group	Par. No.	Name	Range	Unit	Default
			0: Disabled		
			1: No action		
			2: Select set-up 1		
			3: Select set-up 2		
			10: Select preset ref 0		
			11: Select preset ref 1		
			12: Select preset ref 2		
			13: Select preset ref 3		
			14: Select preset ref 4		
			15: Select preset ref 5		
			16: Select preset ref 6		
			17: Select preset ref 7		
			18: Select ramp 1		
			19: Select ramp 2		
			20: Select ramp 3		
			21: Select ramp 4		
			22: Run		
			23: Run reverse		
			24: Stop		
			27: Coast		
			28: Freeze output		
			29: Start timer 0		
D C			30: Start timer 1		
Par. Group	C12 52	Simula DLC Astion	31: Start timer 2		0
13: Simple PLC	C13.52	Simple PLC Action	32: Set terminal DO1 low		0
FLC			33: Set terminal DO2 low		
			34: Set relay 1 low		
			35: Set relay 2 low		
			38: Set terminal DO1 high		
			39: Set terminal DO2 high		
			40: Set relay 1 high		
			41: Set relay 2 high		
			50: Select preset ref 8		
			51: Select preset ref 9		
			52: Select preset ref 10		
			53: Select preset ref 11		
			54: Select preset ref 12		
			55: Select preset ref 13		
			56: Select preset ref 14		
			57: Select preset ref 15		
			60: Reset counter A		
			61: Reset counter B		
			65: Start timer 3		
			66: Start timer 4		
			67: Start timer 5		
			68: Start timer 6		
			69: Start timer 7		
			70: Reverse		



Par. Group	Par. No.	Name	Range	Unit	Default
	C14.01	Switching Frequency	2~6: 2~6kHz 7: 8kHz 8: 10kHz 9: 12kHz 10: 16kHz		*
	*C14.03	Overmodulation	0: Off 1: On		1
	*C14.07	Dead Compensation	0~120	%	100
	C14.08	Damping Gain Factor	0~200	%	96
	C14.10	Action at Mains Failure	0: No function 1: Ctrl ramp-down 2: Ctrl ramp-down, trip 3: Coasting 4: Kinetic back-up 5: Kinetic back-up, trip 6: Alarm		0
	C14.11	Mains Voltage at Mains Failure	100~800	v	*
Par. Group 14: Special Functions	C14.12	Function at Mains Imbanlance	0: Trip (Low sensitivity) 1: Warning (Low sensitivity) 2: Disabled 4: Warning (Middle sensitivity) 5: Trip (Middle sensitivity) 6: Trip (High sensitivity)		0
	C14.16	Low Voltage Mode	0: Disable 1: Enable		0
	C14.17	Automatic Voltage Regulation	0: Disable 1: Enable		1
	C14.18	Delay Time of Auto Restart When Power up Again	0.0~3600.0	s	0.0
	C14.20	Reset Mode	0: Manual reset 1~10: Auto reset 1-10 times 11: Auto reset 15 times 12: Auto reset 12 times 13: Infinite auto reset		0
	C14.21	Automatic Restart Time	0~600	s	10
	C14.22	Operation Mode	0: Normal operation 2: Initialization 3: Backup user settings 4: Recover user settings		0
	C14.23	Trip lock	0: Disable 1: Enable		0
	C14.27	Action at Drive Fault	0: Trip 1: Warning		0
	C14.30	Current Controller 1 Proportional Gain	0~500	%	100

Par. Group	Par. No.	Name	Range	Unit	Default
	C14.31	Current Controller 1 Integration Time	0.000~2.000	s	0.020
	C14.32	Current Controller Filter Time	2.0~100.0	ms	*
	C14.33	Current Controller 2 Proportional Gain	0~300	%	0
Par. Group	C14.34	Current Controller 2 Integration Time	0.000~2.000	s	0.020
14: Special Functions	*C14.40	VT Level	40~90	%	90
runctions	*C14.41	AEO Min. Magnetisation	40~75	%	66
	*C14.50	RFI Filter Selection	0: Off 1: On 2: Reserved		1
	*C14.51	DC Link Compensation	0: Off 1: On		0
	C14.68	Overheat warning relative temperature	0~25	°C	5
	C15.00	Operating Days	0~9999	d	
	C15.01	Running Hours	0~65535	h	
	C15.02	kWh Counter	0~65535	kWh	
	C15.03	Power Up's	0~65535		
	C15.04	Over Temperatures	0~65535		
Par. Group	C15.05	Over Voltages	0~65535		
15: Drive Information	C15.06	Reset kWh Counter	0: Do not reset 1: Do reset		0
	C15.07	Reset Running Hours Counter	0: Do not reset 1: Do reset		0
	C15.30	Alarm Code	0~255		
	C15.31	Internal Fault Reason	-32767~32767		
	C15.38	Warning Code	0~255		
	C15.43	Software Version			
	C16.00	Control Word	0~65535		
	C16.01	Reference	-4999.000~4999.000		
	C16.02	Reference	-200.0~200.0	%	
Par. Group 16: Data Readouts	C16.03	Status Word	0~65535		
	C16.04	Active Set-up	0: Set-up 1 1: Set-up 2 2: Multi Set-up		
	C16.05	Motor Speed	0~9999	rpm	
	C16.06	Low Voltage Frequency Limit	0.0~400.0	Hz	



Par. Group	Par. No.	Name	Range	Unit	Default
	C16.09	Custom Readout	0.00~9999.00		
	C16.10	Output Power	0.00~655.35	kW	
	C16.12	Motor Voltage	0~65535	V	
	C16.13	Output Frequency	0.0~400.0	Hz	
	C16.14	Output Current	0.00~655.35	A	
	C16.15	Output Frequency	0.0~200.0	%	
	C16.16	Output Torque	-200.0~200.0	%	
	C16.18	Motor Thermal	0~100	%	
	C16.30	DC Link Voltage	0~65535	V	
	C16.31	IO Temperature	-128~127	°C	
	C16.34	IGBT Temperature	-128~127	°C	
	C16.35	Drive Thermal	0~255	%	
	C16.36	Drive Nominal Current	0.0~6553.5	Α	
	C16.37	Drive Max. Current	0.0~6553.5	A	
	C16.38	Simple PLC State	0~255		
	C16.40	Wobble Length	0.000~60.00	km	
Par. Group	C16.44	Line Speed	0.000~4999.000	m/ min	
16: Data Readouts	C16.48	Power Board Temperature	-128~127	°C	
Tiendouto	C16.49	Rectifier Temperature	-128~127	°C	
	C16.50	Main Reference	-200.0~200.0	%	
	C16.51	Pulse Reference	-200.0~200.0	%	
	C16.52	Feedback	-200.0~200.0	%	
	C16.57	Unbalance Value	0~300	%	
	C16.60	Digital Input	0~65535		
	C16.61	Terminal VI Setting	0: 0~20mA 1: 0~10V		
	C16.62	Analog Input VI	0.00~20.00	V /mA	
	C16.63	Terminal AI Setting	0: 0~20mA 1: 0~10V		
	C16.64	Analog Input AI	0.00~20.00	V /mA	
	C16.65	Analog Output VO	0.00~20.00	V	
			0~255	/mA	
		Digital Output	0~255		
		Encoder input value	0.00, 100.00	h L	
		Pulse Input DI3	0.00~100.00	kHz	
	C10.09	Pulse Output DO1	0.00~100.00	kHz	


Par. Group	Par. No.	Name	Range	Unit	Default
Par. Group 16: Data Readouts	C16.71	Relay Output	0~65535		
	C16.72	Counter A	0~65535		
	C16.73	Counter B	0~65535		
	C16.78	Analog Output AO	0.00~20.00	mA	
	C16.79	PID output value	0~100	%	
	C16.86	Communication Reference	-32768~32767		
	C16.90	Alarm Word 1	0~0xFFFFFFFFUL		
	C16.91	Alarm Word 2	0~0xFFFFFFFFUL		
	C16.92	Warning Word 1	0~0xFFFFFFFFUL		
	C16.93	Warning Word 2	0~0xFFFFFFFFUL		
Par. Group 39: Communi cation User- Defined Par.	C39.00	Communication User- Defined Par. 0	0~9999		310
	C39.01	Communication User- Defined Par. 1	0~9999		310
	C39.02	Communication User- Defined Par. 2	0~9999		310
	C39.03	Communication User- Defined Par. 3	0~9999		310
	C39.04	Communication User- Defined Par. 4	0~9999		310
	C39.05	Communication User- Defined Par. 5	0~9999		310
	C39.06	Communication User- Defined Par. 6	0~9999		310
	C39.07	Communication User- Defined Par. 7	0~9999		310
	C39.08	Communication User- Defined Par. 8	0~9999		310
	C39.09	Communication User- Defined Par. 9	0~9999		310
	C39.10	Communication User- Defined Par. 10	0~9999		310
	C39.11	Communication User- Defined Par. 11	0~9999		310
	C39.12	Communication User- Defined Par. 12	0~9999		310
	C39.13	Communication User- Defined Par. 13	0~9999		310
	C39.14	Communication User- Defined Par. 14	0~9999		310
	C39.15	Communication User- Defined Par. 15	0~9999		310
	C39.16	Communication User- Defined Par. 16	0~9999		0

- 62 -



Par. Group	Par. No.	Name	Range	Unit	Default
Par. Group 39: Communi cation User- Defined Par.	C39.17	Communication User- Defined Par. 17	0~9999		0
	C39.18	Communication User- Defined Par. 18	0~9999		0
	C39.19	Communication User- Defined Par. 19	0~9999		0
	C39.20	Communication User- Defined Par. 20	0~9999		0
	C39.21	Communication User- Defined Par. 21	0~9999		0
	C39.22	Communication User- Defined Par. 22	0~9999		0
	C39.23	Communication User- Defined Par. 23	0~9999		0
	C39.24	Communication User- Defined Par. 24	0~9999		0
	C39.25	Communication User- Defined Par. 25	0~9999		0
	C39.26	Communication User- Defined Par. 26	0~9999		0
	C39.27	Communication User- Defined Par. 27	0~9999		0
	C39.28	Communication User- Defined Par. 28	0~9999		0
	C39.29	Communication User- Defined Par. 29	0~9999		0
	C39.30	Communication User- Defined Par. 30	0~9999		0
	C39.31	Communication User- Defined Par. 31	0~9999		0
	C39.32	Communication User- Defined Par. 32	0~9999		0
	C39.33	Communication User- Defined Par. 33	0~9999		0
	C39.34	Communication User- Defined Par. 34	0~9999		0
	C39.35	Communication User- Defined Par. 35	0~9999		0
	C39.50	Communication User- Defined Par. 0 index	0~9999		0
	C39.51	Communication User- Defined Par. 1 index	0~9999		1
	C39.52	Communication User- Defined Par. 2 index	0~9999		2

Par. Group	Par. No.	Name	Range	Unit	Default
	C39.53	Communication User- Defined Par. 3 index	0~9999		3
	C39.54	Communication User- Defined Par. 4 index	0~9999		4
	C39.55	Communication User- Defined Par. 5 index	0~9999		5
	C39.56	Communication User- Defined Par. 6 index	0~9999		6
	C39.57	Communication User- Defined Par. 7 index	0~9999		7
	C39.58	Communication User- Defined Par. 8 index	0~9999		8
	C39.59	Communication User- Defined Par. 9 index	0~9999		9
	C39.60	Communication User- Defined Par. 10 index	0~9999		10
	C39.61	Communication User- Defined Par. 11 index	0~9999		11
	C39.62	Communication User- Defined Par. 12 index	0~9999		12
Par. Group 39:	C39.63	Communication User- Defined Par. 13 index	0~9999		13
Communi cation User- Defined Par.	C39.64	Communication User- Defined Par. 14 index	0~9999		14
	C39.65	Communication User- Defined Par. 15 index	0~9999		15
	C39.66	Communication User- Defined Par. 16 index	0~9999		0
	C39.67	Communication User- Defined Par. 17 index	0~9999		0
	C39.68	Communication User- Defined Par. 18 index	0~9999		0
	C39.69	Communication User- Defined Par. 19 index	0~9999		0
	C39.70	Communication User- Defined Par. 20 index	0~9999		0
	C39.71	Communication User- Defined Par. 21 index	0~9999		0
	C39.72	Communication User- Defined Par. 22 index	0~9999		0
	C39.73	Communication User- Defined Par. 23 index	0~9999		0
	C39.74	Communication User- Defined Par. 24 index	0~9999		0





Par. Group	Par. No.	Name	Range	Unit	Default		
	C39.75	Communication User- Defined Par. 25 index	0~9999		0		
	C39.76	Communication User- Defined Par. 26 index	0~9999		0		
	C39.77	Communication User- Defined Par. 27 index	0~9999		0		
	C39.78	Communication User- Defined Par. 28 index	0~9999		0		
	C39.79	Communication User- Defined Par. 29 index	0~9999		0		
Par.	C39.80	Communication User- Defined Par. 30 index	0~9999		0		
Group 39: Communi cation User-	C39.81	Communication User- Defined Par. 31 index	0~9999		0		
Defined Par.	C39.82	Communication User- Defined Par. 32 index	0~9999		0		
	C39.83	Communication User- Defined Par. 33 index	0~9999		0		
	C39.84	Communication User- Defined Par. 34 index	0~9999		0		
	C39.85	Communication User- Defined Par. 35 index	0~9999		0		
	Control mode related parameters						
	C29.00	Winding mode	0: Winding 1: Unwinding		0		
Par. Group	C29.01	Tension control mode	0: Close Speed Loop control 1: Constant linear speed control 2: Open torque control 3: Close torque control		0		
29: Winding and	C29.02	Mechanical gear ratio	0.01 ~ 100.00		1.00		
unwinding		Lir	near speed related parameters				
function.	C29.06	Linear speed setting source	0: Digital setting 1: Terminal VI 2: Terminal AI 8: Pulse input		1		
	C29.07	Minimum linear speed for calculation of roll diameter	0.1~5000.0	m/ min	200		
	C29.08	Maximum linear speed	0.1~5000.0	m/ min	1000		
	C29.09	Digital line speed	0.0~5000.0	m/ min	00		




Par. Group	Par. No.	Name	Range	Unit	Default	
		Roll dian	neter calculation related parameters			
	C29.12	Roll diameter calculation methods selection	0: Digital setting 1: Terminal VI 2: Terminal AI 8: Pulse input 30: Calculate by linear speed 31: Calculate by material thickness		30	
	C29.13	Minimum roll diameter	1~1000	mm	100	
	C29.14	Maximum roll diameter	1~1000	mm	500	
	C29.15	Initial roll diameter source	0: Digital setting, i.e. setting value of parameter 29.16. 1: Terminal VI 2: Terminal AI 8: Pulse input		0	
	C29.16	Initial roll diameter	0~1000	mm	100	
	C29.17	Roll diameter filter time	0.0~100.0	s	2.0	
	C29.18	Roll diameter variation ratio	0~300	mm	0	
	C29.19	Digital Diameter Value	0~1000	mm	100	
_	Winding diameter calculated by material thickness related parameters					
Par. Group 29: Winding	C29.22	Pulses per turn	0.001 ~60.000	К	0.100	
and	C29.23	Turns per layer	0.001 ~10.000	К	0.001	
unwinding	C29.24	Minimum thickness	0.01~100.00	mm	1.00	
function.	C29.25	Maximum thickness	0.01~100.00	mm	50.00	
,	C29.26	Material thickness setting source	0: Digital setting 1: Terminal VI 2: Terminal AI 8: Pulse input		0	
	C29.27	Initial thickness	0.01 ~100.00	mm	0.01	
	C29.28	Accumulative roll diameter signal source	0: Digital setting 7: Encoder input 88: Pulse input; 32: Angular speed calculation		0	
		Broken	material testing related parameters	1		
	C29.32	Broken material auto detection Function	0: Invalid 1: According to the broken line proximity switch 2: According to the swing rod feedback 3: According to the roll diameter variation		0	
	C29.33	Broken material auto detection Low Speed	0.1 ~5000.0	m/ min	200	
	C29.34	Broken material detection error range	0.1~50.0	%	1.0	



Par. Group	Par. No.	Name	Range	Unit	Default		
	C29.35	Broken material detection judgment delay	0.1~60.0	s	2.0		
	C29.36	Broken material detection start delay	0~20	s	6		
	C29.37	Broken material action selection	0: Coast and alarm 1:Stop and alarm 2: Only alarm		0		
	C29.38	Broken material Automatic reset	0: Invalid 1: Valid		0		
	C29.39	Broken material automatic reset time	0.0~100.0	s	6.0		
			PID related parameters				
	C29.43	PID Automatic adjustment basis	0: Only group 1 parameters 11: According to the roll diameter 2: According to the running frequency 3: According to the linear speed		0		
	C29.44	PID initial target set value	0: Fixed 1: According to the current feedback 2: According to the setting value 3: Use PD function at the beginning		0		
Par. Group	C29.45	PID initial setting	0.0~200.0	%	100.0		
29: Winding and	C29.46	Transition time of PID initial setting	0.1~6000.0	s	5.0		
unwinding function.	C29.50	Brake holding output frequency	0.0~50.0	Hz	1.5		
	C29.51	Brake holding time	0.1~100.0	S	1.0		
	C29.52	Jog selection in running	0: No action; 1: Coast and output the brake holding signal		0		
	Tension setting related parameters						
	C29.55	Tension setting source	0: Digital setting 1: Terminal VI 2: Terminal AI 8: Pulse input		0		
	C29.56	Digital tension setting	0~50000	Ν	0		
	C29.57	Maximum tension	0~50000	N	0		
	C29.58	Tension lifting at zero speed	0.0~100.0	%	0		
	C29.59	Tension taper source	0: Digital setting 1: Terminal VI 2: Terminal AI 8: Pulse input		0		
	C29.60	Digital taper setting	0.00~100.00	%	0		
	C29.61	Roll diameter range start value	0.001~10.000	m	10.000		

Par. Group	Par. No.	Name	Range	Unit	Default
	C29.62	Taper compensation correction	0~10.000	m	0
		Related p	parameters of tension compensation		
	C29.66	Mechanical inertia compensation coefficient	0.00 ~ 600.00	Kg .m2	0
	C29.67	Material density	0~60.000	Kg/ m3	0
	C29.68	Material width	0~60.000	m	0
	C29.69	Full-reel material inertia compensation coefficient	0.00 ~ 600.00	Kg .m2	0
	C29.70	Frequency of zero speed	0.0 ~ 50.0	Hz	0.0
	C29.71	Static friction compensation coefficient	0.00~100.00	%	0
	C29.72	Dynamic friction frequency	0.0 ~ 100.0	Hz	50.0
	C29.73	Dynamic friction compensation coefficient	0.00 ~ 100.00	%	0
	C29.74	Inertia self-learning torque 1	0.00 ~ 100.00	%	25
	C29.75	Inertia self-learning torque 2	0.00 ~ 100.00	%	45
Par. Group 29: Winding and unwinding	C29.76	Compensation value self- learning	0: Invalid 1: Friction self-learning 2: Mechanical inertia self-learning 3: Material inertia self-learning		0
function.	C29.78	Minimum linear acceleration	0.00~10.000	m/ min	0.00
	C29.79	Deceleration mechanical inertia ratio	0~200	%	100
	C29.81	Reverse running	0~1		0
	C29.83	Terminal tension lifting ratio	0.0~200.0	%	50
		Pre-c	drive control related parameters		
	C29.84	Pre-drive speed gain	-100.00~100.00	%	0.00
	C29.85	Pre-drive end delay time	0.0~20.0	S	1.0
	C29.87	Frequency limit gain of linear speed	-50.0~50.0	%	0.0
	C29.88	Frequency limit gain of linear speed	-30.0~30.0	Hz	0.0
		М	onitoring related parameters		
	C29.91	Input line speed	0~4096	m/ min	
	C29.92	Current roll diameter	0~10000	mm	
	C29.93	Actual tension value (After taper calculation)	0~50000	N	





Par. Group	Par. No.	Name	Range	Unit	Default		
	DI Terminal Correlative Parameters						
Par. Group 29: Winding and unwinding function.	C05.10 ~ C05.11	Digital input terminal(FOR, REV、DI1、DI2、DI3)	160: Diameter bit0:         161: Diameter bit01:         162: Diameter calculation suspend:         163: Material thickness bit0         164: Material thickness bit1:         165: Broken line signal input:         166: Winding start:         167: Tension liftiing;         168: Broken line reset:         169: Roll diameter reset:         170: Pre-drive start         171: Winding and unwinding Switch         172: PID suspend         173: Reverse running				

Note: Reference signed with "\*" in Par. No. column means this parameter can't be modified when the motor is running. In factory setting column, "\*" means the default setting for this parameter is determined by the drive type.



# Chapter 6 Parameter Description

## 6.1 Group 00: Operation/Display

#### C00.0\* Basic Settings

Par. N	o.	Name	Range	Unit	Default
*C00.03		Degional Cattings	0: 50Hz		0
		Regional Settings	1: 60Hz		0

This parameter is used to select motor frequency default value according to different regions.

0: 50Hz, Motor frequency default value is 50 Hz, see C01.23;

1: 60Hz, Motor frequency default value is 60 Hz, see C01.23;

Attention: This parameter can not be adjusted when motor is running. Change this parameter may result in changes in the value of the following parameters: C01.23, C01.25, C01.39, C01.56, C01.30, C01.31, C01.33, C01.35, C01.39 and C01.56.

Par. No.	Name	Range	Unit	Default
	Operating State at Power-up	0: Resume		
C00.04		1: Forced stop, ref=old		0
		2: Forced stop, ref=0		

Selects the operating mode upon reconnection of the drive to mains voltage after power down in Hand operation mode.

- 0: Resume, restarts the drive maintaining the same local reference and the same start/stop settings as before the drive was powered down.
- 1: Forced stop, ref=old, restarts the drive with a saved local reference, after mains voltage reappears and after pressing HAND key.
- 2: Forced stop, ref=0, resets the local reference to 0 upon restarting the drive.

Attention: This parameter is only active in Hand operation mode.

Par. No.	Name	Range	Unit	Default
*C00.06	Grid Type	0~122		*

Selects the grid type. Output frequency and voltage will be changed according to the grid type.

0: 200-240V/50Hz/IT-Grid 1: 200-240V/50Hz/IT-Delta 2: 200-240V/50Hz 10: 380-440V/50Hz/IT-Grid 11: 380-440V/50Hz/IT-Delta 12: 380-440V/50Hz/IT-Grid 20: 440-480V/50Hz/IT-Grid 21: 440-480V/50Hz/IT-Delta



22: 440-480V/50Hz 100: 200-240V/60Hz/IT-Grid 101: 200-240V/60Hz/IT-Delta 102: 220-240V/60Hz 110: 380-440V/60HZ/IT-Grid 111: 380-440V/60Hz/IT-Delta 112: 380-440V/60Hz/IT-Grid 121: 440-480V/60Hz/IT-Grid 122: 440-480V/60Hz

#### C00.1\* Set-up Operations

Define and control the individual parameter setups.

The drive has two parameter setups that can be programmed independently of each other. This makes the drive very flexible and able to solve advanced control functionality problems, often saving the cost of external control equipment. For example these can be used to program the drive to operate according to one control scheme in one setup (e.g. motor 1 for horizontal movement) and another control scheme in another setup (e.g. motor 2 for vertical movement). Alternatively they can be used by an OEM machine builder to identically program all their factory fitted drives for different machine types within a range to have the same parameters and then during production/commissioning simply select a specific setup depending on which machine the drive is installed on.

Par. No.	Name	Range	Unit	Default
	Active Set-up	1: Set-up 1		
C00.10		2: Set-up 2		1
		9: Multi Set-up		

Selects the set-ups to control the drive functions.

- 1: Set-up 1, Set-up 1 to Set-up 2 are the two separate parameter set-ups within which all parameters can be programmed.
- 2: Set-up 2
- 9: 9: Multi Set-up, two set-ups can be changed each other via digital input or communication commands.

Par. No.	Name	Range	Unit	Default
C00.11	Edit Set-up	1: Set-up 1		1
		2: Set-up 2		1

Selects the set-up to be edited during operation, either the active set-up or one of the inactive setups.



Par. No.	Name	Range	Unit	Default
C00.12	Link Set-up	0: Not linked		20
		20: Linked		20

- 0: Not linked, parameters between two set-ups can not be changed each other while the motor is running;
- 20: Linked, parameters between two set-ups can be changed each other while the motor is running via digital input or communication commands. But this facility is best for the same motor, else the link will synchronize the parameters that can not be changed while the motor is running (mainly motor parameters).

C00.3\* LCP Custom Readout

Par. No.	Name	Range	Unit	Default
C00.31	Custom Readout Min. Value	0.00~99999.00		0.00
C00.32	Custom Readout Max. Value	0.00~99999.00		100.00

It is possible to customize a readout value in the drive. Custom Readout Value is linear proportional to speed, it is stored in parameter C16.09.

The calculation of Custom Readout Value (C16.09) is shown below:

C16.09 = (C00.32 - C00.31) × C16.13 ÷ C04.14 + C00.31

Par. No.	Name	Range	Unit	Default
C00.33	LCP Display Option	0~4095		0

The LCP is fixed to display the output frequency, reference and motor current (switch by  $\blacktriangleleft$  key). This parameter is used to show another 11 basic operating states of the drive, each states corresponds to a binary code : "1" means display the item, "0" means does not display the item. For example, if you want to display the states of the temperature and the terminal VI on LCP. Transform the binary code to decimal digit,

Bit	Bit	Bit	Bit	Bit	Bit	Bit	Bit	Bit	Bit	Bit	Bit
11	10	9	8	7	6	5	4	3	2	1	0
Custom Readout	Pulse Output	Pulse Input	AI	VI	Counter B	Counter A	Feedback Value	Temperature	DC-Voltage	Motor Speed	Motor Voltage
0	0	0	0	1	0	0	0	1	0	0	0



Par. No.	Name	Range	Unit	Default
C00.34	Parameter Type	0: Word mode		0
		1: Double word mode		0

This parameter is used for compatible with the previous software version (version number less than 1.34). These previous software use double word to read some parameters.

### C00.4\* LCP Keypad

Enable, disable individual keys on the LCP.

Par. No.	Name	Range	Unit	Default
C00.40	HAND Key Option	0: Disabled		0
		1: Enabled		0

0: Disabled, No effect when HAND key is pressed. Select [0] Disabled to avoid accidental start of the drive in Hand operation mode;

1: Enabled, HAND key is functional;

Par. No.	Name	Range	Unit	Default
		0: Disabled		
C00.41	OFF Key Option	1: Enabled		1
		2: Enabled reset only		

0: Disabled, avoids accidental stop of the drive;

1: Enabled, OFF key stop signal and reset of any fault;

2: Enabled reset only, reset only (fault), stop (off) function is disabled;

Par. No.	Name	Range	Unit	Default
C00.42	AUTO Key Option	0: Disabled		1
C00.42		1: Enabled		1

0: Disabled, avoids accidental start of the drive in AUTO operation mode;

1: Enabled, AUTO key is functional;

Par. No.	Name	Range	Unit	Default
		0: Disabled		
		5: 5s		
C00.46	One Key Recovery Time	y Time 10: 10s		1
		15: 15s		
		20: 20s		

"One Key Recovery" is that user can press OFF key to recover the backup settings if the settings have been backuped. If the settings have not been backuped, this function is disabled.

One key Recovery Time is used to determine how many seconds should OFF key pressed to recover the backup settings, it is set to 0 to disable one key recovery function.



Note: If an alarm happens, press OFF key will reset alarm first.

Par. No.	Name	Range	Unit	Default
C00.47	LCP Potentiometer Step	0: 0.1 1: 1 2: 10		1

This parameter determines the reference value increase or decrease when the LCP potentiometer rotates.

C00.5\* Copy/Save

Par. No.	Name	Range	Unit	Default
C00.51	Set-up Copy	0: No copy 1: Copy from set-up 1 2: Copy from set-up 2 9: Copy from factory setting		0

0: No copy;

- 1: Copy from set-up 1, Copies all parameters in the Set-up 1 to the edit set-up (defined in C00.11);
- 2: Copy from set-up 2, Copies all parameters in the Set-up 2 to the edit set-up (defined in C00.11);
- 9: Copy from factory setting, Copies factory setting to the edit set-up (defined in C00.11);

Attention: When selected set-up is the same to the edit set-up, copy function doesn't work; both LCP and parameter database are locked while copying.

#### C00.6\* Protection

Par. N	. Name	Range	Unit	Default
C00.60	Set-up Locked	0: Disabled 1: Enabled		0

0: Disabled

1: Enabled, prevent unauthorized editing of parameters.

Attention: This function is only valid to LCP, not active to local bus.

Par. No.	Name	Range	Unit	Default
C00.62	Password	0~65535		
C00.63	Password Comfirm	0~65535		
C00.64	Drive Running Time	0~65535	h	

These parameters are used to set the timer to stop the drive.

Initial state: C00.62 password is "0", C00.64 drive running time is "0", the password and drive running time are invalid;

Setting the Password: Enter C00.62, it shows "0", change the parameter value (such as 2003), Re-

enter C00.62 shows "0"; Enter C00.63, it shows "0", after modifying the parameter value, and if the parameter value is the same as C00.62 (such as 2003), it displays "P.Set" 2s, password has been set; After the password has been set, re-enter the C00.62 shows "0"; If the parameter value is not the same as C00.62, it shows "Err" 2s, password setting fails; Back to the initial state.

Setting the drive running the time: After the password has been set, change the C00.64 value (such as 2000h) to set the drive running the time. After setting, the C00.64 cannot be changed. If the password has been set, but not set C00.64, reboot the drive, it will report "A.96", please set the correct password into C00.62 to clear the warning.

Clear password and the drive running time: If the password has been set, enter C00.62, it shows "0"; set the correct password into C00.62, it will display "P.Yes" 2s, then the password and the drive running time are cleared; If set the wrong password value, it will display "P.No", after 3 consecutive wrong password, the drive locked, you can not modify the parameter, it displays "A.96". It must be powered off and on again to clear "A.96" warning.

12h before the drive running time, the drive shows "A.96" to prompt the user that the running time will be over. If the running time is over, the drive can still be used; if you stop the drive, the drive will not accept any command to start, the drive displays "A.96".

Note: The drive running time refers to the drive power-up time.

# 6.2 Group 01: Load and Motor

#### C01.0\* General Settings

Par. No.	Name	Range	Unit	Default
	Configuration Mode	0: Speed open loop 1: Speed close loop		
C01.00		2: With speed feedback torque control		0
		3: Process closed loop		
		4: Torque open loop		

- 0: Speed open loop, Enables speed control (without feedback signal from motor) with automatic slip compensation for almost constant speed at varying loads. Compensations are active but can be disabled in the Load/Motor par. group C01.0\*;
- 1: Speed close loop,
- 2: With speed feedback torque control
- 3: Process closed loop, Enables the use of process control in the drive. The process control parameters are set in par. groups 7-2\* and 7-3\*.
- 4: Torque open loop, Enables the use of torque open loop in VVC+ mode (C01.01 Motor Control Principle). The torque PID parameters are set in par. group C07.1\*;

Attention: If configuration mode is changed, C03.00, C03.03 will be restored to factory setting.

Attention: If configuration mode is changed, C03.00, C03.03 will be restored to factory setting.

I	Par. No.	Name	Range	Unit	Default
	*C01.01	01.01 Motor Control Principle	0: V/F		0
Collo1 Motor Control P	Motor Control Principle	1: VVC+		0	

Selects which motor control principle to employ.

- 0: V/F, for special motor or parallel connected motors in special motor applications. When V/F is selected the characteristic of the control principle can be edited in C01.55 V/F Characteristic V and C01.56 V/F Characteristic F;
- 1: VVC+, Voltage Vector Control principle suitable for higher requirements on control performance applications. The main benefit of VVC+ operation is that it uses a robust motor model;

Attention: When V/F control principle is selected, slip compensation and load compensation are invalid; When VVC+ control principle is selected, it includes slip compensation and load compensation itself.

Par. No.	Name	Range	Unit	Default
*C01.03	Torque Characteristics	0: Constant torque		
		1: Variable torque		0
		3: Auto Energy Optimization		0
		(AEO)		

Select the torque characteristic required. VT and AEO are both energy saving operations.

- 0: Constant torque, Motor shaft output provides constant torque under variable speed control.
- 1: Variable torque, Motor shaft output provides variable torque under variable speed control, usually used for fan or pump applications. Set the variable torque level in C14.40 VT Level.
- Auto Energy optimization (AEO), Automatically optimises energy consumption by minimising magnetisation and frequency via C14.41 AEO Minimum Magnetisation;

Par. No.	Name	Range	Unit	Default
	Application Configuration	0: No function		
*C01.07 Mode		1: Winding and Unwinding		0
	Mode	function		

When you need to use the winding and unwinding function, first set the C01.07 to 3. winding and unwinding function, See Par C29.\*.

0: No function;

1: Winding and Unwindting function, see parameter group C29.\*;

#### C01.2\* Motor Date

Par. No.	Name	Range	Unit	Default
*C01.20	Motor Power	Motor dependant	kW	*
*C01.22	Motor Voltage	50~1000	V	*
*C01.23	Motor Frequency	20~400	Hz	*
*C01.24	Motor Current	Motor dependant	А	*
*C01.25	Motor Speed	100~9999	rpm	*
*C01.26	Motor Torque	0.1~6553.5	N•m	*

Set the parameters according to the motor nameplate no matter whether V/F control or VVC+ control is adopted.

Changing the value of C01.20-C01.22, C01.30-C01.35 will be automatically modified to factory settings.

Par. No.	Name	Range	Unit	Default
*C01.29	Automatic Motor Adaption (AMA)	0: Disabled 1: Enable complete AMA 2: Enable reduced AMA		0

The AMA function optimises dynamic motor performance by automatically optimising the advanced motor parameters (C01.30 Stator Resistance (Rs) to C01.35 Main Reactance (Xh)) at motor standstill.

Activate the AMA function by pressing HAND key after selecting [1] or [2]. See also the chapter 7.

- 0: Disabled;
- 1: Enable complete AMA, Performs AMA of the stator resistance RS, the rotor resistance Rr, the stator leakage reactance X1 and the main reactance Xh. Do not select this option if an LC filter is used between the drive and the motor;
- 2: Enable reduced AMA, Performs a reduced AMA of the stator resistance Rs in the system only.

#### C01.3\* Adv.Motor Data

Par. No.	Name	Range	Unit	Default
*C01.30	Stator Resistance (Rs)	Motor dependant	Ω	*
*C01.31	Rotor Resistance (Rr)	Motor dependant	Ω	*
*C01.33	Stator Leakage Reactance (X1)	Motor dependant	Ω	*
*C01.35	Main Reactance (Xh)	Motor dependant	Ω	*



Parameters for advanced motor data. The motor data in C01.30 Stator Resistance (Rs) to C01.35 Main Reactance (Xh) must match the relevant motor in order to run the motor optimally. The default settings are figures based on common motor parameter values from standard motors. If the motor parameters are not set correctly, a malfunction of the drive system may occur. If the motor data is not known, running an AMA (Automatic Motor Adaptation) is recommended.

Par. No.	Name	Range	Unit	Default	
*C01.39	Motor Poles	2~100	Р	4	

Enter the motor poles from the nameplate data.

#### C01.4\* Motor Cable Length

Par. No.	Name	Range	Unit	Default
*C01.42	Motor Cable Length	0~150	m	*


Enter the motor cable length connected between the motor and the drive. Set correct cable length can suppress noises resulted from the motor.

C01.5\* Load Indep.Setting

Par. No.	Name	Range	Unit	Default
C01.50	Motor Magnetisation at Zero Speed	0~300	%	100
C01.52	Min Speed Normal Magnetising	0.0~10.0	Hz	0.0


Use C01.50 Motor Magnetisation at Zero Speed along with C01.52 Min Speed Normal Magnetising to obtain a different thermal load on the motor when running at low speed (under C01.52).

The value of C01.50 is a percentage of the motor current. If the setting is too low, the torque on the motor shaft may be reduced.



Par. No.	Name	Range	Unit	Default
C01.55	V/F Characteristic-V	0.0~999.9	V	*
C01.56	V/F Characteristic-F	0.0~400.0	Hz	*

These parameters are array parameters [0-5], used to manually form a V/F characteristic matching the motor. The frequency points [F0-F5] are defined in C01.56 V/F Characteristic - F. The voltage at each point [V0-V5] is defined in C01.55 V/F Characteristic - V. These parameters are only accessible when C01.01 Motor Control Principle is set to V/F.




C01.55[0]~C01.55[5] is respective to V0~V5, C01.56[0]~C01.56[5] is respective to F0~F5, Vn is motor rated voltage, Fn is the motor rated frequency.

The set of C01.56 must met F0=0 and F1 $\leq$ F2 $\leq$ F3 $\leq$ F4 $\leq$ F5.

Simplify V/F characteristic by merging 2 or more points (voltages and frequencies), which respectively are set equal.

The slope (ratio of V/F) after point (F5, V5) must be equal to the slope between point (F5, V5) and the previous point.



The default settings of V/F Characteristic are:

200V model:

	[0]	[1]	[2]	[3]	[4]	[5]
C01.55	0.0	7.0	230.0	230.0	230.0	230.0
C01.56	0.0	0.5	50.0	50.0	50.0	50.0

æ

HOLIP

400V model:


	[0]	[1]	[2]	[3]	[4]	[5]
C01.55	0.0	12.0	400.0	400.0	400.0	400.0
C01.56	0.0	0.5	50.0	50.0	50.0	50.0

C01.6\* Load Depen.Setting

Par. No.	Name	Range	Unit	Default
C01.60	Low Speed Load Compensation	0~199	%	100
C01.61	High Speed Load Compensation	0~199	%	100

Enter the % value to compensate voltage in relation to load when the motor is running at low speed (C01.60)/high speed (C01.61) and obtain the optimum V/F characteristic.

The low speed and high speed change-over point is automatically calculated based on motor size. Usually it is 5Hz.



Par. No.	Name	Range	Unit	Default
C01.62	Slip Compensation	-400~399	%	100


When the motor is driving an electric-driven load, motor speed drops with the increase of load. When the motor is driving a power generating load, motor speed will increase with the increase of load. Appropriate slip compensation can maintain constant motor speed when the motor load is


# 


## changing.

If this parameter is set to 100%, it indicates that the compensation when the motor bears rated load is the rated motor slip.

Diagram of slip compensation is shown below:







When having more than one motor on the same shaft there is a need for some kind of load share between the drives controlling the motors. This has typically been made with two drives running in speed open loop mode and one with negative slip compensation.

Par. No.	Name	Range	Unit	Default
C01.63	Slip Compensation Time Constant	0.05~5.00	s	0.10

Enter the slip compensation reaction speed. A high value results in slow reaction, and a low value results in quick reaction. If low-frequency resonance problems arise, use a longer time setting.

Par. No.	Name	Range	Unit	Default
C01.64	Resonance Dampening	0~3000	%	50



Motor (especially >=30kW motor) speed and current resonance is likely to occur due to load vibration, and may lead to system failure even over current protection. This is particularly obvious during no-load or light-load applications.

Do not change this parameter if the motor has no resonance. Increase the value properly only when the motor has obvious resonance. The larger the value is, the better the resonance dampening result will be.

Par. No.	Name	Range	Unit	Default
C01.65	Resonance Dampening Time constant	0.005~0.050	s	0.005

Enter the resonance dampening reaction speed. A high value results in slow reaction, and a low value results in quick reaction.

#### C01.7\* Start Adjustments

Par. No.	Name	Range	Unit	Default
C01.71	Start Delay	0.0~10.0	s	0.0

This parameter enables a delay of the starting time. The drive begins with the start function selected in C01.72. Enter the time delay required before commencing acceleration. Setting start delay to 0.0 sec. disables start function when start command is given.

Par. No.	Name	Range	Unit	Default
C01.72	Start Function	0: DC hold 2: Coast		2

Select the start function during start delay. This parameter is linked to C01.71 Start Delay.

- 0: DC Hold, Energizes motor with a DC holding current (C02.00 DC Hold Current) during the start delay time;
- 2: Coast, Motor coasted during the start delay time (drive off);

Par. No.	Name	Range	Unit	Default
*C01.73	Flying Start	0: Disabled 1: Enabled		0

This function applies for the inertia load to restart due to mains drop-out; If [0] Clockwise is selected in C04.10, and no rotating motor is found, It is possible to use DC-brake command to ramp down the motor speed to 0 rpm, and then start the motor in the normal way; If [2] Both directions is selected in C04.10, and no rotating motor is found, the drive will assume the motor is stationary or in low-speed rotation, and then start the motor in the normal way. When Flying start is enabled, C01.71 Start delay and C01.72 Start function is disabled.

Warning: This function is not suitable for hoisting applications.

Par. No.	Name	Range	Unit	Default
C01.75	Min. Start Frequency	0.00~50.00	Hz	0.00

If the drive frequency reference is less than C01.75 Min. Start Frequency, the drive will not run even the start command is given (the start command will be shielded). Only the drive frequency reference is greater than or equal C01.75, then the drive starts to run. The drive still accelerates from 0 to frequency reference using ramp time.

Par. No.	Name	Range	Unit	Default
C01.76	Jump Frequency	0.0~20.0	Hz	0.0

If the drive frequency reference's absolute value (not zero, frequency reference maybe negative) is less than C01.76 Jump Frequency, the drive will run at jump frequency (maybe reversing if the reference is negative).

For example:

Set C01.76 = 3. if the frequency reference is 2, the drive will run forward at 3Hz; If the frequency reference is -2, the drive will run reversing at 3Hz; If the frequency reference is 0, the drive will stop. If the frequency reference is 20, the drive will run at 3Hz immediately, then accelerates from 3Hz to 20Hz using ramp time.

Note: it is not recommended for using C01.75 and C01.76 together.

If C01.75 and C01.76 are used together, the following talbe is its behaviour.

Freq. ref. Par. setting	3Hz	8Hz	15Hz
C01.75 = 5.00 C01.76 = 10.0	Freq. ref < C01.75 the start command is shielded, the drive stop.	is given, Freq. ref < C01.76	Freq. ref > C01.75, the start command is given, Freq. ref > C01.76 the drive runs at 10Hz immediately, then accelerates from 10Hz to 15Hz using ramp time.
C01.75 = 10.00 C01.76 = 5.0		Freq. ref < C01.75 the start command is shielded, the drive stop.	Freq. ref > C01.75, the start command is given, Freq. ref > C01.76 the drive runs at 5Hz immediately, then accelerates from 5Hz to 15Hz using ramp time.

Attention: When C01.76 Jump Frequency and C02.04 DC Brake Cut in Speed are not zero, DC brake will only be active when C02.04 > C01.76.

æ


HOUP

Par. No.	Name	Range	Unit	Default
C01.80	Function at Stop	0: Coast 1: DC hold		0

Select the drive function after stop command is given or start command is removed (standby), and output frequency is ramped down to C01.82 Min Speed for Function at Stop.

- 0: Coast, Leaves motor in free mode. the drive is off;
- 1: DC hold, the motor is energized with a DC current. See C02.00 DC Hold Current for more information;

Diagram of Function at Stop is shown below:



Par. No.	Name	Range	Unit	Default
C01.82	Min Speed for Function at Stop	0.0~400.0	Hz	0.0

Set the output frequency at which to activate C01.80 Function at Stop.

Par. No.	Name	Range	Unit	Default
C01.88	AC Brake Gain	1.0~2.0		1.4

Enter AC brake reaction speed. A high value results in slow reaction, and a low value results in quick reaction.

NOTE: Generally do not need adjustments.

### C01.9\* Motor Temperature

Par. No.	Name	Range	Unit	Default
C01.90	Motor Thermal Protection	0: No protection 1: Thermistor warning 2: Thermistor trip 3: ETR warning 4: ETR trip 5: ETR warning (Self-cooling mode) 6: ETR trip (Self-cooling mode)		0

The drive determines the motor temperature for motor protection in two different ways:

- Via a thermistor sensor connected to the analog input terminal VI (C01.93 Thermistor Source).
- Via calculation (ETR = Electronic Terminal Relay) of the thermal load,

based on the actual load and time. The calculated thermal load is compared with the rated motor current IM,N and the rated motor frequency fM,N. The calculations estimate the need for a lower load at lower speed due to less cooling from the fan incorporated in the motor.

- 0: No protection;
- 1: Thermistor warning, a thermistor connected to analog input VI gives a warning if upper limit of motor temperature range is exceeded, (see 01.93, Thermistor Resource);
- Thermistor trip, a thermistor connected to analog input VI gives an alarm and makes the drive trip if upper limit of motor temperature range is exceeded, (see 01.93, Thermistor Resource);
- 3: ETR warning, if calculated upper limit of motor temperature range is exceeded, a warning ccurs
- 4: ETR trip, if calculated upper limit of motor temperature range is exceeded, an alarm occurs and the drive trips.
- 5: ETR warning (Self-cooling mode)
- 6: ETR trip (Self-cooling mode)

Option [5]/[6] is similar with the option [3]/[4], it uses ETR function to protect the motor, if the motor exceeds the maximum temperature range, the drive will report a "A.10" warning, or "E.10" alarm, this two options are suitable for motor with no forced cooling (Self-cooling). When the drive is going into the protected status, it requires more stop time to wait motor temperature down.



Par. No.	Name	Range	Unit	Default
*C01.93	Thermistor Resource	0: None 1: Terminal VI		0

Select the input to which the thermistor (PTC sensor) should be connected.

0: None

1: Terminal VI, Connect thermistor to analog input terminal VI;

Attention: Analog input can't be selected for other purpose when selected as thermistor resource.

Thermistor specifications:

Input Signal Type	Voltage Supply	Termistor Threshold
Analog	10V	<0.8kΩ, >2.9kΩ

## 6.3 Group 02: Brakes

#### C02.0\* DC-Brake

Par. No.	Name	Range	Unit	Default
C02.00	DC Hold Current	0~150	%	50

Enter a value for holding current as a percentage of the rated motor current set in C01.24 Motor Current. 100% DC holding current corresponds to IM,N. This parameter either holds the motor (holding torque) or pre-heats the motor. This parameter is active if DC Hold has been selected in either C01.72 Start Function or C01.80 Function at Stop.

Attention: Avoid 100% current too long as it may overheat the motor.


Par. No.	Name	Range	Unit	Default
C02.01	DC Brake Current	0~150	%	50

Enter a value for current as a percentage of the rated motor current  $I_{M^{2}N}$ , see C01.24 Motor Current. 100% DC braking current corresponds to  $I_{M^{2}N}$ .

DC brake current is applied on a stop command, when the speed is lower than the limit set in C02.04 DC Brake Cut In Speed; or via the serial communication port. The braking current is active during the time period set in C02.02 DC Braking Time.

Par. No.	Name	Range	Unit	Default
C02.02	DC Braking Time	0.0~60.0	s	10.0

This parameter defines DC brake current (C02.01) time during which DC-brake current is applied to the motor.



# 


Par. No.	Name	Range	Unit	Default
C02.04	DC Brake Cut in Speed	0.0~400.0	%	0.0

Set the DC brake cut-in speed for activation of the DC braking current set in C02.01 DC Brake Current, upon a stop command.

Par. No.	Name	Range	Unit	Default
C02.08	Motor Demagnetization	0~100	%	100

when the drive output frequency less than DC brake cut in frequencies, motor demagnetization process needs to be done before starting a DC brake for preventing overcurrent at a high speed or great inertia starting DC brake. The smaller this parameter is, the faster motor demagnetization will be done, the time shorter entering the DC brake. If the Load inertia is small and DC brake cut in frequency is lower, this parameter can be reduced to 0.

Diagram of DC Brake process is shown below:



#### C02.1\* Brake Energy Funct.

Par. No.	Name	Range	Unit	Default
C02.10	Brake Function	0: Off 1: Resistor brake 2: AC brake		0

### 0: Off;

1: Resistor brake, use the resistor brake to consume surplus energy resulting from motor

braking, and prevent the drive to trip due to over-voltage in the intermediate circuit;

2: AC brake, dissipate surplus energy in the motor core, and prevent the energy back into drive causing trips. It is important to keep in mind that frequent use of this function will cause an increase in motor temperature;

Attention: Resistor brake is only functional when the drive build-in braking unit or external braking unit must be installed.

Par. No.	Name	Range	Unit	Default
C02.11	Brake Resistor	5~65535	Ω	*

Set brake resistor value. This parameter is only active in drives with an integral brake unit.

Par. No.	Name	Range	Unit	Default
*C02.14	*C02.14 Resistor Brake Threshold	Cuid tumo donon dont	V	*
C02.14	Voltage	Grid type dependant	v	

This parameter takes effect only to the drives with built-in brake unit.

If C02.10 is set to 1, When the DC link voltage exceeds the value of C02.14, resistor brake will perform, the energy will be rapidly consumed through brake resistor. This value is used to regulate the brake effect of brake unit.

The following table is the Resistor Brake Threshold Voltage's range and default value which depends on C00.06 Grid Type:

Grid Type	Range	Default
200~240V	360~395V	390V
380~440V	680~780V	700V
440~480V	750~780V	770V

Par. No.	Name	Range	Unit	Default
C02.15	Over-voltage Control Threshold Voltage	Grid type dependant	V	*

When the DC link voltage exceeds the value of C02.15, over-voltage control is active.

The following table is the Over-voltage Control Threshold Voltage's range and default value which depends on C00.06 Grid Type:

Grid Type	Range	Default
200~240V	360~395V	395V
380~440V	680~780V	710V
440~480V	750~780V	780V



Par. No.	Name	Range	Unit	Default
C02.16	AC Brake, Max Current	0~150	%	100

Enter the maximum permissible current when using AC brake to avoid overheating of motor windings. 100% equals motor current set in C01.24.

Par. No.	Name	Range	Unit	Default
		0: Disabled		
C02.17	Over-voltage Control	2: Mode 1		0
		3: Mode 2		

Over-voltage control (OVC) reduces the risk of the drive tripping due to an over voltage on the DC link caused by generative power from the load.

- 0: Disabled;
- 2: Mode 1, used to consume surplus energy by increasing the output frequency;
- 3: Mode 2, used for very short deceleration;

Attention: If C02.10 = 1 (Resistor brake), C02.17 = 2 or 3, resistor brake function starts first, if the DC link voltage still can not be controlled, OVC starts.

Par. No.	Name	Range	Unit	Default
C02.18	Over-voltage Control Integral Time	0.01~0.10	s	0.05
C02.19	Over-voltage Control Proportional Gain	0~200	%	100

Over-voltage control (OVC) reduces the risk of the drive tripping due to an over voltage on the DC link caused by generative power from the load.

Note: These parameters are only active when selecting [2] Mode 1 or [3] Mode 2 in C02.17 Overvoltage Control.

#### C02.2\* Mechanical Brake

Parameters for controlling operation of an electro-magnetic (mechanical) brake, typically required in hoisting applications.

To control a mechanical brake, a relay output (FA-FB-FC or KA-KB) or a programmed digital output (DO1 or DO2) is required. Normally this output must be closed during periods when the drive is unable to 'hold' the motor, e.g. due to an excessive load. Select [32] Mechanical Brake Control for applications with an electro-magnetic brake in C05.40 Relay output, C05.30 DO1 Output, or C05.31 DO2 Output. When selecting [32] Mechanical brake control, the mechanical brake is closed from start up until the output current is above the level selected in C02.20 Release Brake Current. During stop, the mechanical brake activates when the speed falls below the level specified in C02.22 Activate Brake Speed. If the drive enters an alarm condition or an over-current



or over-voltage situation, the mechanical brake immediately cuts in. This is also the case during safe stop.


Par.	No.	Name	Range	Unit	Default
C02	.20	Release Brake Current	0.00~1200.00	А	0.00

Set the motor current for release of the mechanical brake, when a start condition is present.

Attention: When Mechanical brake control output is selected but no mechanical brake is connected, the function will not work. If start delay time has passed, and motor current is below Release brake current, the drive trips.

Par. No.	Name	Range	Unit	Default
C02.22	Activate Brake Speed	0.0~400.0	Hz	0.0

Set the motor frequency for activation of the mechanical brake, when a stop condition is present. Diagram of Mechanical Brake Control process is shown below:



# 

# 6.4 Group 03: Reference/Ramps

## C03.0\* Reference Limits

Reference is the drive control target. Reference value is a dimensionless number, reference unit depends on configuration mode (C01.00). When select [0] speed open loop in configuration mode, motor frequency is the drive control target, the reference unit is Hz; When select [4] torque open loop in configuration mode, motor torque is the drive control target, the reference unit is Nm; When select [3] process closed loop in configuration mode, process variable (such as temperature, pressure) is the drive control target, the reference unit may be °C or kg, etc.

Par. No.	Name	Range	Unit	Default
C03.00	Reference Range	0: 0~C03.03 1: -C03.03~C03.03		0

Select the range of the reference.

0: 0~Max, Reference set point ranges can have positive values only;

1: -Max~+Max, Ranges can have both positive and negative values;

Р	Par. No.	Name	Range	Unit	Default
	C03.03	Maximum Reference	0.0~6553.5		50.0

Enter value for Maximum Reference. The Maximum Reference is the highest value obtainable by summing all references.

Par. No.	Name	Range	Unit	Default
C03.07	Main Reference Calculation	<ul> <li>0: Preset reference + Reference source1, 2, 3</li> <li>1: Preset reference priority</li> <li>2: Reference source 2,3 operation</li> <li>3: Switchover between Reference source 1 and Reference source 2</li> <li>4: Switchover between Reference source 1 and Reference source 2,3</li> <li>operation</li> </ul>		0

Select main reference calculation method.

0: Preset reference + reference source1, 2, 3

Main reference = Preset reference + reference source1, 2, 3



1: Preset reference priority

Main reference =-

Preset reference [0] + Reference source 1, 2, 3, use preset ref.[0]

Par. No.	Name	Range	Unit	Default
		0: Reference source 2 + Reference		
		source 3		
		1: Reference source 2 - Reference		
C03.08	Reference source 2,3	source 3		0
C03.08	operation mode	2: Max(Reference source 2, Reference		0
		source 3)		
		3: Min(Reference source 2, Reference		
		source 3)		

Preset reference[1-N], use preset ref.[1]-[N]

This parameter is used to set the reference value calculation source 2,3, the results can be used for parameter C03.07 options [2] and [4].

# The reference value calculation logic as shown below: Acthal Ref. 0~C03.03 -C03.03~C03.03 Ref. Adjustment Speed up Speed down Ā Total Ref Catch up Main Reft Main Reft (C03.14 + C03.18/C03.03) C03.07 ---- Main C03.07 Reference Main Reference 2 C05.10~C05.15 = 24 Relative Ref Ĵ. DI 1~D14 C03.18 Relative Ref Source C03.14 Preset Relative Ref C05.10~C05.15 =15~18 DI1~DI4 C03.08 Ref source 2,3 operation mode Max Min C03.10[0-15] Preset Ref. 0-15 C03.17 Ref Source 3 C03.16 Ref Source 2 C03.15 Ref Source 1



#### C03.1\* References

Par. No.	Name	Range	Unit	Default
C03.10	Preset Reference	-100.00~100.00	%	0.00

This parameter is an array-16 to be used for presetting different references. 16 preset references are selectable via digital terminals or local bus. See C05.1\*. 0% equals 0, 100% equals value set in C03.03.

Par. No.	Name	Range	Unit	Default
C03.11	Jog Speed	0.0~400.0	Hz	0.0

The jog speed is a fixed output speed at which the drive is running when the jog function is activated.

The drive with the highest priority will operate at jog speed when a variety of run command activates. Removing the jog signal makes the drive run according to the selected configuration, this parameter is set limited by C04.14.

Par. No.	Name	Range	Unit	Default
C03.12	Catch up/Slow down Value	0.00~100.00	%	0.00

This parameter enables the entry of a percentage value (relative) which will to be either added to or deducted from the total reference.

The Catch up/Slow down function is activated by a digital input terminal (See C05.1\*, choose [28]/ [29]). If this function is active, the catch up/slow down value will be added to the total reference constituting new setting at which the drive is going to run, calculated as follows:

Reference = total reference ± total reference × (Catch up/Slowdown value)

If this function is inactive, the reference returns to its original value.

Par. No.	Name	Range	Unit	Default
C03.13	Speed Up/Down Value	0.01~50.00	Hz	0.10

Enter the Speed Up/Down value.

Par. No.	Name	Range	Unit	Default
C03.14	Preset Relative Reference	-100.00~100.00	%	0.00

Define an adjustable Preset Relative Reference which is to be added to the total reference as a percentage value of the actual reference. Its calculation refers to Reference Calculation Diagram.

# 

Par. No.	Name	Range	Unit	Default
C02.15		0: No function		1
C03.15	C03.15 Reference Source 1	1: Terminal VI		1
		2: Terminal AI		
C03.16	Reference Source 2	8: Pulse input DI3		2
000.15		11: Local bus		
C03.17	Reference Source 3	21: LCP potentiometer		11

Select the reference input to be used for the first, second and third reference source.

- 0: No function;
- 1: Terminal VI, use analog input VI as reference source, see C06.1\*;
- 2: Terminal AI, use analog input AI as reference source, see C06.2\*;
- 8: Pulse input DI3, use pulse input DI3 as reference source, see C05.5\*;
- 10: Preset reference [0], use preset reference [0], see C03.10;
- 11: Local bus, use local bus reference as reference source, see C08.\*\*;
- 21: LCP potentiometer, use LCP potentiometer as reference source, see C06.8\*;

Par. No.	Name	Range	Unit	Default
		0: No function		
C02.10		1: Terminal VI		
	Delative Defense of Course	2: Terminal AI		0
C03.18		8: Pulse input DI3		0
		11: Local bus		
		21: LCP potentiometer		

Relative Reference is similar to Preset Relative Reference (see C03.14). It adds a variable value to total reference. Its calculation refers to Reference Calculation Diagram.

- 0: No function;
- 1: Terminal VI, use analog input VI as relative reference source, see C06.1\*;
- 2: Terminal AI, use analog input AI as relative reference source, see C06.2\*;
- 8: Pulse input DI3, use pulse input DI3 as relative reference source, see C05.5\*;
- 10: Preset reference [0], use preset reference [0], see C03.10;
- 11: Local bus, use local bus reference as relative reference source, see C08.\*\*;
- 21: LCP potentiometer, use LCP potentiometer as relative reference source, see C06.8\*;

Par. No.	Name	Range	Unit	Default
		0: No function		
C03.19	Speed Up/Down Value Store	1: Stop save		0
		2: Power down save		

This parameter is used for setting whether to save the data changed in the Speed Up/Down

Par. No.	Name	Range	Unit	Default
C03.39	Ramp Time Scale	0: 0.1s 1: 0.01s		1

function if the drive stops or after it power down.

HLP-SD100 series offers two kinds of ramp time scale for different applications.

After modifying the parameter, ramp time scale will be changed, the ramp time will be changed too.


#### C03.4\* Ramp1

There are 4 ramps built in the drive. For each of four ramps (C03.4\*, C03.5\*, C03.6\* and C03.7\*), configure the ramp parameters: ramp type, ramp up time and ramp down time.

Par. No.	Name	Range	Unit	Default
C03.40	Ramp 1 Type	0: Linear		0
		2: S ramp		-
C03.41	Ramp 1 Ramp Up Time	0.05~655.35	s	*
C03.42	Ramp 1 Ramp Down Time	0.05~655.35	s	*
C03.50	Ramp 2 Type	0: Linear		0
03.30	Kallip 2 Type	2: S ramp		0
C03.51	Ramp 2 Ramp Up Time	0.05~655.35	s	*
C03.52	Ramp 2 Ramp Down Time	0.05~655.35	s	*
C03.60	Ramp 3 Type	0: Linear		0
03.00	Kallip 5 Type	2: S ramp		0
C03.61	Ramp 3 Ramp Up Time	0.05~655.35	s	*
C03.62	Ramp 3 Ramp Down Time	0.05~655.35	s	*
C03.70	Ramp 4 Type	0: Linear		0
003.70	Kamp 4 Type	2: S ramp		0
C03.71	Ramp 4 Ramp Up Time	0.05~655.35	s	*
C03.72	Ramp 4 Ramp Down Time	0.05~655.35	s	*

Ramp Type:

0: Linear, motor ramps up/down with constant acceleration/deceleration; 2: S ramp, motor ramps up/down with non-linear acceleration/deceleration; Ramp Up Time is the time motor accelerates from 0Hz to rated motor frequency (C01.25). Ramp Down Time is the time motor decelerates from rated motor frequency (C01.25) to 0Hz. Diagram of Ramp Type, Ramp Up Time and Ramp Down Time are shown below:



### C03.8\* Other Ramps

Ē

Par. No.	Name	Range	Unit	Default
C03.80	Jog Ramp Time	0.05~655.35	s	*

Enter the jog ramp time, i.e. the acceleration/deceleration time between 0Hz and the rated motor frequency (C01.25).

Jog ramp time starts upon activation of a jog signal via a selected digital input or serial communication port.

## 6.5 Group 04: Limits/Warnings

#### C04.1\* Motor Limits

Par. No.	Name	Range	Unit	Default
*C04.10	Motor Speed Direction	0: Clockwise 1: Counter clockwise 2: Both directions		2

Select the motor speed direction(s) required. Use this parameter to prevent unwanted reversing.

- 0: Clockwise, the motor shaft rotates in clockwise direction, this setting prevents the motor from running in counter clockwise direction;
- 1: Counter clockwise, motor shaft rotates in counter clockwise direction, this setting prevents the motor from running in clockwise direction;
- 2: Both directions, with this setting, the motor can run in both directions;

Par. No.	Name	Range	Unit	Default
*C04.12	Motor Speed Low Limit	0.0~C04.14	Hz	0.0

Set the minimum limit for Motor Speed, the motor speed low limit can be set to correspond to the minimum output frequency of the motor shaft. The Motor Speed Low

Limit must not exceed the setting in C04.14 Motor Speed High Limit



[	Par. No.	Name	Range	Unit	Default
	*C04.14	Motor Speed High Limit	C04.12~C04.19	Hz	65.0

Set the maximum limit for Motor Speed, the motor speed high limit can be set to correspond to the maximum manufacture's rated motor speed. The motor speed high limit must exceed the Motor Speed Low Limit in C04.12.

Par. No.	Name	Range	Unit	Default
C04.16	Torque Limit Motor Mode	0~1000	%	160
C04.17	Torque Limit Generator Mode	0~1000	%	160

These parameters limit the torque on the shaft to protect the mechanical installation. 100% equals motor rated torque set in C01.26. If the motor torque is bigger than C04.16/C04.17, the drive will report "A.12".

Par. No.	Name	Range	Unit	Default
C04.18	Current Limit	0~300	%	*

This parameter is used to set drive output current limit, 100% equals motor current set in C01.24. If the output current exceeds the C04.18 motor current limit, the drive will report A.59 warning and current limit controllers (see C14.3\*) start.

Par. No.	Name	Range	Unit	Default
*C04.19	Max. Output Frequency	0.0~400.0	Hz	65

Provides a final limit on the output frequency for improved safety in applications where you want to avoid accidental over-speeding. This limit is final in all configurations (independent of the setting in C01.00 Configuration Mode).

Par. No.	Name	Range	Unit	Default
		0: No function		
		1: Terminal VI		
*C04.21	Frequency Upper Limit	2: Terminal AI		1
	Source	8: Pulse input DI3		1
		11: Local bus		
		21: LCP potentiometer		

In some occasions, it needs to set a dynamic frequency upper limit. For example, to avoid runaway in torque control mode in winding application, you can set the frequency upper limit by means of analog input. When the drive reaches the upper limit, it will continue to run at this speed.

- 0: No function, use C04.19 as frequency upper limit;
- 1: Terminal VI, use analog input VI as frequency upper limit, see C06.1\*;
- 2: Terminal AI, use analog input AI as frequency upper limit, see C06.2\*;

8: Pulse input DI3, use pulse input DI3 as frequency upper limit, see C05.5\*;

11: Local bus, use local bus reference as frequency upper limit, see C08.\*\*;

21: LCP potentiometer, use LCP potentiometer as frequency upper limit, see C06.8\*;

Par. No.	Name	Range	Unit	Default
C04.28	Low Voltage Overload Limit	5~100	%	100

When the grid voltage is low, the drive will limit output frequency for overload protection.

When C16.35 Drive Thermal factor is greater than C04.28 Low Voltage Overload Limit, the drive goes into the low voltage output frequency limit protection and reports "A.101"; When C16.35 is less than 1%, the drive quits from the protection and runs at the original frequency, the warning disappears.

When C04.28 is set to 100, the low voltage frequency limit protection is disabled; When setting to other values, it is turned on; The smaller the value is, the more likely the drive goes into the low voltage frequency limit protection.

Par. No.	Name	Range	Unit	Default
C04.29	Low Voltage Udc Limit	50~1000	V	220/380

When entering the low-voltage protection limit frequency, the inverter maximum output frequency:

Par. No.	Name	Range	Unit	Default
C04.42	Counter Store at Power down	0: Disable		0
		1: Counter A save		
		2: Counter B save		
		3: Both counter A and B save		

This parameter is used to control whether counter A/B's value is saved at power down.


## C04.5\* Adjustable Warnings

This parameter group is used to adjust warning limits for current, speed, reference and feedback. Warnings can be programmed as an output or sent via serial bus.

Par. No.	Name	Range	Unit	Default
C04.50	Warning Current Low	0.00~C16.37	А	0.00
C04.51	Warning Current High	0.00~ C16.37	А	*

When the motor current falls below C04.50 or exceeds C04.51, a signal can be produced on relays or terminal DO1. See [12] Out of current range, [13] Below current low and [14] Above current high in C05.30/31/40.

Diagram of Warning Current Low and Warning Current High are shown below:




æ

HOLIP

[	Par. No.	Name	Range	Unit	Default
	C04.52	Warning Frequency Low	0.0~400.0	Hz	0.0
	C04.53	Warning Frequency High	0.1~400.0	Hz	65.0

When the motor frequency falls below C04.52 or exceeds C04.53, a signal can be produced on relays or terminal DO1. See [15] Out of frequency range, [16] Below frequency low and [17] Above frequency high in C05.30/40.

Diagram of Warning Frequency Low and Warning Frequency High are shown below:





Par. No.	Name	Range	Unit	Default
C04.54	Warning Reference Low	-200.00~200.00	%	0.00
C04.55	Warning Reference High	-200.00~200.00	%	100.00

When the actual reference falls below C04.54 or exceeds C04.55, a signal can be produced on relays or terminal DO1. 100% equals value set in C03.03.

See [40] Out of reference range, [41] Below reference low and [42] Above reference high in C05.30/40.

Par. No.	Name	Range	Unit	Default
C04.56	Warning Feedback Low	-200.00~200.00	%	0.00
C04.57	Warning Feedback High	-200.00~200.00	%	100.00

When the feedback falls below C04.56 or exceeds C04.57, a signal can be produced on relays or terminal DO1. 100% equals value set in C03.03.

See [18] Out of feedback range, [19] Below feedback low and [20] Above feedback high in C05.30/40.

Par. No.	Name	Range	Unit	Default
*C04.58	Missing Motor Phase	0: Disable		1
04.38	Function	1: Enable		1

Displays an alarm in the event of a missing motor phase (alarm 30, 31 or 32). Select disabled for no missing motor phase alarm. It is strongly recommended to make an active setting to avoid motor damage.

Par. No.	Name	Range	Unit	Default
*C04.59	Current/Torque Limit	0: Disable		1
04.39	Warning Selection	1: Enable		1

This parameter is used to control whether the drive reports A.12/A.59 warning or not when the motor torque exceeds C04.16/C04.17, the output current exceeds C04.18.

Note: Even if you select disable warning, C14.3\* current limit controller still works.

#### C04.6\* Speed Bypass

Par. No	Name	Range	Unit	Default
C04.61	Bypass Speed From	0.0~400.0	Hz	0.0
C04.63	Bypass Speed to	0.0~400.0	Hz	0.0


Some systems call for avoiding certain output frequencies, due to resonance problems in the

system. A maximum of three frequency ranges can be avoided. The drive will pass quickly when it approaching to the Bypass Speed area.

These parameters are dyadic array, [0] is used to set the bypass speed range 1, [1] is used to set the bypass speed range 2, and [2] is used to set the bypass speed range 3.

Diagram of bypass speed ranges are shown below:

Output Frequency




Time

Par. No.	Name	Range	Unit	Default
C04.70	Minimum Torque at Zero Speed	0~100	%	5
C04.71	Minimum Torque Cut-off Frequency	0.1~50.0	Hz	3.0

In torque control mode, the device may not start if the torque reference is too small due to the presence of static friction. So it needs a minimum torque reference at low speed.

The following figure is a graph showing the minimum torque at zero speed and minimum torque cut-off frequency. When the output frequency is less than the minimum torque cutoff frequency, if the torque reference is greater than the corresponding value in curve, then use torque reference; If the torque reference is less than the corresponding value in curve, then use curve corresponding value;





Par. No.	Name	Range	Unit	Default
C04.72	Torque open loop stop	0: Torque mode		0
	mode	1: Speed mode		0

This parameter is used to set the stop mode in torque open loop configuration mode:

0: Torque mode

When the stop signal is activated, the drive torque is reduced to zero according to the ramp down time.

1: Speed mode

When the stop signal is activated, the drive speed is reduced to zero according to the ramp down time.

Par. No.	Name	Range	Unit	Default
C04.80	Unbalance Detection Frequency	5.0-400.0		15.0
C04.81	Grear Ratio	1.0~100.0	%	9.0
C04.82	Unbalance Detection Threshold Value	10~300	s	300
C04.83	Unbalance WaitingTime	0~100	s	5
C04.84	Unbalance DetectionTime	0~100	Hz	10

### 6.6 Group 05: Digital In/Out

#### C05.1\* Digital Input

Par. No.	Name	Range	Unit	Default
C05.04	DI Filter Time	2~16	ms	4

It is used to set the software filter time of DI terminal status. If DI terminals are liable to interference and may cause malfunction, increase the value of this parameter to enhance the antiinterference capability. However, increase of DI filter time will reduce the response of DI terminals.

Par. No.	Name	Range	Unit	Default
C05.05	DI terminal logic selection	0~255		0

This parameter is used to control the digital input terminal positive or negative logic. Each digital input terminal corresponds to a bit: "1" indicates that the digital input terminal is negative logic; "0" indicates that the digital input terminal is positive logic.

For example: If you want to set FOR and DI2 terminal as negative logic, set the C05.05 to 9.

 $C05.05 = 1 \times 2^0 + 1 \times 2^3 = 9$ 



Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Reversed	Reversed	Reversed	DI3	DI2	DI1	REV	FOR
0	0	0	0	1	0	0	1

Positive/Negative logic Note:

For NPN mode:

When the digital input selects positive logic, connecting the digital input terminal and COM terminal is ON state (active), disconnecting is OFF state (inactive);

When the digital input selects negative logic, connecting the digital input terminal and COM terminal is OFF state (inactive), disconnecting is ON state (active);

For PNPmode:

When the digital input selects positive logic, connecting the digital input terminal and VDD terminal is ON state (active), disconnecting is OFF state (inactive);

When the digital input selects negative logic, connecting the digital input terminal and VDD terminal is OFF state (inactive), disconnecting is ON state (active);

Note: There are some digital input function is inverse. If the terminal logic is set as negative and the function of the terminal is inverse, then the function of the terminal is

positive. For example: When C05.10 Terminal FOR is set to [6] Stop inverse, C05.05 is set to 1 (The logic of terminal FOR is negative), then connect the terminal FOR and COM (NPN mode), function "stop" is active, disconnect the terminal FOR and COM, function "stop" is inactive.

Par. No.	Name	Range	Unit	Default
C05.06	DO/Relay terminal logic	0~255		0
	selection	0~235		0

This parameter is used to control the DO/Relay terminal positive or negative logic. Each DO/Relay terminal corresponds to a bit: "1" indicates that the terminal is negative logic; "0" indicates that the terminal is positive logic.

For example: If you want to set DO1 and Relay1 terminal as negative logic, set the C05.06 to 5.

 $C05.06 = 1 \times 2^0 + 1 \times 2^2 = 5$ 

Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Reversed	Reversed	Reversed	Reversed	Relay2	Relay1	Reversed	DO1
0	0	0	0	0	1	0	1

Positive logic: When the selected function of DO/Relay terminals is activated, the DO/Relay terminal outputs ON signal, else outputs OFF signal.

Negative logic: When the selected function of DO/Relay terminals is activated, the DO/Relay terminal outputs OFF signal, else outputs ON signal.

Par. No.	Name	Range	Unit	Default
		0: Off		
		2: Stop and warning		
C05.09	Function at External Alarm	3: Jogging and warning		0
		4: Max. speed and warning		
		5: Stop and trip		


The function activates when the digital input terminal function [43] external alarm input is active.

- 0: Off, resumes control via serial bus using the most recent control word;
- 2: Stop and warning, drive stops and reports "A.102";
- 3: Jogging and warning, overruled to jog speed and reports "A.102";
- 4: Max. speed, overruled to max.speed and reports "A.102";
- 5: Stop and trip, overruled to stop with subsequent trip ("E.102").

Par. No.	Name	Range	Unit	Default
C05.10	Terminal FOR			8
C05.11	Terminal REV			11
C05.12	Terminal DI1	0~173		15
C05.13	Terminal DI2			16
C05.15	Terminal DI3			17

The digital inputs are used for selecting various functions in the drive. All digital inputs can be set to the following functions:

- 0: No operation, no reaction to signals transmitted to the terminal;
- 1: Reset, reset the drive after a Trip/Alarm;
- 2: Coast inverse, no output, leaving the motor coasting to stop. Terminal logic '0' => coasting stop;
- 3: Coast and reset inverse, the drive resets leaving the motor coasting to stop. Terminal logic '0'
   => coasting stop;
- 6: Stop inverse, the drive is stopped according to selected ramp time. Terminal logic '0' => stop;
- 8: Start, select start for a start/stop command. Terminal logic '1' = start, logic '0' = stop;
- 9: Latched start, the motor starts, if a pulse is applied for min. 4ms. The motor stops when [6] Stop inverse/[46] Stop is activated;



- 11: Start reversing, used for start/stop and for reversing at the same time;
- 12: Enable start forward only, disengages the counterclockwise movement and allows for the clockwise direction;
- 13: Enable start reverse only, disengages the clockwise movement and allows for the counterclockwise direction;
- 14: Jog, used for activating jog speed, see C03.11;
- 15: Preset ref. bit0, Preset ref.bit0, bit1, bit2 enables a choice between one of the sixteen preset references (see C03.10) according to the table below;
- 16: Preset ref. bit1, same as [15];
- 17: Preset ref. bit2, same as [15];

Terminal of Preset ref. bit2	Terminal of Preset ref. bit1	Preset ref. bit0	Parameter
OFF	OFF	OFF	C03.10[0]
OFF	OFF	ON	C03.10[1]
OFF	ON	OFF	C03.10[2]
OFF	ON	ON	C03.10[3]
ON	OFF	OFF	C03.10[4]
ON	OFF	ON	C03.10[5]
ON	ON	OFF	C03.10[6]
ON	ON	ON	C03.10[7]

- 19: Freeze reference, freezes the actual reference, if freezing reference is active, stop the drive via a terminal programmed for [2] Coast inverse, [3] Coast and reset inverse, [42] Coast and [46] Stop;
- 20: Freeze output, freezes the output frequency, If freezing output is active, stop the drive via a terminal programmed for [2] Coast inverse, [3] Coast and reset inverse, [42] Coast and [46] Stop;
- 21: Speed up, when speed up is activated for less than 400 ms. the resulting reference will be increased by C03.13 Speed Up/Down Value. If Speed up is activated for more than 400 ms, the resulting reference will ramp according to ramp 4;
- 22: Speed down, similar to [21] Speed up;
- 23: Set-up select, select one of the two set-ups, see C00.10;
- 24: Main reference calculation switchover;

- This function is used C03.07 Main Reference Calculation option [3] Switchover between Reference source 1 and Reference source 2, [4] Switchover between Reference source 1 and Reference source 2,3 operation. When the terminal is in the ON state, the main reference value is Reference Source 1; when the terminal is in the OFF state, the main reference is Reference source 2 or Reference source 2,3 operation results;
- 28: Catch up, select catch up to increase the resulting reference value by the percentage set in C03.12 Catch up/slow Down Value;
- 29: Slow down, similar to [28] Catch up;
- 32: Pulse input, use pulse input as either reference or feedback. Scaling is done in par. group C05.5\*, the function is available for C05.15 Terminal DI3 only;
- 34: Ramp bit0, ramp bit0, bit1 are used for select one of the four ramps;
- 35: Ramp bit1, same as [34];

Terminal of Ramp bit1	Terminal of Ramp bit0	Parameters
OFF	OFF	Ramp1 (C03.41, C03.42)
OFF	ON	Ramp2 (C03.51, C03.52)
ON	OFF	Ramp3 (C03.61, C03.62)
ON	ON	Ramp4 (C03.71, C03.72)

- 37: Latched Reversing, motor starts counter-clockwise if a pulse is applied for min. 4ms. The motor stops when [6] Stop inverse/[46] Stop is activated;
- 42: Coast, similar to [2] coast reverse, but logic contrary: Terminal logic '1' => coasting stop;
- 43: External alarm input, When terminal is in ON state, the drive will run as C05.09 specified.
- 46: Stop, similar to [6] stop reverse, but logic contrary: Terminal logic '1' => stop;
- 50: Speed control/torque control switchover;
- When C01.00 Configuration Mode is set to [4] Torque open loop, torque open loop and speed open loop can be switched via digital input terminal. The terminal is in the OFF state, it is torque open loop; The terminal is in the ON state, it is speed open loop;
- 60: Counter A, to count the pulse number inputted into the terminal;
- 62: Reset counter A, to clear counter A to "0";
- 63: Counter B, to count the pulse number inputted into the terminal;
- 65: Reset counter B, to clear counter B to "0";
- 110: Process Control invalid;
- 160: Diameters Select bit0:
- 161: Diameters Select bit1:

Terminal of Deameters	Terminal of Deameters	Related Parameter
select bi1	select bi1	Related Parameter
OFF	OFF	C29.16[0]
OFF	ON	C29.16[1]
ON	OFF	C29.16[2]
ON	ON	C29.16[3]

162: Diameter calculation suspend:

163: Material thickness bit0:

164: Material thickness bit1:

Terminal of Material	Terminal of Material	Related Parameter
thickness bit0	thickness bit1	
OFF	OFF	C29.27[0]
OFF	ON	C29.27[1]
ON	OFF	C29.27[2]
ON	ON	C29.27[3]

165: Broken line signal input

166: Winding start:

167: Tension lifting

168: Broken line reset

169: Roll diameter reset:

When you change the volume, you need to reset the roll diameter to the initial roll diameter

170: Pre-drive valid

When the terminal is valid, the converter works in the pre drive mode

171: Winding and unwinding switch

172: PID suspend

The PID is temporarily disabled and the converter is maintained at the current output frequency 173: Reverse Running

#### C05.3\* Digital Output

Par. No.	Name	Range	Unit	Default
C05.30	Terminal DO1	0~91		0

Set the Terminal DO1/DO2 output function.

Terminal DO1 is a programmable multiplex terminal, it can be a high-speed pulse output terminal,

also available as a collector's digital output terminal. if C05.60 = 0, DO1 is as a collector's digital output terminal; If C05.60 is not set to 0, DO1 is as a high-speed pulse output terminal.

If terminal DO1 as collector's digital output terminals, their output function options are the same as C05.40 relay output.

#### C05.4\* Relay

Par. No.	Name	Range	Unit	Default
C05.40	Relay Function	0~91		9, 5

This parameter is an array[2] parameter. C05.40[0] corresponds to the relay 1 (FA-FB-FC), C05.40[2] the corresponds to relay 2 (KA-KB).

- 0: No operation;
- 1: Drive ready, the drive control card have received supply voltage;
- 3: Remote control ready, the drive is ready for operation and is in AUTO mode;
- 4: Drive running/No warning, the drive is running and no warning is present;
- 5: Drive running, the drive is running;
- 7: Run in range/No warning, the drive is running within the programmed speed ranges set in C04.12 Motor Speed Low Limit and C04.14 Motor Speed High Limit. No warnings are present;
- 8: Run on reference/No warning, the drive runs at reference speed without warnings;
- 9: Alarm, the drive alarms;
- 10: Alarm or warning, an alarm or warning occurs;
- 12: Out of current range, output current is outside the range set in C04.50 and C04.51;
- 13: Below current low, output current is lower than set in C04.50;
- 14: Above current high, output current is higher than set in C04.51;
- 15: Out of frequency range, output frequency is outside the range set in C04.52 and C04.53;
- 16: Below frequency low, output frequency is lower than set in C04.52;
- 17: Above frequency high, output frequency is higher than set in C04.53;
- 18: Out of feedback range, feedback is outside the range set in C04.56 and C04.57;
- 19: Below feedback low, feedback is lower than set in C04.56;
- 20: Above feedback high, feedback is higher than set in C04.57;
- 21: Thermal warning, a thermal warning occurs;
- 22: Ready, no thermal warning, the drive is ready for operation and no over-temperature warning is present;
- 23: Remote ready, no thermal warning, the drive is ready for operation in AUTO mode, and no over-temperature warning is present;
- 24: Ready, voltage OK, the drive is ready for operation, no over-voltage or under-voltage is present;
- 25: Reverse, the drive runs in counter clockwise;



- 26: Bus OK, local bus communication is normal;
- 32: Mech. brake control, enter mechanical brake control signal, see C02.2\*;
- 36: Control word bit 11, bit 11 in control word is active;
- 37: Control word bit 12, bit 12 in control word is active;
- 40: Out of reference range, reference is outside the range set in C04.54 and C04.55;
- 41: Below reference low, reference is lower than set in C04.54;
- 42: Above reference high, reference is higher than set in C04.55;
- 43: External alarm, the digital input terminal function [43] external alarm input is active;
- 44: Unbalance warning, unbalance occurs, see C04.8\*;
- 51: Drive in HAND state;
- 52: Drive in AUTO state;
- 53: No alarm;
- 56: Drive in HAND state;
- 57: Drive in AUTO state;
- 60: Comparator 0, using a simple PLC, the results of comparator 0;
- 61: Comparator 1, using a simple PLC, the results of comparator 1;
- 62: Comparator 2, using a simple PLC, the results of comparator 2;
- 63: Comparator 3, using a simple PLC, the results of comparator 3;
- 70: Logic rule 0, using a simple PLC, the results of logic rule 0;
- 71: Logic rule 1, using a simple PLC, the results of logic rule 1;
- 72: Logic rule 2, using a simple PLC, the results of logic rule 2;
- 73: Logic rule 3, using a simple PLC, the results of logic rule 3;
- 80: Simple PLC digital rutput 1, only active for DO1;
- 82: Simple PLC relay 1, only active for relay 1;
- 83: Simple PLC relay 2, only active for relay 2;

Par. No.	Name	Range	Unit	Default
C05.41	Relay On Delay Time	0.00~600.00	s	0.00
C05.42	Relay Off Delay Time	0.00~600.00	s	0.00

These parameters an array-2 parameters which are used to set the relay output turn-on and turnoff delay time. Array[0] is corresponding to the relay 1; array [1] is corresponding to the relay 2.

E.g:

When the relay 1 function is satisfied, it delays C05.41[0] time, then outputs ON.

When the relay 1 function is not satisfied, it delays C05.42[0] time, then outputs OFF.

#### C05.5\* Pulse Input

Terminal DI3 is a programmable multiplex terminals. It can be a high-speed pulse input terminal, also available as a normal digital input terminal. When select [32] pulse input in C05.15, DI3 is as a high-speed pulse input terminal; when select other options in C05.15, DI3 is as a normal digital

input terminal. Other digital input terminals without this feature.

C05.55~C05.58 are used to configure the scale of the pulse input. The scale is similar to the analog input VI, please refer to the diagram of analog input VI (See C06.1\*).

Par. No.	Name	Range	Unit	Default
C05.55	Terminal DI3 Low Frequency	0.00~C05.56	kHz	0.00

Enter the low frequency corresponding to the low referece/feedback value in C05.57.

Par. No.	Name	Range	Unit	Default
C05.56	Terminal DI3 High Frequency	C05.55~100.00	kHz	50.00

Enter the high frequency corresponding to the high referece/feedback value in C05.58.

Par. No.	Name	Range	Unit	Default
C05.57	Terminal DI3 Low Ref./ Feedb. Value	-200.00~200.00	%	0.00

Enter low ref. /feedb. value corresponding to value in C05.55. 0% equals 0, 100% equals value set in C03.03.

Par. No.	Name	Range	Unit	Default
C05.58	Terminal DI3 High Ref./ Feedb. Value	-200.00~200.00	%	100.00

Enter high ref./feedb. value corresponding to value in C05.56. 0% equals 0, 100% equals value set in C03.03.

Par. No.	Name	Range	Unit	Default
C05.59	Terminal DI3 Filter Time	1~1000	ms	100

Enter the pulse filter time, the low pass filter reduces the influence on and dampends the oscillations on the feedback signal from the control.

#### C05.6\* Pulse Output

Par. No.	Name	Range	Unit	Default
C05.60	Terminal DO1 Pulse Output	0~30		0

Terminal DO1 pulse output function and the corresponding scales are as follows:

Option	Function	Scale
0	Digital output	DO1 is as a collector's digital output terminal

Option	Function	Scale
10	Output frequency	In torque open loop and Process closed loop mode: 0% = 0, 100% = C04.19 In speed open loop mode:
11	Reference	0% = 0, 100% = C03.03 If C03.00 = 0, then 0% = 0, 100% = C03.03; If C03.00 = 1, then 0% = -C03.03, 100% = C03.03;
12	Feedback	
13	Output current	0% = 0, 100% = C16.37
16	Power	0% = 0, 100% = C01.20
17	Speed	0% = 0, 100% = C01.25
18	Motor voltage	0% = 0, 100% = C01.22
20	Bus control	
21	Terminal DI3 pulse input	0% = C05.55, 100% = C05.56
22	Terminal VI input	0% = C06.10/C06.12, 100% = C06.11/C06.13
23	Terminal AI input	0% = C06.20/C06.22, 100% = C06.21/C06.23
26	DC link voltage	0% = 0V, 100% = 1000V
30	Output torque	0% = 0N•m, 100% = C01.26

æ


HOLIP

Par. No.	Name	Range	Unit	Default
C05.61	Pulse Output Min. Freq.	0.00~C05.62	kHz	0.00
C05.62	Pulse Output Max. Freq.	C05.61~100.00	kHz	50.00
C05.63	Pulse Output Min. Scale	0.00~200.00	%	0.00
C05.64	Pulse Output Max. Scale	0.00~200.00	%	100.00


C05.61 and C05.62 are used to set minimum and maximum frequency of the pulse output.

C05.63 and C05.64 are used to set minimum and maximum scale corresponding to minimum and maximum frequency.

For example: In speed open loop mode, Set C03.03 = 50.0, C05.60 = 10 (0% = 0Hz, 100% = 50Hz), C05.61 = 2kHz, C05.62 = 10kHz, if C05.63 = 0.00% (0Hz), C05.64 = 100.00% (50Hz), then the relationship between the output frequency and terminal DO1 pulse output frequency is shown below:



If C05.63 = 80.00% (40Hz), C05.64 = 10.00% (5Hz), then the relationship between the output frequency and DO1 pulse output frequency is shown below:



### 6.7 Group 06: Analog In/Out


#### C06.0\* Analog I/O Mode

Par. No.	Name	Range	Unit	Default
C06.00	Live Zero Timeout Time	1~99	s	10

Live Zero Time-out Function is used for analog input signal detection. To active the Live Zero Timeout Function, if voltage input is selected, then the low input voltage (C06.10, C06.20) settings must be greater than 1V; if current input is selected, the low input current (C06.12, C06.22) settings must be greater than 2mA or more. If the analog input signal is lower than 50% of the settings of parameters of C06.10, C06.12, C06.20, C06.22, and lasts longer than the settings of C06.00 Live Zero Timeout Time, this feature takes effect.

If the analog input signal is back to normal within the delay time, then reset the timer.

Diagram of Live Zero Timeout Function is shown below:



Par. No.	Name	Range	Unit	Default
	(	0: Off		
C06.01 Live Zero Tir Function		1: Freeze output		
	Live Zero Timeout	2: Stop		0
	Function	3: Jogging		0
		4: Max. speed		
		5: Stop and trip		

Select the live zero time-out function.

- 0: Off;
- 1: Freeze output, frozen at the present value;
- 2: Stop, overruled to stop;
- 3: Jogging, overruled to jog speed;
- 4: Max. speed, overruled to Max.speed;
- 5: Stop and trip, overruled to stop with subsequent trip.

#### C06.1\*Analoge Input VI

Parameters for configuring the scaling and limits for analog input VI.


Par. No.	Name	Range	Unit	Default
C06.10	Terminal VI Low Voltage	0.00~C06.11	V	0.07
C06.11	Terminal VI High Voltage	C06.10~10.00	V	10.00
C06.12	Terminal VI Low Current	0.00~C06.13	mA	0.14
C06.13	Terminal VI High Current	C06.12~20.00	mA	20.00
C06.14	Terminal VI Low Ref./ Feedb. Value	-200.00~200.00	%	0.00
C06.15	Terminal VI High Ref./ Feedb. Value	-200.00~200.00	%	100.00


C06.10 is used to set low voltage input; C06.12 is used to set low current input; The low voltage and current analog input scaling value corresponds to the low ref./feedb. value, set in C06.14.

C06.11 is used to set high voltage input; C06.12 is used to set high current input; The high voltage and current analog input scaling value corresponds to the high ref./feedb. value, set in C06.15.

For C06.14 and C06.15, 0% equals 0, 100% equals value set in C03.03.

There are 4 kind of curves between terminal VI input voltage/current and its scale value:





C06.14 > C06.15 and C06.15 < 0

Terminal VI reference/feedback value calculated as follows:

If C06.10 <= VI Input <= C06.11,

VI Ref./Feedb. Value = ((C06.15 - C06.14)  $\div$  (C06.11 - C06.10) × (VI input - C06.10) + C06.14) × C03.03;

If VI Input < C06.10, VI Ref./Feedb. Value = C06.14 × C03.03;

If VI Input > C06.11, VI Ref./Feedb. Value = C06.15 × C03.03;


Note: Above formulas are for voltage input. If it is a current input, C06.10 and C06.11 use C06.12 and C06.13 instead respectively.

Par.	No.	Name	Range	Unit	Default
C06	.16	Terminal VI Filter Time	0.01~10.00	s	0.01

Enter the terminal VI filter time. This is a first-order digital low pass filter for suppressing electrical noise in terminal VI. A high time constant value improves dampening but also increases the time delay through the filter.

Par. No.	Name	Range	Unit	Default
C06.18	Terminal VI Zero Dead	0.0~20.00	V/mA	0.00
000.10	Band	0.0 20.00	• / 1111 1	0.00

Set the dead-band of VI at 0 speed. When analog input VI ref. low and ref. high have opposite signs, there must be a set point that corresponding to an analogue value equals 0. In order to prevent the set point jitter at zero point due to analog interference, this parameter should be set properly.



Point A as shown in the figure is the analog value that corresponds to a setpoint that equals 0. It is calculated via analog low, high values and low, high reference/feedback values. After set terminal VI zero dead band, UAB=UAC=C06.18/2. If the VI input is between B and C, the VI reference/ feedback is 0.

Par. No.	Name	Range	Unit	Default
C06.19 7	Terminal VI Mode	0: Voltage mode		Default 0
C00.19	Terminar v i Mode	1: Current mode		0

Select the input to be present on analog input VI.

#### C06.2\* Analog Input AI

Par. No.	Name	Range	Unit	Default
C06.20	Terminal AI Low Voltage	0.00~C06.21	V	0.07
C06.21	Terminal AI High Voltage	C06.20~10.00	V	10.00
C06.22	Terminal AI Low Current	0.00~C06.23	mA	0.14
C06.23	Terminal AI High Current	C06.22~20.00	mA	20.00
C06.24	Terminal AI Low Ref./ Feedb. Value	-200.00~200.00	%	0.00
C06.25	Terminal AI High Ref./ Feedb. Value	-200.00~200.00	%	100.00
C06.26	Terminal AI Filter Time	0.01~10.00	s	0.01
C06.28	Terminal AI Zero Dead Band	0.0~20.00	V/mA	0.00
C06.29	Terminal AI Mode	0: Voltage mode 1: Current mode		0

The usage of terminal AI is similar to terminal VI, please refer to C06.1\* Analog Input VI.

#### C06.7\* Analog Output VO

Par. No.	Name	Range	Unit	Default
C06.70	Terminal VO Mode	0: 0-20mA 1: 4-20mA 3: 0-10V		3

Select output to be present on analog output VO.

Attention: This parameter is in relation with the jumper switch, if voltage output is selected, junmper swith J2 leg1, 2 should be asserted on; if current output is selected, junmper swith J2 leg2, 3 should be asserted on.



Par. No.	Name	Range	Unit	Default
C06.71	Terminal VO Analog Output	0~30		0


Select choices of the analog output VO.

Option	Function	Scale
0	No function	
10	Output frequency	In torque open loop and Process closed loop mode: 0% = 0Hz, 100% = C04.19 In speed open loop mode: 0% = 0Hz, 100% = C03.03
11	Reference	If C03.00 = 0, then 0% = 0, 100% = C03.03; If C03.00 = 1, then 0% = -C03.03, 100% = C03.03;
12	Feedback	
13	Output current	0% = 0, 100% = C16.37
16	Power	0% = 0, 100% = C01.20
17	Speed	0% = 0, 100% = C01.25
18	Motor voltage	0% = 0, 100% = C01.22
20	Bus control	
21	Pulse input DI3	0% = C05.55, 100% = C05.56
22	Terminal VI input	0% = C06.10/C06.12, 100% = C06.11/C06.13
23	Terminal AI input	0% = C06.20/C06.22, 100% = C06.21/C06.23
26	DC link voltage	0% = 0V, 100% = 1000V
30	Output torque	0% = 0N·m, 100% = C01.26


Par. No.	Name	Range	Unit	Default
C06.73	Terminal VO Output Min. Scale	0.00~200.00	%	0.00
C06.74	Terminal VO Output Max. Scale	0.00~200.00	%	100.00
C06.75	Terminal VO Min. Output	0.00~C06.76		0.00 /4.00
C06.76	Terminal VO Max. Output	C06.75~10.00/20.00		10.00 /20.00

Scale minmum/maximum output of selected ananlog signal at terminal VO as percentage of minmum/maximum signal value.

For example: In speed open loop mode, set C03.03 = 50.0, C06.70 = 3 (0~10V), C06.70 = 10 (Output frequency 0% = 0.0Hz, 100% = 50.0Hz), C06.73 = 0.00% (0.0Hz), C06.74 =100.00% (50.0Hz), C06.75 = 2V, C06.76 = 8V, the relationship between the output frequency and VO output is shown below:



If C06.73 = 80.00% (40Hz), C06.74 = 10.00% (5Hz), then the relationship between the output frequency and VO output is shown below:



### C06.8\* LCP Potentiometer

The LCP Potentiometer can be select either as reference resource or relative reference source.

Par. No.	Name	Range	Unit	Default
C06.81	LCP Pot. Min. Ref.	-200.00~200.00	%	0.00
C06.82	LCP Pot. Max. Ref.	-200.00~200.00	%	100.00

These parameters are used to set the minimum/maximum reference of LCP Potentiometer. The reference of LCP potentiometer's per division depends on the set of the C00.47 LCP potentiometer step.



### 6.8 Group 07: Controllers

#### C07.1\* Torque PI Control

Parameters for configuring the torque PI control in torque open loop (C01.00 Configuration Mode).

Par. No.	Name	Range	Unit	Default
C07.12	Torque PI Proportional Gain	0~500	%	100

Enter the proportional gain value for the torque controller. Selection of a high value makes the controller react faster. Too high a setting leads to control instability.

Par. No.	Name	Range	Unit	Default
C07.13	Torque PI Integration Time	0.002~2.000	s	0.020

Enter the integration time for the torque controller. Selection of a low value makes the controller react faster. Too low a setting leads to control instability.

#### C07.2\* Process PID Feedback

Par. No.	Name	Range	Unit	Default
		0: No function		
	Process PID Feedback	1: Terminal VI		
C07.20		2: Terminal AI		0
	Source	8: Pulse input DI3		
		11: Local bus		

Select source of feedback signal.

#### C07.3\* Process PID Control

This parameter is active in closed loop process control mode (See C01.00 Configuration Mode).

Par. No.	Name	Range	Unit	Default
C07.30	Process PID Normal/	0: Normal		0
	Inverse	1: Inverse		0

Normal and inverse control are implemented by introducing a difference between the reference signal and the feedback signal.

- 0: Normal, the drive is to reduce/increase the output frequency if the feedback signal is larger/ lower than reference;
- 1: Inverse, the drive is to reduce/increase the output frequency if the feedback signal is lower/ larger than reference;




Par. No.	Name	Range	Unit	Default
C07.31		0: Disable		0
	Process PID Anti Windup	1: Enable		0

This function ensures the output frequency reaches to frequency limit. PID-controller will be initialized to the current frequency when the output frequency can not be changed. This can prevent the integrator continue to integrate on an error when the PID-controller can't adjust output frequency.

- 0: Disable, continue regulation of a given error even when the output frequency can't be increased/decreased;
- 1: Enable, ceases regulation of a given error when the output frequency can't be increased/ decreased;

Par. No.	Name	Range	Unit	Default
C07.32	Process PID Start	0.0~200.0	Hz	0.0

Enter the motor speed to be attained as a start signal for commencement of PID control. When the power is switched on, the drive will commence ramping and then operate under speed open loop control. Thereafter, when the Process PID Start Speed is reached, the drive will change over to Process PID Control.



Par. No.	Name	Range	Unit	Default
C07.33	Process PID Proportional Gain	0.00~10.00		0.01

Enter the PID proportional gain. The proportional gain multiplies the error between the set point and the feedback signal.

Attention: This function is disabled when it is set to "0".

Par. 1	lo.	Name	Range	Unit	Default
C07.	84	Process PID Integral Time	0.01~655.35	s	655.35

Enter the PID integral time. The integrator provides an increasing gain at a constant error between the set point and the feedback signal. The integral time is the time needed by the integrator to reach the same gain as the proportional gain.

ſ	Par. No.	Name	Range	Unit	Default
	C07.35	Process PID Differentiation Time	0.00~10.00	s	0.00

Enter the PID differentiation time. The differentiator does not react to a constant error, but provides a gain only when the error changes. The shorter the PID differentiation time, the stronger the gain from the differentiator.

Par. No.	Name	Range	Unit	Default
C07.38	Process PID Feed Forward Factor	0~400	%	0

Enter the PID feed forward (FF) factor. The FF factor sends a constant fraction of the reference signal to bypass the PID control, so the PID control only affects the remaining fraction of the control signal. Any change to this parameter will thus affect the motor speed. When the FF factor is activated it provides less overshoot, and high dynamics when changing the set point.

Par. No.	Name	Range	Unit	Default
C07.39	On Reference Bandwidth	0.0~200.0	%	0.1

Enter the On Reference Bandwidth. When the PID Control Error (the difference between the reference and the feedback) is less than the set value of this parameter, the PID control stops.

Par. No.	Name	Range	Unit	Default
C07.41	Process PID Output Low	-100.00~100.00	%	0.00
C07.42	Process PID Output High	-100.00~100.00	%	100.00

These parameters are used to set process PID controller output low/high limit, 100% corresponds to C04.19.

### 6.9 Group 08: Communication

C08.0\* Comm. General Settings

Par. No.	Name	Range	Unit	Default
		0: Digital and Communication		
C08.01	Control Site	1: Digital only		0
		2: Communication only		

The drive start, stop, reverse, jog commands can be given both through digital input terminals and communication, this parameter is used to set the drive control command site.

- 0: Digital and Communication, controlled by using both digital input and Communication;
- 1: Digital only, controlled by using digital inputs only;
- 2: Communication only, controlled by using communication only;

Par. No.	Name	Range	Unit	Default
C08.03	Communication Timeout Time	0.00~650.00	s	1.00

Enter the maximum time expected to pass between the reception of two consecutive telegrams. If this time is exceeded, it indicates that the serial communication has stopped. The function selected in C08.04 Communication Timeout Function will then be carried out. The time-out counter is triggered by a valid communication.

Par. No.	Name	Range	Unit	Default
		0: Off		
		1: Freeze output		
C08.04	Communication Timeout	2: Stop		0
000.04	Function	3: Jogging 4: Max. speed		0
		4: Max. speed		
		5: Stop and trip		

The communication time-out function activates when the communication fails to be updated within the time period specified in C08.03 Communication Timeout Time.

- 0: Off, resumes control via serial bus using the most recent control word;
- 1: Freeze output, frozen at the present value;
- 2: Stop, overruled to stop;
- 3: Jogging, overruled to jog speed;
- 4: Max. speed, overruled to max.speed;
- 5: Stop and trip, overruled to stop with subsequent trip ("E.17").

Par. No.	Name	Range	Unit	Default
C08.06	Reset Communication	0: Do not reset		0
	Timeout	1: Do reset		0



Resetting communication timeout will remove any timeout function. After communication timeout occurs, a communication interrupt flag will be within the drive. It must be use the parameter to clear the flag (Do reset), else even to restore communication or clear "E.17" alarm, the drive will continue to report communication timeout.

0: Do not reset, communication timeout is not reset;

1: Do reset, communication timeout is reset;

Par. No.	Name	Range	Unit	Default
C08.29	Communication Alarm	0: Bit mode		0
	Mode	1: Code mode		0

Register 51101 is used to store the drive fault information, it has two warning/alarm modes:

0: Bit mode

Each register bit represents a different warning and failure.

1: Code mode

Warning/alarm code is stored in the register. For example: When the drive occurs E.13 alarm, the value of register 51101 is 13.

C08.3\* Port Setting

Par. No.	Name	Range	Unit	Default
		0: FC		
C08.30	Protocol	2: Modbus RTU		0
		6: Modbus ASCII		

Select the protocol to be used.

Par. No.	Name	Range	Unit	Default
C08.31	Address	0~247		1

Select the address for the bus. FC-bus range is 1-126, and Modbus range is 1-247.

Par. No.	Name	Range	Unit	Default
		0: 2400		
		1: 4800		2
	Baud Rate	2: 9600		
		3: 19200	bit/s	
C08.32		4: 38400		
		5: 57600		
		6: 76800		
		7: 115200		
		8~9: Reserved		

Select baud rate for communication.



Par. No.	Name	Range	Unit	Default
	C08 33 Parity/Stop Bits	0: Even parity (1 stop bit)		
C00.22		1: Odd parity (1 stop bit)		2
C08.55		2: No parity (1 stop bit)		2
		3: No parity (2 stop bit)		

This parameter only effective for Modbus and FC bus always has even parity.

Par. No.	Name	Range	Unit	Default
C08.35	Min. Response Delay	0.000~0.500	s	0.002

Specify the minimum delay time between receiving a request and transmitting a response. This is used for overcoming modem turnaround delays.

Par. No.	Name	Range	Unit	Default
C08.36	Max. Response Delay	0.010~10.000	s	5.000

Specify the maximum permissible delay time between transmitting a request and receiving a response. If exceeds this delay time, the drive will not respond to received data.

Par. No.	Name	Range	Unit	Default
		0: Normal		
C08.38	Message Response	1: Only response exception message		0
		2: Not response		

This parameter is used to control Modbus message response.

Attention: the drive will response the READ instruction no matter what C08.38 set.

Par. No.	Name	Range	Unit	Default
C08.39	Modbus Parameter Write	0: Not saved at power down		0
	Store	1: Saved at power down		0

This parameter is used to control whether the parameters which is changed by Modbus WRITE instruction are saved or not at power down.

#### C08.5\* Digital/Bus

This parameter only active only when C08.01 Control site is set to [0] digital and control word.

Par. No.	Name	Range	Unit	Default
C08.50	Coasting Select			3
C08.53	Start Select	0: Digital input		3
C08.54	Reversing Select	1: Bus - 2: Logic AND 3: Logic OR		3
C08.55	Set-up Select			3
C08.56	Preset Reference Select			3

Select control of the coasting, start, reverse, set-up and preset reference function via the terminals (digital input) and/or via the bus.

æ

- 0: Digital input, activate via a digital input;
- 1: Bus, activate via serial communication port;
- 2: Logic AND, activate via serial communication port and a digital input;
- 3: Logic OR, activate via serial communication port or a digital input;

### 6.10 Group 13: Simple PLC

Simple PLC is a user-defined sequence of operation (C13.52[x]). When the associated user-defined envents (C13.51[x]) is set to true, Sample PLC will perform these operations.

Events and related operations are paired, that is , once an event is "true", will execute its associated action. You can set up to 54 events and operations.

Start and stop simple PLC: Selects order or parallel control in C13.00 Sample PLC Mode, when start event (C13.01) is "true", start simple PLC, when stop event (C13.02) is "true", simple PLC will be stopped. In addition, you can also choose [0] off (C13.00) to stop the simple PLC.

Attention: Simple PLC function is only valid in AUTO mode.


#### C13.0\* Simple PLC Settings

Par. No.	Name	Range	Unit	Default
		0: Off		
C13.00	Simple PLC Mode	1: Order execution		0
		2: Parallel execution		


Set the simple PLC control mode.

0: Off;

1: Order execution, after simple PLC start event is "true", the control event executes orderly: from the control event 0 (C13.51[0]) to control events n (C13.51[N], N is the last non-empty event) and then back to control event 0, as shown in the following figure:



2: Parallel execution, after simple PLC start event is "true", the control event executes parallelly: control event 0~N executes at the same time (cycle), as shown in the following figure:



Par. No.	Name	Range	Unit	Default
C13.01	Start Event	0~54		39

Enter the simple PLC start event.

- 0: False, enter the fixed value FALSE;
- 1: True, enter the fixed value TRUE;
- 2: Running, the motor is running;
- 3: In current range-No warning, The motor is running within the programmed current ranges set in C04.50 Warning Current Low and C04.51 Warning Current High, and no warning is present;
- 4: On reference-No warning, the motor is running on reference, and no warning is present;
- 7: Out of current range, output current is outside the range set in C04.50 and C04.51;
- 8: Below current low, output current is lower than set in C04.50;
- 9: Above current high, output current is higher than set in C04.51;
- 10: Out of frequency range, output frequency is outside the range set in C04.52 and C04.53;
- 11: Below frequency low, output frequency is lower than set in C04.52;
- 12: Above frequency high, output frequency is higher than set in C04.53;
- 13: Out of feedback range, feedback is outside the range set in C04.56 and C04.57;
- 14: Below feedback low, feedback is lower than set in C04.56;
- 15: Above feedback high, feedback is higher than set in C04.57;
- 16: Thermal warning, a thermal warning occurs;
- 17: Mains out of range, over-voltage or under-voltage occurs;
- 18: Reversing, the drive runs in counter clockwise;
- 19: Warning, if the drive issues a warning, this event is TRUE;
- 20: Alarm (trip), if the drive alarms and trip is actived, this event is TRUE;
- 21: Alarm (trip lock), if the drive alarms and trip lock is actived, this event is TRUE;
- 22: Comparator 0, output of comparator 0 is used in logic rules;
- 23: Comparator 1, output of comparator 1 is used in logic rules;
- 24: Comparator 2, output of comparator 2 is used in logic rules;
- 25: Comparator 3, output of comparator 3 is used in logic rules;
- 26: Logic rule 0, result of logic rule 0 is used in logic rules;



27: Logic rule 1, result of logic rule 1 is used in logic rules;

28: Logic rule 2, result of logic rule 2 is used in logic rules;

29: Logic rule 3, result of logic rule 3 is used in logic rules;

30: Simple PLC time-out 0, result of timer 0 is used in logic rules;

31: Simple PLC time-out 1, result of timer 1 is used in logic rules;

32: Simple PLC time-out 2, result of timer 2 is used in logic rules;

33: Terminal FOR, input value entered via terminal FOR is used in logic rules;

34: Terminal REV, input value entered via terminal REV is used in logic rules;

35: Terminal DI1, input value entered via terminal DI1 is used in logic rules;

36: Terminal DI2, input value entered via terminal DI2 is used in logic rules;

38: Terminal DI3, input value entered via terminal DI3 is used in logic rules;

39: Start command, if the drive starts in any way, this event is TRUE;

40: Drive stopped, if the drive stops in any way, this event is TRUE;

50: Simple PLC time-out 3, result of timer 3 is used in logic rules;

51: Simple PLC time-out 4, result of timer 4 is used in logic rules;

52: Simple PLC time-out 5, result of timer 5 is used in logic rules;

53: Simple PLC time-out 6, result of timer 6 is used in logic rules;

54: Simple PLC time-out 7, result of timer 7 is used in logic rules;

Par. No.	Name	Range	Unit	Default
C13.02	Stop Event	0~54		40

Enter the simple PLC stop event. For options, see C13.01 Start Event.

Par. No.	Name	Range	Unit	Default
C12.02	C13.03 Reset Simple PLC	0: Do not reset		0
C13.03		1: Do reset		0

0: Do not reset, retains programmed settings in all group 13 parameters;

1: Do reset, resets all group 13 parameters to default settings;

Par. No.	Name	Range	Unit	Default
	Simple PLC Store	0: No function		
		1: Power down save		0
C13.04		2: Stop save		0
		3: Both power down and stop save		

This parameter is used to select whether the simple PLC state is saved or not at power down/stop.

#### C13.1\* Comparators

Comparators are used for comparing continuous variables (e.g. output frequency, output current, analog input etc.) with fixed preset values. In addition, there are some constant value in

conjunction with the preset value for comparison, please refer to options in C13.10. In each of the scanning integral the comparator will be evaluated once. And directly use the results (true or false). Parameters in this group are all array-type parameter with index 0-4. Select 0 to programme Comparator 0, select index 1 to programme Comparator 1, and so on.

For example: Motor current is 25A, C13.10 [0] =4, C13.12 [0] =23, C13.11 [0] =2, then the output of comparator 0 is TRUE.

Par. No.	Name	Range	Unit	Default
C13.10	Comparator Operand	0~31		0

0: Disabled;

1: Reference;

2: Feedback;

3: Motor speed [Hz];

4: Motor current [A];

6: Motor power [kW];

7: Motor Voltage [V];

12: Terminal VI input, depending on your choice is current input or voltage input;

13: Terminal AI input, depending on your choice is current input or voltage input;

20: Fault number, please refer to chapter 8;

30: Counter A;

31: Counter B;

Par. No.	Name	Range	Unit	Default
		0: Less than		
C13.11	Comparator Operator	1: Approx. Equal		1
		2: Greater than		

0: Less than, if the variable selected in C13.10 is less than the set value in C13.12, the comparator output is TRUE, else FALSE;

1: Approx. Equal, if the variable selected in C13.10 equals the set value in C13.12, the comparator output is TRUE, else FALSE;

2: Greater than, opposite with option [0];

Par. No.	Name	Range	Unit	Default
C13.12	Comparator Value	-9999.0~9999.0		0.0

Enter the "trigger level" for the variable that is monitored by this comparator.

#### C13.2\* Timers

Use the timer output to define an event (see C13.51) or acts as Boolean inputs of the logic rules (see C13.40, C13.42 or C13.44).



Par. No.	Name	Range	Unit	Default
C13.20	Simple PLC Timer	0.00~3600.00	s	0.00

This parameter is an array [8] parameters with index 0 to 7. Select index 0 to Timer 0, select index 1 to Timer 1, and so on.

Timer is started by option [29]~[31], [65]~[69] in C13.52 Simple PLC Action, and becomes TRUE if its value has exceeded the set time.

#### C13.4\* Logic Rules

Combine up to three boolean inputs (TRUE or FALSE inputs) from timers, comparators, digital inputs, status bits and events using the logical operators AND, OR and NOT. C13.40, C13.42 and C13.44 are used to select logic rule Booleans, and C13.41, C13.43 is for selecting logic rule operators.

Caculation order: First, select three Boolean inputs from C13.40, C13.41 and C13.42 for the selected logic rule, and then the result ("TRUE or FALSE") as a logic boolean value, together with other two boolean inputs got from C13.43 and C13.44 to obtain the final result of the calculation ("TRUE or FALSE").

All parameters in this parameter group are array [4] parameters with index 0 to 3. Select index 0 to logic rule 0, select index 1 to logic ruler 1, and so on.

Par. No.	Name	Range	Unit	Default
C13.40	Logic Rule Boolean 1	The same as C13.01's		0

Select the first boolean (TRUE or FALSE) input for the selected logic rule. Options refer to C13.01.

Par. No.	Name	Range	Unit	Default
C13.41	Logic Rule Operator 1	0~8		0

Select the first logic operator to be used on the boolean inputs from C13.40 Logic Rule Boolean 1 and C13.42 Logic Rule Boolean 2.

- 0: Disabled, ignoring C13.40 and C13.42;
- 1: AND, evaluates the expression [C13.40] AND [C13.42];
- 2: OR, evaluates the expression [C13.40] OR [C13.42];
- 3: AND NOT, evaluates the expression [C13.40] AND NOT [C13.42];
- 4: OR NOT, evaluates the expression [C13.40] OR NOT [C13.42];
- 5: NOT AND, evaluates the expression NOT [C13.40] AND [C13.42];
- 6: NOT OR, evaluates the expression NOT [C13.40] OR [C13.42];

7: NOT AND NOT, evaluates the expression NOT [C13.40] AND NOT [C13.42];

8: NOT OR NOT, evaluates the expression NOT [C13.40] OR NOT [C13.42];

Par. No.	Name	Range	Unit	Default
C13.42	Logic Rule Boolean 2	The same as C13.01's		0

Select the second boolean (TRUE or FALSE) input for the selected logic rule. Options refer to C13.01.

Par.	. No.	Name	Range	Unit	Default
C13	3.43	Logic Rule Operator 2	0~8		0

Select the second logic operator to be used on the boolean input calculated in C13.40 Logic Rule Boolean 1, C13.42 Logic Rule Operator 1 and C13.43 Logic Rule Boolean 2 and the boolean input coming from C13.44 Logic Rule Boolean 3.

0: Disabled, ignoring C13.44;

1: AND, evaluates the expression [C13.40/C13.42] AND [C13.44];

2: OR, evaluates the expression [C13.40/C13.42] OR [C13.44];

3: AND NOT, evaluates the expression [C13.40/C13.42] AND NOT [C13.44];

4: OR NOT, evaluates the expression [C13.40/C13.42] OR NOT [C13.44];

5: NOT AND, evaluates the expression NOT [C13.40/C13.42] AND [C13.44];

6: NOT OR, evaluates the expression NOT [C13.40/C13.42] OR [C13.44];

7: NOT AND NOT, evaluates the expression NOT [C13.40/C13.42] AND NOT [C13.44];

8: NOT OR NOT, evaluates the expression NOT [C13.40/C13.42] OR NOT [C13.44];

Par. No.	Name	Range	Unit	Default
C13.44	Logic Rule Boolean 3	The same as C13.01's		0

Select the third boolean (TRUE or FALSE) input for the selected logic rule. Options refer to C13.01.

#### C13.5\* Events/Actions

This group of parameter is used for setting evens or actions for Simple PLC. All parameters in this parameter group are array [30] parameters with index 0 to 29. Select index 0 to event/action 0, select index 1 to event/action 1, and so on.

Par. No.	Name	Range	Unit	Default
C13.51	Simple PLC Event	The same as C13.01's		0

Select the boolean input to define the Simple PLC event. Options refer to C13.01.

Par. No.	Name	Range	Unit	Default
C13.52	Simple PLC Action	0~69		0

Select the action corresponding to the C13.51 Simple PLC Events. Actions are executed when the corresponding event is evaluated as true.

0: Disabled, function is disabled;



- 1: No action, no action is operated;
- 2: Select set-up 1, select set-up 1 changes the active set-up to "1";
- 3: Select set-up 2, select set-up 2 changes the active set-up to "2";
- 10: Select preset ref 0;
- 11: Select preset ref 1;
- 12: Select preset ref 2;
- 13: Select preset ref 3;
- 14: Select preset ref 4;
- 15: Select preset ref 5;
- 16: Select preset ref 6;
- 17: Select preset ref 7;
- 18: Select ramp 1;
- 19: Select ramp 2;
- 20: Select ramp 3;
- 21: Select ramp 4;
- 22: Run, issues a start command to the drive;
- 23: Run reverse, issues a start reverse command to the drive;
- 24: Stop, issues a stop command to the drive;
- 27: Coast, the drive coasts immediately, all stop commands including the coast command stop the drive;
- 28: Freeze output, freezes the output frequency of the drive;
- 29: Start timer 0;
- 30: Start timer 1;
- 31: Start timer 2;
- 32: Set terminal DO1 low;
- 34: Set relay 1 low;
- 35: Set relay 2 low;
- 38: Set terminal DO1 high;
- 40: Set relay 1 high;
- 41: Set relay 2 high;
- 50: Select preset ref 8;
- 51: Select preset ref 9;
- 52: Select preset ref 10;
- 53: Select preset ref 11;
- 54: Select preset ref 12;
- 55: Select preset ref 13;
- 56: Select preset ref 14;
- 57: Select preset ref 15;

- 60: Reset counter A, reset counter A to "0";61: Reset counter B, reset counter B to "0";
- 65: Start timer 3:
- 66: Start timer 4:
- 67: Start timer 5;
- 68: Start timer 6;
- 69: Start timer 7;
- 70: Reverse;

## 6.11 Group 14: Special Functions

Par. No.	Name	Range	Unit	Default
		2~6: 2~6kHz	kHz *	
		7: 8kHz		
C14.01	Switching Frequency	7: 8KHz 8: 10kHz	kHz	*
		9: 12kHz	kHz	
		10: 16kHz		

Switching frequency has a significant influence to the drive and the motor. Select appropriate switch frequency can help to adjust acoustic noise from the motor, power consumption and the drive efficiency. When switching frequency increases, the consumption and the noise of the motor are reduced, but the drive's temperature will increase, and motor leakage and the interference to the external device will increase; the contrary, the opposite.

Par. No.	Name	Range	Unit	Default
*C14.02	Overmodulation	0: Off	1	
*C14.03	Overmodulation	1: On		1

The overmodulation function can obtain an output voltage greater than mains voltage.

- 0: Off, disable the overmodulation function to avoid torque ripple on the motor shaft. This feature may be useful for applications such as grinding machines.;
- 1: On, connects the overmodulation function to obtain an output voltage up to 5% greater than mains voltage. Overmodulation leads to increased torque ripple as

harmonics are increased;

Par. No.	Name	Range	Unit	Default
C14.08	Damping Gain Factor	0~200	%	96

Damping gain factor can help to improve the response speed of the DC link of the drive making the DC loop signal more smooth.

### C14.1\* Mains On/Off



Par. No.	Name	Range	Unit	Default
		0: No function		
		1: Ctrl ramp-down		
	14.10 Action at Mains Failure	2: Ctrl ramp-down, trip		
C14.10		3: Coasting		0
		4: Kinetic back-up	Unit	
		5: Kinetic back-up, trip		
		6: Alarm		

This parameter is typically used to where very short mains interruptions (voltage dips) are present. At 100% load and a short voltage interruption, the DC voltage on the main capacitors drops quickly. For larger drive it only takes a few milliseconds before the DC level is down to about 373V DC and the IGBTs cut off and looses the control over the motor. When the mains is restored, and the IGBTs start again, the output frequency and voltage vector does not correspond to the speed/ frequency of the motor, and the result is normally an overvoltage or overcurrent, mostly resulting in a trip lock. C14.10 Mains Failure can be programmed to avoid this situation.

This parameter is used to select the function to which the drive must act when the threshold in C14.11 Mains Voltage at Mains Fault has been reached.

0: No function

The drive will not compensate for a mains interruption. The voltage on the DC-link will drop quickly and motor control will be lost within milliseconds to seconds.

1: Ctrl ramp-down

This selection is particularly useful in pump applications, where the inertia is low and the friction is high. When the mains is restored, the output frequency will ramp the motor up to the reference speed (if the mains interruption is prolonged, the controlled ramp down might take the output frequency all the way down to 0rpm, and when the mains is restored, the application is ramped up from 0rpm to the previous reference speed via the normal ramp up). If the energy in the DC-link disappears before the motor is ramped to zero the motor will be coasted.

2: Ctrl ramp-down, trip

This selection is similar to selection [1] except that in [2] a reset is necessary for starting up after power-up.

3: Coasting

Centrifuges can run for an hour without power supply. In those situations it is possible to select a coast function at mains interruption, together with a flying start which occurs when the mains is restored.

4: Kinetic back-up

Kinetic back-up ensures that the frequency converter keeps running as long as there is energy in the system due to the inertia from motor and load. This is done by converting the

mechanical energy to the DC-link and thereby maintaining control of the drive and motor. This can extend the controlled operation, depending on the inertia in the system. For fans it is typically several seconds, for pumps up to 2 seconds and for compressors only for a fraction of a second. Many industry applications can extend controlled operation for many seconds, which is often enough time for the mains to return.

5: Kinetic back-up, trip

The difference between kinetic back-up with and without trip is that the latter will always ramp down to 0RPM and trip, regardless of whether mains return or not.

The function is made so that it will not even detect if mains return, this is the reason for the relatively high level on the DC-link during ramp down.

6: Alarm

The drive reports alarm "E.36".

Note: For option [1] to [5], the drive will report warning "A.36" while doing the selected operation.

Par. No.	Name	Range	Unit	Default
C14.11	Mains Voltage at Mains Failure	100~800	V	*

This parameter defines the threshold votlage at which the selected function in C14.10 Mains Failure should be activated.

Par. No.	Name	Range	Unit	Default
		0: Trip (Low sensitivity)		
		1: Warning (Low sensitivity)		
C14.12	Function at Mains	2: Disabled		0
C14.12	Imbanlance	4: Warning (Middle sensitivity)		0
		5: Trip (Middle sensitivity)		
		6: Trip (High sensitivity)		

Select actions when a mains imbalance is detected. The dection of mains imbalance depends on load. In order to meet different applications, different sensitivity options are set for this parameter.

- 0: Trip (Low sensitivity), the drive trips (reports "E.04") when a mains imbalance is detected;
- 1: Warning (Low sensitivity), the drive issues a warning (reports "A.04") but continues to run when a mains imbalance is detected;

The dection method for option [0] and [1] is low sensitive, even if a severe mains imbalance occurs, the drive will continue to run and do not report warning if the load is low, the drive and motor will not damage in this occasion; The drive trips (option [0]) or issues a warning (option [1]) only the load exceeds a certain range.

2: Disabled, the drive does nothing when a mains imbalance is detected. Be attention to use this option;



- 4: Warning (Middle sensitivity), the drive issues a warning (reports "A.04") but continues to run when a mains imbalance is detected;
- 5: Trip (Middle sensitivity), the drive trips (reports "E.04") when a mains imbalance is detected;

The dection method for option [4] and [5] is middle sensitive. The drive trips (option [5]) or issues a warning (option [4]) at low frequency and heavy loaded, or high frequency and low load.

6: Trip (high sensitivity), the drive trips (reports "E.04") when a mains imbalance is detected; The dection method for option [6] is high sensitive. Mains imbalance can be detected immediately. But there is minimum risk of false positives (generally occurs in an abnormal grid or the drive over-current protection frequently).

Par. No.	Name	Range	Unit	Default
C14.16	Low Voltage Mode	0: Disable 1: Enable		0

If the power input voltage is low, enable low voltage mode can improve load capacity. If the voltage is 15% lower, enable low voltage mode can make the drive afford long-term full load; If the voltage is 20% lower, the drive needs to down load; If the voltage is normal, do not enable the low voltage mode, otherwise it will reduce the drive useful life.

Par. No.	Name	Range	Unit	Default
C14.17	Automatic Voltage	0: Disable		1
	Regulation	1: Enable		1

When motor voltage 12%~20% higher than rated, motor temperature will increase, insulation capability destroyed, the torque output is unstable, long-term operation will cause the motor shorten its life.

Automatic voltage regulation can automatically control the output voltage at the motor's rated voltage when the grid voltage exceed the rated motor voltage.

Turn off automatic voltage regulation will improve the ability of rapid deceleration, but turn off this option need to be cautious, it will cause the output voltage different due to different grid voltage, there is an increased risk of heat damage to the motor.

This feature can only be turned off when in VF mode.

Par. No.	Name	Range	Unit	Default
(1418	Delay Time of Auto Restart When Power up Again	0.0~3600.0	s	0.0

This parameter is used to define the drive action when power up again after power loss during running.

If it is set to 3600.0, the drive does not respond to the start command valid upon drive power-on (for example, start terminal is ON before power-on). The drive responds only after the start command is cancelled and becomes valid again.

If it is set to 0.0~3599.9, the drive will respond to the start command delaying the C14.18 setting time upon drive power-on (for example, start terminal is ON before power-on).

#### C14.2\* Trip Reset

Par. No.	Name	Range	Unit	Default
		0: Manual reset		
		1~10: Auto reset 1-10 times		
C14.20	Reset Mode	11: Auto reset 15 times		0
		12: Auto reset 12 times		
		13: Infinite auto reset		

Select reset function after tripping.

0: Manual reset, perform reset via "OFF" button or digital inputs;

1~10: Auto reset 1-10 times, can perform 1-10 automatic resets after trips;

11: Auto reset 15 times, can perform 15 automatic resets after trips;

12: Auto reset 20 times, can perform 20 automatic resets after trips;

13: Infinite auto reset, can perform an infinite number of automatic resets after trips;

Once option [1] - [13] is selected, the drive will be restarted after an alarm. If reset has been done and the running signal is active, the drive will restart automatically. For option [1] - [12], if the drive performs a set number of automatic reset, fault still cannot be removed, the drive will remain a trip state. It needs power off and on to reset the trip after shooting fault.

Be attention to select option [13], it may cause infinite auto reset.

Par. No.	Name	Range	Unit	Default
C14.21	Automatic Restart Time	0~600	s	10

Enter time interval from trip to start of automatic reset function after an alarm. This parameter is active when C14.20 Reset Mode is set to automatic reset [1]-[13].

Par. No.	Name	Range	Unit	Default
C14.22	Operation Mode	0: Normal operation		
		2: Initialization		0
		3: Backup user settings		0
		4: Recover user settings		

0: Normal operation;

2: Initialization, initialise all the parameters except information about the drive itself and the recorded parameters.

3: Backup user settings;

#### 4: Recover user settings;

For option [3] to [4], after modifying the drive parameters based on the functional requirements, OEM manufacturers can set C14.22 = 3 to backup settings. If the end users modify parameters and cannot be self-recovery, it can be recovered by setting C14.22 = 4 or pressing "OFF" key on LCP 5 seconds (the default time, can be modified by C00.46 One Key Recovery Time).

Par. No.	Name	Range	Unit	Default
C14.23	Trip lock	0: Disable		
		1: Enable		0

- 0: Disable, trip lock fault reset do not need power off;
- 1: Enable, trip lock fault reset need power off;

Par. No.	Name	Range	Unit	Default
C14.27	Action at Drive Fault	0: Trip 1: Warning		0

Select how the drive should react at inerter fault (output short circuit, over-current, earth fault or over-voltage).

- 0: Trip, drive issues an alarm and trips immediately if it detects a fault;
- 1: Warning, when a fault occurs, drive issues a warning and stops the PWM outputs, and repeatly try to open the normal PWM, if the fault still can't be removed, the drive issues an alarm and trips.

#### C14.3\* Current Limit Control

The drive contains two current limit controllers. The two controllers will be enabled when the current is over C04.18 current limit. Current controller 1 controls current by reducing the output frequency, and current controller 2 controls current by reducing the output voltage. Typically only recommended to use current controller 1, if it is still unable to control the current in some occasions (such as fast acceleration and deceleration), you can use the current controller 2.

Par. No.	Name	Range	Unit	Default
C14.30	Current Controller 1	0~500	%	100
014.50	Proportional Gain	0~500	70	100
C14.31	Current Controller 1	0.000~2.000	s	0.020
014.51	Integration Time		8	0.020
C14.32	Current Controller Filter	0.1~100.0	ms	10.0
014.52	Time		1115	10.0
C14.33	Current Controller 2	0~300	%	0
014.55	Proportional Gain	0~500	70	0
C14.34	Current Controller 2	0.000~2.000		0.020
014.34	Integration Time	0.000~2.000	s	0.020

It can adjust the dynamic response characteristics of the current controllers by setting the

proportional gain and integration time.

Choose a higher value of proportional gain and lower integration time causes the controller response more quickly, but too high value of proportional gain and tow low value of integration time will cause the controller unstable.

#### C14.4\* Energy Optimising

Par. No.	Name	Range	Unit	Default
*C14.40	VT Level	40~90	%	90

Enter the level of motor magnetisation at low speed. Selection of a low value reduces energy loss in the motor, but also reduces load capability.

Par. No	. Name	Range	Unit	Default
*C14.41	AEO Min. Magnetisation	40~75	%	66

Enter the minimum allowable magnetisation for AEO. Selection of a low value reduces energy loss in the motor, but can also reduce resistance to sudden load changes.

Par. No.	Name	Range	Unit	Default
		0: Off		
*C14.50	RFI Filter Selection	1: On		1
		2: Reserved		

- 0: Off, only the power supply is IT mains system can select [0] Off. In this mode, the linkage can be reduced;
- 1: On, to ensure the drive meets EMC standards, select [1] On ;
- 2: Reserved;

Attention: The RFI Filter selection in the model (<=22kW) is not controlled by this parameter, but selected by screwing off/on the RFI switch.

Par. No.	Name	Range	Unit	Default
*C14.51	*C14.51 DC Link Compensation	0: Off		0
014.51		1: On		0

This function ensures the output voltage is independent of any voltage fluctuations in the DC link. Low torque ripple. In some cases, this dynamic compensation may cause resonance problems in DC link circuit and then this function should be disabled.

Par. No.	Name	Range	Unit	Default
C14.68	Overheat warning relative	0~25	ŝ	5
014.00	temperature	025	C	5

This temperature is the overheat (E.69) relative temperature protection point, the default value is 5  $^\circ C$ , that is, 5  $^\circ C$  lower than the overheat (E.69) temperature protection point. When the drive

temperature reaches the relative protection point for a few seconds, it will report A.69 warning. With this parameter, users can more easily control the overheat warning report.

æ

## 6.12 Group 15: Drive Information

#### C15.0\* Operating Data

Par. No.	Name	Range	Unit	Default
C15.00	Operating Days	0~9999	d	

View how many days the drive has run. The value is saved automatically at power off and can't be reset.

Par. No.	Name	Range	Unit	Default
C15.01	Running Hours	0~60000	h	

View how many hours the motor has run. Reset the counter in C15.07 Reset Running Hours Counter.

Par. No.	Name	Range	Unit	Default
C15.02	kWh Counter	0~65535	kWh	

View the power consumption of the motor as a mean value over one hour. Reset the counter in C15.06 Reset kWh Counter.

Par. No.	Name	Range	Unit	Default
C15.03	Power Up's	0~65535		

View the number of times the drive has been powered up. This parameter can't be reset.

Par. No.	Name	Range	Unit	Default
C15.04	Over Temperatures	0~65535		

View the number of the drive temperature faults that have occurred. This parameter can't be reset.

Par. No.	Name	Range	Unit	Default
C15.05	Over Voltages	0~65535		

View the number of drive over-voltages that have occurred. This parameter can't be reset.

Par. No.	Name	Range	Unit	Default
C15.06	Reset kWh Counter	0: Do not reset		0
		1: Do reset		0

0: Do not reset;

1: Do reset, kWh counter is reset to zero (see C15.02 kWh Counter);

Attention: This parameter can't be set via local bus.

Par. No.	Name	Range	Unit	Default
C15.07	Reset Running Hours	0: Do not reset		0
015.07	Counter	1: Do reset		0

0: Do not reset;

1: Do reset, running hours counter is reset to zero (see C15.01 Running Hours);

Attention: This parameter can't be set via local bus.

#### C15.3\* Fault Log

Par. No.	Name	Range	Unit	Default
C15.30	Alarm Code	0~255		

View the alarm code and look up its meaning in chapter 8. This parameter is an array [10] parameters. It contains a alarm log showing reasons for the ten latest trips. C15.30[0] represents the latest, C15.30[9] is a recent 10th, this parameter cannot be reset.

Par. No.	Name	Range	Unit	Default
C15.31	Internal Fault Reason	-32767~32767		

This parameter contains internal fault reasons, mostly used in combination with alarm E.38.

Par. No.	Name	Range	Unit	Default
C15.38	Warning Code	0~255		

View the warning code and look up its meaning in chapter 8. This parameter is an array [10] parameters. It contains a warning log showing reasons for the ten latest warnings. C15.38[0] represents the latest, C15.38[9] is a recent 10th, this parameter cannot be reset.

#### C15.4\* Drive Identification

Par. No.	Name	Range	Unit	Default
C15.43	Software Version			

View the software version of the drive.

### 6.13 Group 16: Data Readouts

This parameter group is read-only.

#### C16.0\* General Status

Par. No.	Name	Range	Unit	Default
C16.00	Control Word	0~65535		

View latest valid control word that sent to the drive via local bus. Turn it into 16-bit binary code.

For the meaning of each bits, please refer to register 2809 and coils 0~15 description in appendix A Modbus Communication Specification.

Par. No.	Name	Range	Unit	Default
C16.01	Reference	-4999.0~4999.0		

View the actual reference.


Par. No.	Name	Range	Unit	Default
C16.02	Reference	-200.0~200.0	%	

View the actual reference in percentage.

Par. No.	Name	Range	Unit	Default
C16.03	Status Word	0~65535		

View active status word, the following shows the definition for each bit.

	Communication Status Word				
Bit	0	1			
Bit00	Control Not Ready	Control Ready			
Bit01	Drive Not Ready	Drive Ready			
Bit02	Coasting	Enabled			
Bit03	No Error	Trip			
Bit04	Error	Error Without Trip			
Bit05	Undefined	Undefined			
Bit06	No Error	Trip			
Bit07	No Warning	Warning			
Bit08	Not On Reference	On Reference			
Bit09	Local Control	Remote Control			
Bit10	Frequency Not In Range	Frequency In Range			
Bit11	Stop	Running			
Bit12	Brake Resistor Is Normal	Brake Resistor Fault			
Bit13	Voltage Limit	Out Of Voltage Limit			
Bit14	Undefined	Undefined			
Bit15	No Terminal Warning	Terminal Warning			





Par. No.	Name	Range	Unit	Default
		0: Set-up 1		
C16.04	Active Set-up	1: Set-up 2		
	-	2: Multi Set-up		

View the drive active set-up.

Par. No.	Name	Range	Unit	Default
C16.05	Motor Speed	0~9999	rpm	

View motor speed.

Par. No.	Name	Range	Unit	Default
C16.06	Low Voltage Frequency Limit	0.0~400.0	Hz	

View Low Voltage Frequency Limit.

Par. No.	Name	Range	Unit	Default
C16.09	Custom Readout	0.00~99999.00		

View the value of user-defined readout corrected from C00.31, C00.32 and C04.14.

#### C16.1\* Motor Status

Р	ar. No.	Name	Range	Unit	Default
(	C16.10	Output Power	0.00~655.35	kW	

View output power in kW.

Par. No.	Name	Range	Unit	Default
C16.12	Motor Voltage	0~65535	V	

View motor phase voltage.

Par. No.	Name	Range	Unit	Default
C16.13	Output Frequency	0.0~400.0	Hz	

View output frequency.

Par. No.	Name	Range	Unit	Default
C16.14	Output Current	0.00~655.35	A	

View motor phase current.

Par. No.	Name	Range	Unit	Default
C16.15	Output Frequency	0.0~200.0	%	

View actual output frequency in percentage.



Par. No.	Name	Range	Unit	Default
C16.16	Output Torque	-200.0~200.0	%	

View actual output Torque.

Par. No.	Name	Range	Unit	Default
C16.18	Motor Thermal	0~100	%	

View calculated thermal motor load which is set as percentage of estimated thermal motor load.

### C16.3\* Drive Status

Par. No.	Name	Range	Unit	Default
C16.30	DC Link Voltage	0~65535	V	

View DC-link voltage.

Par. No.	Name	Range	Unit	Default
C16.31	IO Board Temperature	-128~127	°C	

View IO Board Temperature.

Par. No.	Name	Range	Unit	Default
C16.34	IGBT Temperature	-128~127	°C	

View the temperature of drive's IGBT Temperature.

Par. No.	Name	Range	Unit	Default
C16.35	Drive Thermal	0~255	%	

View calculated drive thermal load, which is set as a percentage of estimated drive thermal load.

Par. No.	Name	Range	Unit	Default
C16.36	Drive Nominal Current	0.0~6553.5	А	

View the drive nominal current.


Par. No.	Name	Range	Unit	Default
C16.37	Drive Max. Current	0.0~6553.5	А	

View the drive maximum current.

Par. No.	Name	Range	Unit	Default
C16.38	Simple PLC State	0~255		

View the state of the event under execution by the simple SLC.

#### C16.4\* Application Message



Par. No.	Name	Range	Unit	Default
C16.40	Wobble Length	0.000~60.000	km	

View the current wobble length.

Par. No.	Name	Range	Unit	Default
C16.48	Power Board Temperature	-128~127	°C	

View the rectifier temperature, only active in >=90kW model.

Par. No.	Name	Range	Unit	Default
C16.49	Rectifier Temperature	-128~127	°C	

View the rectifier temperature, only active in >=90kW model.

#### C16.5\* Ref./Feedb.

Par. No.	Name	Range	Unit	Default
C16.50	Main Reference	-200.0~200.0	%	

View sum of all external references in percentage.

Par. No.	Name	Range	Unit	Default
C16.51	Pulse Reference	-200.0~200.0	%	

View pulse input converted to a reference in percentage.

Par. No.	Name	Range	Unit	Default
C16.52	Feedback	-4999.000~4999.000		

View the feedback value.

#### C16.6\*, C16.7\* Inputs and Outputs

Par. No.	Name	Range	Unit	Default
C16.60	Digital Input	0~65535		

View signal states from active digital inputs, which indicates in a 16-bit binary code. If the drive detects digital input terminals connected, the corresponding position is set to "1", otherwise "0". Digital input terminal and the corresponding relationship between the binary code are as below:

Binary	Term. No.						
bit0	FOR	bit4	DI3	bit8	Reserved	bit12	Reserved
bit1	REV	bit5	Reserved	bit9	Reserved	bit13	Reserved
bit2	DI1	bit6	Reserved	bit10	Reserved	bit14	Reserved
bit3	DI2	bit7	Reserved	bit11	Reserved	bit15	Reserved



Par. No.	Name	Range	Unit	Default
C16.61	Townsin al MI Cottine	0: 0~20mA		
	Terminal VI Setting	1: 0~10V		

View actual state of analog input VI.

Par. No.	Name	Range	Unit	Default
C16.62	Analog Input VI	0.00~20.00	V/mA	

View actual input voltage or current value on analog input VI.

Par. No.	Name	Range	Unit	Default
C16.63	Townsing 1 AT Cotting	0: 0~20mA		
	Terminal AI Setting	1: 0~10V		

View actual state of analog input AI.

Par. No.	Name	Range	Unit	Default
C16.64	Analog Input AI	0.00~20.00	V/mA	

View actual input voltage or current value on analog input AI.

Par. No.	Name	Range	Unit	Default
C16.65	Analog Output VO	0.00~20.00	V/mA	

View actual output voltage or current on analog output VO.

Par. No.	Name	Range	Unit	Default
C16.66	Digital Output	0~255		


View actual state of digital output, which indicates in a 4-bit binary code; If the digital output terminal is active, the corresponding position is set to "1", otherwise "0". Corresponding relationship between state of the digital output terminals and the binary code are as below:

Binar	у	bit3	bit2	bit1	bi	t0
Term. N	No.	Reserved	Reserved	DO2	D	D1
Par. No.	Par. No. Name		Range		Unit	Default
C16.68 Pulse Input DI3		0.00~100.00		kHz		

View input frequency on pulse input terminal DI3.

Par. No.	Name	Range	Unit	Default
C16.69	Pulse Output DO1	0.00~100.00	kHz	

View output frequency on pulse output terminal DO1.



# HOLIP

Par. No.	Name	Range	Unit	Default
C16.71	Relay Output	0~65535		

View the output status of the relay, the corresponding bit is set to "1"when the relay output is active, otherwise it will be set to "0".

Binary	Bit1	Bit0
Item. No.	Relay 2	Relay 1

Par. No.	Name	Range	Unit	Default
C16.72	Counter A	0~65535		

View present value of counter A.

Par. No.	Name	Range	Unit	Default
C16.73	Counter B	0~65535		

View present value of counter B.

#### C16.8\* Field bus/FC Port

Par. No.	Name	Range	Unit	Default
C16.86	Communication Reference	-32768~32767		

View the last received reference from communication.

#### C16.9\* Diagnosis Readouts

Par. No.	Name	Range	Unit	Default
C16.90	Alarm Word 1	0~0xFFFFFFFFUL		
C16.91	Alarm Word 2	0~0xFFFFFFFFUL		
C16.92	Warning Word 1	0~0xFFFFFFFFUL		
C16.93	Warning Word 2	0~0xFFFFFFFFUL		

View the alarm/warning word sent via the serial communication port in hex code. Convert this parameter to a 32-bit binary code, definition of the bits in word showed in the table below, among which that reserved by manufacturers are undefined bits:

Bit	Alarm Word 1	Alarm Word 2	Warning Word 1	Warning Word 2
Dit	C16.90	C16.91	C16.92	C16.93
0	Brake Detect	Undefined	Undefined	Undefined
1	Power Card Over	Undefined	Power Card Over	Undefined
	Temp.	Undennied	Temp.	Ondenned
2	Earth Fault	Trip	Earth Fault	Undefined



Bit	Alarm Word 1 C16.90	Alarm Word 2 C16.91	Warning Word 1 C16.92	Warning Word 2 C16.93
3	Reserved	Option Part	Undefined	Undefined
4	Control Card Temp	Undefined	Control Card Temp	Undefined
5	Over Current	Undefined	Over Current	Undefined
6	Torque Limit	Undefined	Undefined	Undefined
7	Motor Over Thermal	Undefined	Motor Over Thermal	Undefined
8	Motor Over Thermal ETR	Damaged Part	Motor Over Thermal ETR	Damaged Part
9	Drive Overload	Undefined	Drive Overload	Undefined
10	Under Volt	Undefined	Under Volt.	Undefined
11	Over Volt	Undefined	Over Volt.	Undefined
12	Short Circuit	External Interlock	Undefined	Undefined
13	Undefined	Undefined	Undefined	Undefined
14	Mains Ph. Loss	Undefined	Mains Ph. Loss	Undefined
15	AMA Error	Undefined	No Motor	Undefined
16	Live Zero Error	Undefined	Live Zero Error	Undefined
17	Internal Fault	Undefined	Undefined	Undefined
18	Brake Overload	Fan Fault	Brake Overload	Fan Fault
19	U Phase Loss	Undefined	Undefined	Undefined
20	V Phase Loss	Undefined	Undefined	Undefined
21	W Phase Loss	Undefined	Undefined	Undefined
22	Undefined	Undefined	Undefined	Undefined
23	Control Voltage Fault	Undefined	Undefined	Undefined
24	Undefined	Undefined	Vdd Supply Low	Undefined
25	VDD Supply Low	Undefined	Current Limit	Undefined
26	Brake Resistor Error	Undefined	Undefined	Undefined
27	Brake Transistor Fault	Undefined	Undefined	Undefined
28	Bake Transistor Open Circuit	Undefined	Undefined	Undefined
29	Drive Initialize	Feedback Error	Undefined	Feedback Error




Bit	Alarm Word 1	Alarm Word 2	Warning Word 1	Warning Word 2
ы	C16.90	C16.91	C16.92	C16.93
30	Undefined	Undefined	Overload DO1	Undefined
31	Mech. Brake Low	Undefined	Overload DO2	Undefined

# 6.14 Group 39: Communication User-Defined Par.

Par. No.	Name	Range	Unit	Default
C39.00	Communication User- Defined Par. 0	0~9999		310
C39.01	Communication User- Defined Par. 1	0~9999		310
C39.02	Communication User- Defined Par. 2	0~9999		310
C39.03	Communication User- Defined Par. 3	0~9999		310
C39.04	Communication User- Defined Par. 4	0~9999		310
C39.05	Communication User- Defined Par. 5	0~9999		310
C39.06	Communication User- Defined Par. 6	0~9999		310
C39.07	Communication User- Defined Par. 7	0~9999		310
C39.08	Communication User- Defined Par. 8	0~9999		310
C39.09	Communication User- Defined Par. 9	0~9999		310
C39.10	Communication User- Defined Par. 10	0~9999		310
C39.11	Communication User- Defined Par. 11	0~9999		310
C39.12	Communication User- Defined Par. 12	0~9999		310

Par. No.	Name	Range	Unit	Default
C39.13	Communication User- Defined Par. 13	0~9999		310
C39.14	Communication User- Defined Par. 14	0~9999		310
C39.15	Communication User- Defined Par. 15	0~9999		310
C39.16	Communication User- Defined Par. 16	0~9999		0
C39.17	Communication User- Defined Par. 17	0~9999		0
C39.18	Communication User- Defined Par. 18	0~9999		0
C39.19	Communication User- Defined Par. 19	0~9999		0
C39.20	Communication User- Defined Par. 20	0~9999		0
C39.21	Communication User- Defined Par. 21	0~9999		0
C39.22	Communication User- Defined Par. 22	0~9999		0
C39.23	Communication User- Defined Par. 23	0~9999		0
C39.24	Communication User- Defined Par. 24	0~9999		0
C39.25	Communication User- Defined Par. 25	0~9999		0
C39.26	Communication User- Defined Par. 26	0~9999		0
C39.27	Communication User- Defined Par. 27	0~9999		0
C39.28	Communication User- Defined Par. 28	0~9999		0
C39.29	Communication User- Defined Par. 29	0~9999		0



Par. No.	Name	Range	Unit	Default
C39.30	Communication User- Defined Par. 30	0~9999		0
C39.31	Communication User- Defined Par. 31	0~9999		0
C39.32	Communication User- Defined Par. 32	0~9999		0
C39.33	Communication User- Defined Par. 33	0~9999		0
C39.34	Communication User- Defined Par. 34	0~9999		0
C39.35	Communication User- Defined Par. 35	0~9999		0
C39.50	Communication User- Defined Par. 0 index	0~9999		0
C39.51	Communication User- Defined Par. 1 index	0~9999		1
C39.52	Communication User- Defined Par. 2 index	0~9999		2
C39.53	Communication User- Defined Par. 3 index	0~9999		3
C39.54	Communication User- Defined Par. 4 index	0~9999		4
C39.55	Communication User- Defined Par. 5 index	0~9999		5
C39.56	Communication User- Defined Par. 6 index	0~9999		6
C39.57	Communication User- Defined Par. 7 index	0~9999		7
C39.58	Communication User- Defined Par. 8 index	0~9999		8
C39.59	Communication User- Defined Par. 9 index	0~9999		9
C39.60	Communication User- Defined Par. 10 index	0~9999		10

Par. No.	Name	Range	Unit	Default
C39.61	Communication User- Defined Par. 11 index	0~9999		11
C39.62	Communication User- Defined Par. 12 index	0~9999		12
C39.63	Communication User- Defined Par. 13 index	0~9999		13
C39.64	Communication User- Defined Par. 14 index	0~9999		14
C39.65	Communication User- Defined Par. 15 index	0~9999		15
C39.66	Communication User- Defined Par. 16 index	0~9999		0
C39.67	Communication User- Defined Par. 17 index	0~9999		0
C39.68	Communication User- Defined Par. 18 index	0~9999		0
C39.69	Communication User- Defined Par. 19 index	0~9999		0
C39.70	Communication User- Defined Par. 20 index	0~9999		0
C39.71	Communication User- Defined Par. 21 index	0~9999		0
C39.72	Communication User- Defined Par. 22 index	0~9999		0
C39.73	Communication User- Defined Par. 23 index	0~9999		0
C39.74	Communication User- Defined Par. 24 index	0~9999		0
C39.75	Communication User- Defined Par. 25 index	0~9999		0
C39.76	Communication User- Defined Par. 26 index	0~9999		0
C39.77	Communication User- Defined Par. 27 index	0~9999		0

# HOLIP

Par. No.	Name	Range	Unit	Default
C39.78	Communication User- Defined Par. 28 index	0~9999		0
C39.79	Communication User- Defined Par. 29 index	0~9999		0
C39.80	Communication User- Defined Par. 30 index	0~9999		0
C39.81	Communication User- Defined Par. 31 index	0~9999		0
C39.82	Communication User- Defined Par. 32 index	0~9999		0
C39.83	Communication User- Defined Par. 33 index	0~9999		0
C39.84	Communication User- Defined Par. 34 index	0~9999		0
C39.85	Communication User- Defined Par. 35 index	0~9999		0

## 6.15 Group 29: winding and unwinding related parameters

Par. No.	Name	Range	Unit	Default
C29.00	Control mode	0: Winding 1: Unwinding		0

#### [0]: Winding.

The roll diameter increases gradually. To keep the linear speed constant and the motor speed shall be decreased gradually; To keep the tension constant, the motor torque shall be increased gradually;

### [1]: Unwinding.

It can be understood as the inverse process of winding. The unwinding section is generally drawn by the constant linear speed of the intermediate drawing and the unwinding motor is under the power generation status. When the frequency converter is used for unwinding, the power generation issue shall be considered. The common methods: the unwinding frequency converter and the winding frequency converter have a common DC bus (+/-UDC) and then apply braking resistance respectively. In some cases, the magnetic Power controller is required for unwinding. Application of common DC bus, it is necessary to confirm whether the converter can connect directly to +/-UDC.

Note: when the winding and unwinding is swtiching, the frequency converter can't be running .


Par. No.	Name	Range	Unit	Default
C29.01	Tension control mode	<ol> <li>Close speed loop control;</li> <li>Constant linear speed control;</li> <li>Open torque control;</li> <li>Close torque control;</li> </ol>		0

[0]: Close speed control:

According to the input linear speed and current winding diameter, The frequency converter adjusts the output frequency in real time and performs the synchronous control of linear speed; meanwhile, it receives the feedback information from the swing rod (swing arm) and corrects the speed, to ensure that the swing rod is at the middle position.

Output frequency = Synchronous frequency of linear speed + PID corrected frequency of swing rod


Under the mode, the tension on the material surface is determined by the balance weight on the swing rod.



[1]: Constant linear speed control .

Only the speed control is required and it is suitable for scenarios without swing rod feedback.

Without the correction effects of the swing rod PID, the frequency converter can output the matching synchronous speed only based on linear speed and winding diameter, instead of the actual tightness degree of materials.




[2]: Open torque control;

The frequency converter outputs the matching torque according to the "winding diameter" and "tension setting", to ensure the stability of material tension.

Under the mode, two issues shall be considered: the difference of equipment friction under different speeds; hindrance caused by equipment and material inertia during system acceleration and deceleration. When the PLC does not compensate for the torque of these items, open c29.6x and x29.7x instead.

For some materials, their surface tension shall decrease as the winding diameter increases, to ensure winding and forming. At this time, the tension taper can be started. See c29.59-c29.62.

For the scenarios requiring high accuracy control, especially for the applications requiring the accurate control of torque below 5HZ, it is recommended to add a high-resolution encoder and auxiliary frequency converter for torque control.




æ

1 HOLIP

The frequency converter receives the pressure feedback signal under torque control, to form the torque PID control. i.e. PID control under torque mode.





Par. No.	Name	Range	Unit	Default
C29.02	Mechanical gear ratio	0.01 ~ 100.00		1.00

Function: Mechanical transmission ratio = Motor speed/Reel speed = Reel diameter/Motor shaft diameter = Reel mechanical gear numbers / Mechanical gear number of motor shaft .

Linear speed related parameters

Par. No.	Name	Range	Unit	Default
		0: Digital setting		
C20.06	Timory anonal patting parage	1: Terminal VI		1
C29.06	Linear speed setting source	2: Terminal AI		1
		8: Pulse input		

Function: select source to abtain line peed

Par. No.	Name	Range	Unit	Default
C29.07	Minimum linear speed for	0.1 ~ 5000.0	m/min	200
029.07	calculation of roll diameter	0.1 5000.0	111, 11111	200

Function:



Set the minimum speed to start the calculation of the roll diameter.

When the frequency converter detects that the linear speed is less than the value, it will stop the calculation of the roll diameter. The correct setting of this value can effectively prevent the calculation deviation of the roll diameter at low speed.

Par. No.	Name	Range	Unit	Default
C29.08	Maximum linear speed	0.1 ~ 5000.0	m/min	1000

Function:

Maximum value of the linear speed setting. When C29.06 is set to [1],[2]or[3], we need set the value correctly. The maximum value of the analog or pulse input corresponds to this value. C6.15 and C6.25 will be invalid and is replaced by the parameter.

Par. No.	Name	Range	Unit	Default
C29.09	Digital line speed	0.1 ~ 5000.0	m/min	0

Roll diameter calculation related parameters:

Par. No.	Name	Range	Unit	Default
		0: Digital setting		
		1: Terminal VI		
C20 12	Roll diameter calculation	2: Terminal AI		20
C29.12	methods selection	8: Pulse input		30
		30: Calculate by linear speed		
		31: Calculate by material thickness		

Function:

The roll diameter of options [1]-[11] is obtained by external measurement or calculation and then input into the frequency converter.

The roll diameter of options [30] and [31] is obtained through calculation of the frequency converter. The calculation of roll diameter through linear speed must be used with the tension PID; the calculation of roll diameter through material thickness shall refer to the parameter group C29.22-C29.28 of the roll winding diameter calculated through thickness.

Par. No.	Name	Range	Unit	Default
C29.13	Minimum roll diameter	1~1000	mm	100

Function:

Diameter size for empty reels. The diameter of the converter itself is limited by the parameter and won't be less than this value.



Par. No	Name	Range	Unit	Default
C29.14	Maximum roll diameter	1~1000	mm	500

Function:

Diameter size for a full reel. When Par. C29.12 is set to [1]-[11], the maximum input corresponds to the maximum roll diameter.

When C29.12 is selected as [30]-[31], the value won't be used for calculation. However, it will limit the diameter of the converter calculated diameter limit;

Note: value of parameter C29.13  $\leq$  setting value of C29.14.

Par. No.	Name	Range	Unit	Default
		[0]: Digital setting(29.16);		
C20.15	T.: 141.1	[1]: Terminal VI		0
C29.15	C29.15 Initial roll diameter source	[2]: Terminal AI		0
		[8]: Pulse input		

Function: setting mode of initial roll diameter when the roll diameter is reset.

Par. No.	Name	Range	Unit	Default
C29.16	Initial roll diameter	0~1000	mm	100

Function:

When C29.24 is set to [0], The parameter sets the diameter size when the diameter is reset.

The parameter is a 4-digit array and is selected by two multi-purpose digital terminals.

For example:

If we select two digital terminals([DI1][DI2]), C05.12 is set to [81], C05.13 is set to [82];

The selection relationship of initial roll diameter is as follows:

Note: this function can be used when it is not necessary to calculate the initial winding diameter from the minimum diameter.

The default value of initial roll diameter is C29.22.

Initial roll diameter source of DI2 (bit1) DI1(bit0)

- 0 0 corresponds to 29.16[0].
- 0 1 corresponds to 29.16[1].
- 1 0 corresponds to 29.16[2].
- 1 1 corresponds to 29.16[3].

Par. No.	Name	Range	Unit	Default
C29.17	Roll diameter filter time	0.0~100.0	S	2.0

#### Function:

the proper setting value can increase the system stability, especially when the roll diameter is calculated through the linear speed.

Par. No.	Name	Range	Unit	Default
C29.18	Roll diameter variation ratio	0~300	mm	0

Function: Maximum permissive value of roll diameter variation within fixed time.

Par. No.	Name	Range	Unit	Default
C29.19	Digital roll diameters	0~1000	mm	100

Function: Related parameters of roll diameter calculated through material thickness

Par. No.	Name	Range	Unit	Default
C29.22	Pulses per turn	0.001 ~60.000	K	0.100

Function: number of pulse feedback for each revolution of the reel.

Par. No.	Name	Range	Unit	Default
C29.23	Turns per layer	0.001 ~10.000	K	0.001

Function: number of reel revolutions for each full layer of materials winded on the reel. It is generally used for wire materials.

Par. No.	Name	Range	Unit	Default
C29.24	Minimum thickness	0.01~100.00	mm	1.00

Function: Minimum material thickness.

When parameter C29.24 is set to [1],[2],[8]; the value corresponds to the minimum value of analog or pulse input.

Par. No.	Name	Range	Unit	Default
C29.25	Maximum thickness	0.01~100.00	mm	50.00

Function: Maximum material thickness.

When parameter C29.26 is set to [1],[2],[8]; the value corresponds to the maximum value of analog or pulse input.

Par. No.	Name	Range	Unit	Default
		0: Digital setting		
C29.26	Material thickness setting	1: Terminal VI		0
	source	2: Terminal AI		0
		8: Pulse input		

# HOLIP

Function: When [0] is selected, it is the setting value of parameter 29.27.

Par. No.	Name	Range	Unit	Default
C29.27	Initial thickness	0.01 ~100.00	mm	0.01

Function: Material thickness size at digital setting.

The parameter is a 4-digit array. The terminal selects the thickness setting through the material thickness. Refer to options [163] and [164] of parameter group C05.1\* for related settings.

Par. No.	Name	Range	Unit	Default
		0: Digital setting		
C29.28	Accumulative signal source	7: Encoder input		0
C29.28	of roll diameter	8: Pulse input;		0
		32: Angular speed calculation		

Function: select the source mode of roll diameter accumulative signal.

Options:

- [0]: Digital input. Select any one DI terminal and set it to [60]: counter A;
- [7]: Encoder input;
- [8]: Pulse input;
- [32]: Angular speed calculation. The angular speed is the number of winding revolutions calculated by the number motor revolutions counted by the speed of motor inside the frequency converter divided by the mechanical drive ratio;

Par. No.	Name	Range	Unit	Default
		0: Invalid		
		1: According to the broken line		
		proximity switch		
C29.32		2: According to the swing rod		0
	detection Function	feedback		
		3: According to the roll diameter		
		variation		

Function: select broken line detection mode.

- [0]: Not detection;
- According to the broken line proximity switch. The sensor input is required. Select [165] for terminal DI;
- [2]: According to the swing rod feedback; the alarm is initiated when the percentage of swing rod position is less than the error range set by C29.34;
- [3]: According to the roll diameter variation; the alarm is initiated when the winding diameter variation exceeds the error range set by C29.42;



Par. No.	Name	Range	Unit	Default
C29.33	Broken material auto detection low line speed	0.1 ~5000.0	m/min	200

Function: the broken material detection begins when the speed is higher than the value.

Par. No.	Name	Range	Unit	Default
C29.34	Broken material detection error range	0.1~50.0	%	10

Function: set the error range of the detection signal. The converter will initiate the broken material alarm when error range is less than or greater than the value. The value shall be set according to the customer's actual usage conditions.

Par. No.	Name	Range	Unit	Default
C29.35	Broken material detection judgment delay	0.1~60.0	s	2.0

Function: when the broken material detection is enabled, the running frequency exceeds the minimum detection frequency and the start time exceeds the setting time, the broken material trigger event occurs and the duration exceeds the delay time, which can be judged as disconnection. The frequency converter will report the disconnection failure and perform the corresponding action.

Par. No.	Name	Range	Unit	Default
C29.36	Broken material detection start delay	0~20	s	6.0

Function: The broken material detection is performed when the converter running time exceeds the value. The function is used for preventing the broken material sensor or the swing rod from locating abnormally at the beginning of the operation.

Par. No.	Name	Range	Unit	Default
	Borken material action	0: Coast and alarm		
C29.37		1: Stop and alarm		0
	selection	2: Only alarm		

Function: select the action mode in case of broken material.

Par. No.	Name	Range	Unit	Default
C20.28	Broken material	0: Invalid		0
C29.38	Automatic reset	1: Valid		0

Function: when the parameter is valid, see the function description of parameter C29.39.



Par. No.	Name	Range	Unit	Default
C29.39	Broken material automatic reset time	0.0~100.0	S	6.0

Function: When C29.38 is set to [1], when the duration of the broken material exceeds this value The alarm will invalid;

PID Related Parameters

Par. No.	Name	Range	Unit	Default
		0: Only the first group PID parameter		
	PID automatic adjustment	1: According to the roll diameter		
C29.43	,	2: According to the running		0
	basis	frequency		
		3: According to the linear speed		

Function: select the basis for automatic adjustment of PID parameter.

[0]: Only group 1 parameters is used;

[1]: According to the roll diameter.

Use the first PID parameter group for empty reel and use the second PID parameter group for full reel. The PID parameter varies constantly when reaching the middle of the reel;

[2]: According to the running frequency.

Use the first PID parameter group at zero speed and use the second PID parameter group at the maximum frequency. The PID parameter varies constantly when reaching the middle of the reel;

[3]: According to the linear speed.

Use the first PID parameter group at zero speed and use the second PID parameter group at the maximum linear speed. The PID parameter varies constantly when reaching the middle of the reel; Note:

PID automatically adjust the parameters in roll diameter changes or speed changes, PID coefficient of linear adjustment to adapt to changes;

C07.33, C07.34 and C07.35 PID control is a two-dimensional array, the array [1] PID switch using winding function of double linear, non winding function can only use an array of [0] parameters.

Par. No.	Name	Range	Unit	Default
C29.44 PID initial targe		0: Fixed		
	DID initial tanget out made	1: According to the current feedback		
	PID mitial target set mode	2: According to the setting value		0
		3: Use PD function at the beginning		

Options:



- [0]: Fixed, the starting target value is consistent with the actual value;
- [1]: According to the current feedback;
- [2]: According to the setting value, see parameter C29.45
- [3]: Use PD function at the beginning;

#### Note:

the winding shall be stable at the beginning and the operation response shall be fast. For setting the initial PID target value under mode [1] and mode [2], the setting target shall be close to the actual position to minimize the accumulative deviation.

Mode [3]: use PD function at the beginning. If the initial deviation is very large, the I integral term will accumulate very large, and it will swing to the equilibrium. If the integral time is increased, it will not meet the requirement of fast response at running. Therefore, only use PD adjustment at start-up; when the PD regulation runs to a deviation within the given value bandwidth, the PID start adjustment will end and go into the normal process.

Note: the function is only valid at the start-up phase and will become invalid during the normal adjustment.

Par. No.	Name	Range	Unit	Default
C29.45	PID initial setting	0.0~200.0	%	100.0

Function: The user sets the initial value of PID.

Par. No.	Name	Range	Unit	Default
C29.46	Transition time of PID initial setting	0.1~6000.0	S	5.0
Par. No.	Name	Range	Unit	Default
C29.50	Brake holding output frequency	0.0~50.0	Hz	1.5

Function: Output the brake signal when the output frequency is less than this value during deceleration.

Par. No.	Name	Range	Unit	Default
C29.51	Brake holding time	0.1~100.0	S	1.0

Function: duration of brake signal.

Par. No.	Name	Range	Unit	Default
C29.52	Jog action during running	0: No action;		0
	Jog action during running	1: Coast, and output the brake signal		0

Function: for the winding function. Jog

#### Tension setting related parameters

Par. No.	Name	Range	Unit	Default
C29.55 Tension setting sour		0: Digital setting		
		1: Terminal VI		0
	Tension setting source	2: Terminal AI		0
		8: Pulse input		

Function: select tension setting source.

Options:

- [0]: Digital setting. See the setting value of parameter C29.56;
- Terminal VI, use the analog input terminal VI as the setting source. See parameter value C06.1\*;
- [2]: Terminal AI, use the analog input terminal AI as the setting source. See parameter group C06.2\*;
- [8]: Pulse input, use the pulse input (DI3) as the setting source. See parameter group C05.5\*;
- [11]. Local bus, use the local bus as the setting source. See parameter group C08.9\*;

Par. No.	Name	Range	Unit	Default
C29.56	Digital tension setting	0~50000	Ν	0

Function: When C29.55 is set to [0], the parameter is used for setting the system tension value.

Par. No.	Name	Range	Unit	Default
C29.57	Maximum tension	0~50000	Ν	0

Function: set the upper limit of the system tension. The setting value of C29.56 shall not be greater than the value. The maximum value of the analog quantity or pulse input corresponds to the parameter's setting value.

Par. No.	Name	Range	Unit	Default
C29.58	Tension lifting at zero speed	0.0~100.0	%	0

Par. No.	Name	Range	Unit	Default
C29.59 Tension taper so		0: Digital setting		
		1: Terminal VI		0
	Tension taper source	2: Terminal AI		0
		8: Pulse input		

Function: Source of setting for taper compensation coefficient.

Options:



[0]: Digital setting. See the setting value of parameter C29.60;

[1]: Terminal VI;

- [2]: Terminal AI;
- [8]: Pulse input;
- [11]. Local bus;

Note: The parameter is only suitable for winding control. During the winding control, the tension shall decrease as the winding diameter increases at some time, to ensure good winding and forming of the materials.

The formula of tension taper is as follows:


 $F=F0^{1-K^{1-(D0+Dk)/(D+Dk)]}$ 

F: actual tension; F0: setting tension; K: tension taper; D0: reel diameter;

Dk: taper compensation correction; D: actual roll diameter.

The tension output curve is as shown in the following graph:

The roll diameter range C29.61 corresponds to the winding diameter D0-D9



Р	ar. No.	Name	Range	Unit	Default
	C29.60	Digital taper setting	0.00~100.00	%	0

Note: the parameter is an array composed of 10 elements, which represents the taper setting value

HOLIP

of each taper compensation section.

Par. No.	Name	Range	Unit	Default
C29.61	Start of winding diameter range	0.001~10.000	m	10.000

Note: the parameter is an array composed of 10 elements, which represents the initial value of winding diameter of each taper compensation section.

Par. No.	Name	Range	Unit	Default
C29.62	Taper compensation	0.001~10.000	m	0
	correction	0.001-10.000		0

Related parameters of tension compensation

Par. No.	Name	Range	Unit	Default
C29.66	Mechanical inertia	0.00 ~ 600.00	Kg.m2	0
	compensation coefficient	0.00 ~ 800.00	Kg.III2	0

Function: set the initial mechanical rotational inertia, including the inertia of motor, drive part and reel.

Par. No.	Name	Range	Unit	Default
C29.67	Material density	0~60.000	Kg.m3	0
Par. No.	Name	Range	Unit	Default
C29.68	Material width	0~60.000	m	0

Function: these two parameters are related to the material inertia compensation and the converter calculates the material inertia compensation value according to the parameters and roll diameter automatically.

Par. No.	Name	Range	Unit	Default
C29.69	Full-reel material inertia compensation coefficient	0.00~600.00	Kg.m2	0
Par. No.	Name	Range	Unit	Default
C29.70	Frequency of zero speed	0.0 ~ 50.0	Hz	0.0

Function: when the operating speed of the frequency converter is less than the setting speed of the parameter, the frequency converter is deemed as at the standstill state and the tension compensation set by c29.71 works.



Par. No.	Name	Range	Unit	Default
C29.71	Static friction	0.00~100.00	%	0
	compensation coefficient	0.00~100.00	70	0

Function: set the tension at zero speed. It is mainly used to overcome the static friction at startup or maintain a certain tension at zero speed. The setting value of the parameter can be increased properly in case of little tension control and difficult start-up.

Par. No.	Name	Range	Unit	Default
C29.72	Dynamic friction frequency	0.00~100.00	Hz	50.0
Par. No.	Name	Range	Unit	Default
C29.73	Dynamic friction compensation coefficient	0.00~100.00	%	0

Function: set the dynamic friction compensation coefficient. The material tension becomes smaller due to friction resistance and the effects are much more significant for small reels, meanwhile the tension is not linear. These issues can be improved by setting the parameter.

Par. No.	Name	Range	Unit	Default
C29.74	Inertia self-learning torque 1	0.00~100.00	%	25
DN	N	D.	TT 14	DCK
Par. No.	Name	Range	Unit	Default
C29.75	Inertia self-learning torque 2	0.00~100.00	%	45
Par. No.	Name	Range	Unit	Default
		0: Invalid		
C29.76	Compensation value self-	1: Friction self-learning		0
C29.76	learning	2: Mechanical inertia self-learning		0
		3: Material inertia self-learning		

Par. No.	Name	Range	Unit	Default
C29.78	Minimum linear acceleration	0.00~10.000	m/min	0.00
Par. No.	Name	Range	Unit	Default
C29.79	Deceleration mechanical inertia ratio	0~200	%	100



Par. No.	Name	Range	Unit	Default
C29.81	Reverse running	0~1		0
Par. No.	Name	Range	Unit	Default
C29.83	Terminal tension lifting ratio	0.0~200.0	%	50

Note: Terminal tension lifting ratio. The actual lifting tension is the set tension multiplied by the ratio. DI terminal determines whether the tension lifting is valid.

Pre-drive control related parameters

Par. No.	Name	Range	Unit	Default
C29.84	Pre-drive speed gain	-100.00~100.00	%	0.00
Par. No.	Name	Range	Unit	Default
C29.85	Pre-drive end delay time	0.0~20.0	s	1.0
Par. No.	Name	Range	Unit	Default
C29.87	Frequency limit gain of linear speed	-50.0~50.0	%	0.0
Par. No.	Name	Range	Unit	Default
C29.88	Frequency limit gain of linear speed	-30.0~30.0	Hz	0.0
Par. No.	Name	Range	Unit	Default
C29.91	Input line speed	0~4096	m/min	
C29.92	Current roll diameter value	0~10000	mm	
C29.93	Actual tension value (After taper calculation)	0~50000	N	

Digital input terminal (FOR, REV, DI1, DI2, DI3)



Par. No.	Name	Range	Unit	Default
C05.10~ C05.14	Digital input terminal	<ul> <li>160: Diameter select bit0:</li> <li>161: Diameter select bit1;</li> <li>162: Diameter calculation suspend:</li> <li>163: Material thickness bit0:</li> <li>164: Material thickness bit1:</li> <li>165: Broken line signal input:</li> <li>166: Winding start:</li> <li>167: Tension lifting</li> <li>168: Broken line reset:</li> <li>169: Roll diameter reset:</li> <li>170: Pre-drive start</li> <li>171: Winding and unwinding swith</li> <li>172: PID suspend</li> <li>173: Reverse running</li> </ul>		



# Chapter 7 Quick Application Guide

### 7.1 Using LCP to Start/Stop the Drive


- 1. Press "HAND" key on LCP to start the drive;
- 2. Turn the potentiometer to change output frequency;
- 3. Press "OFF" key on LCP to stop the drive;

## 7.2 Using Digital Input Terminals to Start/Stop the Drive

Usually there are four mode for using digital input terminals to start/stop the drive. No matter what mode, press "AUTO" key on LCP first.

### 7.2.1 Two-line Mode 1


It is the most commonly used two-line mode, in which the forward/reverse rotation of the motor is decided by FOR and REV. Wiring and parameters are set as below:



K1	K2	Command	
OFF	OFF	Stop	
ON	OFF	Run forward	
OFF	ON	Run reverse	
ON	ON	Stop	

### 7.2.2 Two-line Mode 2

In this mode, FOR is run enabled terminal, and REV determines the running direction. Wiring and parameters are set as below:




K1	K2	Command
OFF	OFF	Stop
ON	OFF	Run forward
OFF	ON	Stop
ON	ON	Run reverse

æ

HOLIP


#### 7.2.3 Three-line Mode 1

In this mode, FOR is run enabled terminal, and the direction is decided by DI1 and DI2. Wiring and parameters are set as below:



#### 7.2.4 Three-line Mode 2


In this mode, FOR is run enabled terminal. The RUN command is given by DI1 and the direction is decided by DI2. Wiring and parameters are set as below:



SB1	SB2	SB3	Command
OFF	×	×	Stop
ON		OFF	Run forward
ON		ON	Run reverse

## 7.3 Multi-speed

In scenarios where the running frequency of the drive need not be adjusted continuously and only several frequencies are required, the multi-speed control can be used. The drive supports a maximum of 8 running frequencies in each set-up, which are implemented by state combinations of four DI terminals. Set the parameter number corresponding to DI terminals to a value among 15 to 17 (Preset ref. bit 0~2), and then the DI terminals are specified as the multi-frequency input terminals. The multiple frequencies are set based on the multi-frequency table in group FC. In addition, you need to set C03.03 (Maximum Reference). The following figure shows how to set the multi-speed function.




In the preceding figure, FOR, REV are set as two-line mode 1, DI1, DI2 and DI3 are used as the multi-frequency input terminals, each of which has a bit value. The state combinations of these terminals correspond to multiple frequencies, When (DI3, DI2, DI1) = (0, 1, 0), the state combination value is 2, corresponding to the value set in C03.10[2]. The target running frequency is automatically calculated by C03.10[2] x C03.03.

The drive supports a maximum of three DI terminals to be used as the multi-frequency input terminals. You can also use less than four DI terminals, and the empty bit is considered to be 0.

## 7.4 Analog Input as the Frequency Source


The VI/AI terminals can be used as the frequency source. The following figure shows how to use the VI as the frequency source.



Attention: Parameters and theirs value in dash box should be set according to the application.

#### 7.5 Pulse Input as the Frequency Source


The DI4 terminal can be used as pulse input. The following figure shows how to use the pulse input as the frequency source.



Attention: Parameters and theirs value in dash box should be set according to the application.

### 7.6 Speed up/down

When you need speed fine tuning at a fixed value, you can use the speed up/down via terminals. The following figures show how to use the function:



#### 7.7 Parameter Initialization

- 1. Set C14.22 = 2;
- 2. Cut off the main power and Re-power on, LCP displays "E.80";
- 3. Press "OFF" key on LCP;

## 7.8 Automatic Motor Adaption (AMA)

- 1. Reboot the drive;
- 2. Enter motor nameplate data to C01.20 to C01.25;
- 3. Choose option [2] in C01.29 to enable AMA;
- 4. LCP displays "PUSH", "HAND", press "HAND" key on LCP, "-AT-" will be displayed;
- 5. Wait for the LCP displays "PUSH", "ENT", press " 🚫 " key, AMA complet.

Note: AMA doesn't fit for rotate motor. Measurements are stored in C01.30, C01.33, and C01.35


### 7.9 Encoder direction estimation

#### 7.9.1 Motor direction estimation

After the converter is power up, press the "HAND" key, and the converter runs to the panel potentiometer to give a frequency,Observe whether the motor rotates in correct directions. When the motor is in the right direction, monitor the C16.67. If it is negative, the encoder direction is opposite to that of the motor. The C5.71 encoder is set to 1; if it is positive, the encoder direction is the same as the motor.

### 7.10 Speed mode applicaton scheme

#### 7.10.1 Close speed(start/stop, Analog setting frequency)



1.PLC supplys start signal and speed signal(0~10v)

No.	Par No.	Setting value	Explanation
Control Parameters	C01.00	1	Close speed loop control when motor is with encoder




No.	Par No.	Setting value	Explanation
	C01.20	Motor nameplate	Motor rated power
Motor	C01.24	Motor nameplate	Motor rated current
Parameters	C01.25	Motor nameplate	Motor rated speed
	C01.29	1	Motor self test
	C03.15	1	Terminal VI(set frequency)
Given channel selection	C03.16	0	Invalid
	C03.17	0	Invalid
Acceleration and deceleration	C03.41	According to actual need set	Acceleration time(unit: S)
time	C03.42	According to actual need set	Deceleration time(unit: S)
Encoder	C05.70	Encoder actual value	Encoder resolution
parameters	C05.71	0	Encoder direction

2. PLC supplys start signal speed signal (-10v  $\sim$  10v), add following parameters

No.	Par No.	Setting value	Explanation
1	C03.00	1	-C03.03 ~ C03.03

## 7.10.2 Close speed loop (start/stop, Analog setting frequency, PID), eg: Used for traction parts



Traction is solely controlled by frequency converter PID (from zero to maximum running frequency)

No.	Par No.	Setting value	Explanation
Control	C01.00	1	Close speed loop control,
Parameters	001.00	1	when motor is with encoder
	C01.20	Motor nameplate	Motor rated Power
Motor	C01.24	Motor nameplate	Motor rated current
Parameters	C01.25	Motor nameplate	Motor rated speed
	C01.29	1	Motor self test
Acceleration and deceleration	C03.41	According to actual need setting	Acceleration time(unit: S)
time	C03.42	According to actual need setting	Deceleration time(unit: S)
Encoder	C05.70	Encoder actual value	Encoder resolution
parameters	C05.71	0	Encoder direction
Analogue setting	C06.29	0	AI: Voltage signal
	C03.10[0]	50	PID Target value
	C03.15	0	Reference source 1
	C03.16	0	Reference source 2
	C03.17	0	Reference source 3
	C07.20	2	AI: PID feedback source
	C07.33[0]	0.3	Process PID Proportional Gain(P)
PID	C07.34[0]	4.0S	Process PID Integral Time(I)
Related parameters	C07.35[0]	0.015	Process PID Differentiation Time(D)
	C07.38	100%	Process PID Feed Forward Factor
	C07.45	1	VI: PID Feed Forward Source
	C07.41	0%	Process PID Output Low
	C07.42	100%	Process PID Output High
	C07.50	0%	I Differentiation Low Limit
	C07.51	100%	I Differentiation High Limit

HOLIP

2. Traction: Main Speed + Auxiliary control mode(The main speed is given by the outside, and the PID output is superimposed with the main speed)


No.	Par No.	Setting value	Explanation
Control	C01.00	1	Close speed loop, when motor is with encoder
parameters	C01.07	3	Winding function
	C01.20	Motor nameplate	Motor Power
Motor	C01.24	Motor nameplate	Motor rated current
Parameters	C01.25	Motor nameplate	Motor rated speed
	C01.29	1	Motor self test
Acceleration and deceleration	C03.41	According to actual need setting	Acceleration time(unit: S)
time	C03.42	According to actual need setting	Deceleration time(unit: S)
FOR Terminal	C05.10	166	Winding start
Encoder	C05.70	Encoder actual value	Encoder resolution
parameters	C05.71	0	Encoder direction
	C06.10	5V	Min voltage
Analogue setting	C06.29	0	AI: Voltage signal
	C07.20	2	AI: PID feedback source
	C03.10[0]	50	PID target value
	C03.15	0	Invalid
	C03.16	0	Invalid
	C03.17	0	Invalid
PID Related	C07.33[0]	0.3	Process PID Proportional Gain(P)
Parameters	C07.34[0]	4.0S	Process PID Integral Time(I)
	C07.35[0]	0.015	Process PID Differentiation Time(D)
	C07.41	-5%	Process PID Output Low
	C07.42	5%	Process PID Output High
	C07.50	-5%	I Differentiation Low Limit
	C07.51	5%	I Differentiation High Limit



No.	Par No.	Setting value	Explanation
	C29.02	Actual value	Mechanical reduction ratio
Application	C29.06	1	VI: Line speed setting source
function	C29.08	m/min	Max line speed;
	C29.14	100mm	Max Roll Diameter

## 7.10.3 Close speed loop (start/stop, Analog setting frequency, PID), eg: Used for traction parts

1.Single position winding(Close Speed Loop+Roll diameter calculation +PID)



#### 1.Single position winding(Close Speed Loop+Roll diameter calculation +PID)

No.	Par No.	Setting value	Explanation
Control parameters	C01.00	1	Close speed loop control, when motor is with encoder
	C01.07	3	Winding function
	C01.20	Motor nameplate	Motor rated power
Motor	C01.24	Motor nameplate	Motor rated current
Parameters	C01.25	Motor nameplate	Motor rated speed
	C01.29	1	Motor self test



No.	Par No.	Setting value	Explanation
Acceleration and deceleration	C03.41	According to actual need setting	Acceleration time(unit: S)
time	C03.42	According to actual need setting	Deceleration time(unit: S)
	C05.10	166	FOR Terminal: Winding start
Terminal Input function	C05.11	169	DI1 Terminal: Roll diameter reset
	C05.15	32	DI3: Pulse input
Encoder	C05.70	Encoder actual value	Encoder resolution
parameters	C05.71	0	Encoder direction
	C06.10	5.0V	Terminal VI Low Voltage
Analogue setting	C06.14	0%	Terminal VI Low Ref./Feedb. Value
	C06.29	0	AI: Voltage signal
	C07.20	2	AI: PID feedback source
	C03.10[0]	50	PID target value
	C03.15	0	Reference source 1 is invalid
	C03.16	0	Reference source 2 is invalid
	C03.17	0	Reference source 3 is invalid
PID	C07.33[0]	0.3	Process PID Proportional Gain(P)
Related Parameters	C07.34[0]	4.05	Process PID Integral Time(I)
	C07.35[0]	0.015	Process PID Differentiation Time(D)
	C07.41	-5%	Process PID Output Low
	C07.42	5%	Process PID Output High
	C07.50	-5%	Process PID Proportional Gain(P)
	C07.51	5%	Process PID Integral Time(I)




No.	Par No.	Setting value	Explanation
Application Funtiong	C29.00	1	Unwinding
	C29.02	Actual value	Mechanical reduction ratio
Line speed	C29.06	8	VI is the line speed setting source
counting related parameters	C29.07	7m/min	Minimum linear speed for calculation of winding diameter
	C29.08	m/min	The maximum frequency corresponds to the line speed
Diameter	C29.14	mm	Max Diameter: Diameter at full roll
counting related	C29.15	1	Initial roll diameter source: VI
parameters	C29.17	2.05	Roll diameter filter time

Double position winding: Close Speed Loop+Roll diameter calculation +PID Add the following parameters on the basis of single position winding

No.	Par No.	Setting value	Explanation
DI2 input	C05.12	170	DI2: pre-drive start
funtion	005.12	170	D12: pre-unive start

#### 7.10.4 Close Speed Loop(Close Speed Loop+Roll diameter calculation +PID)

1. Single position winding: Close Speed Loop+Roll diameter calculation +PID





No.	Par No.	Setting value	Explanation
Control	C01.00	1	Speed closed loop
Parameters	C01.07	3	winding function
	C01.20	Motor nameplate	Motor rated power
Motor	C01.24	Motor nameplate	Motor rated current
Parameters	C01.25	Motor nameplate	Motor rated speed
	C01.29	1	Motor self test
Acceleration and deceleration	C03.41	According to actual need setting	Acceleration time(unit: S)
time	C03.42	According to actual need setting	Deceleration time(unit: S)
Terminal Input	C05.10	166	FOR Terminal: Winding start
Function	C05.11	169	DI1Terminal: Roll diameter reset
Encoder	C05.70	Encoder actual value	Encoder resolution
parameters	C05.71	0	Encoder direction
	C06.10	5.0V	VI Low input voltage
Analog setting	C06.14	0%	Terminal VI Low Voltage
	C06.29	0	Terminal VI Low Ref./Feedb. Value
	C07.20	2	AI: PID feedback source
	C03.10[0]	50	PID target value
	C03.15	0	Reference source 1 is invalid
PID	C03.16	0	Reference source 2 is invalid
Related	C03.17	0	Reference source 3 is invalid
Parameters	C07.33[0]	0.3	Process PID Proportional Gain(P)
	C07.34[0]	4.05	Process PID Integral Time(I)
	C07.35[0]	0.01S	Process PID Differentiation Time(D)
	C07.41	-5%	Process PID Output Low
	C07.42	5%	Process PID Output High
	C07.50	-5%	Process PID Proportional Gain(P)
	C07.51	5%	Process PID Integral Time(I)
Application function	C29.00	0	Winding mode

## 1. Single position winding: Close Speed Loop+Roll diameter calculation +PID




No.	Par No.	Setting value	Explanation
	C29.02	Actual value	Mechanical reduction ratio
Line speed	C29.06	8	VI is the line speed setting source
counting related parameters	C29.07	7m/min	Minimum linear speed for calculation of roll diameter
	C29.08	m/min	The maximum frequency corresponds to the line speed
Diameter counting related	C29.14	mm	Max Diameter: Diameter at full roll
parameters	C29.17	2.05	Winding diameter filter time

2. Double position winding: Close Speed Loop+Roll diameter calculation +PID Add the following parameters on the basis of single position winding

No.	Par No.	Setting value	Explanation
DI2 input funtion	C05.12	170	DI2: pre-drive start
Tuntion			

### 7.11 Torque mode application scheme

The torque mode with speed feedback is mainly used for winding and unwinding parts(Internal diameter calculation is not done for converter)






Parameter settings are as follows:

No.	Par No.	Setting value	Explanation
Control Parameters	C01.00	2	With speed feedback torque control
	C01.20	Motor nameplate	Motor rated power
Motor	C01.24	Motor nameplate	Motor rated current
Parameters	C01.25	Motor nameplate	Motor rated speed
	C01.29	1	Motor self test
	C03.03	50N.M	Maximum tension
Torque	C03.15	2	AI set torque
control related	C03.16	0	Reference source 2 is invalid
parameters	C03.17	0	Reference source 3 is invalid
	C04.21	1	Frequency Upper Limit Source
Acceleration and deceleration	C03.41	According to actual need setting	Acceleration time(unit: S)
time	C03.42	According to actual need setting	Deceleration time(unit: S)
Encoder	C05.70	Encoder actual value	Encoder resolution
parameters	C05.71	0	Encoder direction
Analog setting	C06.29	0	AI Terminal: Voltage signal
Dead compensation	C14.07	75%	Zero speed tension duration, motor jitter. C14.07 changed to 70-100

## 7.11.1 The torque mode with speed feedback is mainly used for winding and unwinding parts(Internal diameter calculation is done for converter)

# HOLIP



Winding (With speed feedback torque control+Diameter counting +Friction and Inertia compensation)

Below Parameters:

No.	Par No.	Setting value	Explanation
Control	C01.00	2	With speed feedback torque control
parameters	C01.07	3	winding function
	C01.20	Motor nameplate	Motor rated power
Motor	C01.24	Motor nameplate	Motor rated current
Parameters	C01.25	Motor nameplate	Motor rated speed
	C01.29	1	Motor self test
	C03.15	0	Reference source 1 is invalid
Ref sourcing	C03.16	0	Reference source 2 is invalid
setting	C03.17	0	Reference source 3 is invalid
Acceleration and deceleration	C03.41	According to actual need setting	Acceleration time(unit: S)
time	C03.42	According to actual need setting	Deceleration time(unit: S)
Speed upper limit	C04.21	1	Frequency Upper Limit Source
Digital input	C05.10	166	FOR Terminal: Winding start
Terminal function	C05.11	169	DI1Terminal: Winding reset

No.	Par No.	Setting value	Explanation
Encoder	C05.70	Encoder actual value	Encoder resolution
parameters	C05.71	0	Encoder direction
Analog setting	C06.29	0	AI Terminal: Voltage signal
Dead compensation	C14.07	75%	Zero speed tension duration, motor jitter. C14.07 changed to 70-100
Application	C29.00	According to the actual use settings	Crimp mode: 0: winding
function	C29.01	2	Tension control mode: torque control
	C29.02	Actual reduction ratio	Mechanical reduction ratio
Line speed	C29.06	1	VI is the line speed setting source
counting related parameters	C29.07	7m/min	Minimum linear speed for calculation of roll diameter
	C29.08	Max Frequency	The maximum frequency corresponds to the line speed
	C29.13	mm	Min Diameter: Drum diameter
Roll diameter related	C29.14	mm	Max Diameter: Diameter at full roll
parameters	C29.16[0]	mm	Drum diameter
	C29.17	2.08	Roll diameter filter time
Turnettersien	C29.55	2	AI is tension setting source
Target tension setting	C29.57	N	Max tension: voltage value corresponding to AI input 10V
Inertia compensation	C29.66	0.4kg.m2	Mechanical inertia compensation coefficient
	C29.69	5.0kg.m2	Full-reel material inertia compensation coefficient
Zero speed	C29.70	1.3Hz	Zero speed frequency: When the frequency of the converter is below this value, 29.71 will

tension

compensation

C29.71

1.0~3.0%

be valid

friction)

Compensation factor at zero

speed (used to overcome static



No.	Par No.	Setting value	Explanation
Friction compensation	C29.72	C29.72 [0]=10Hz C29.72 [1]=20Hz C29.72 [2]=30Hz	Corresponding frequency value of dynamic friction compensation. Firstly set C1.07=0. Set different torque values by C3.10 [0], respectively, and wait for the output frequency to stabilize. The correspondence between the recorded torque value and frequency is recorded.
	C29.73	C29.73 [0]=2.2% C29.73 [1]=4.7% C29.73 [2]=6.4%	The dynamic friction compensation value is based on C03.03



## Chapter 8 Faults and Solutions

#### 8.1 Fault List

The drive has three different fault types: warning, alarm and error. When a fault happens, the drive shows a specific code to indicate it.

When a warning happens, it means that the drive is close to its design limits for some reason, but the drive still works. If the drive fault disappear, the warning will also disappear. When a warning happens, LCP displays "A.XX" (XX is warning code).

An alarm means that the drive has exceeded its design limits for some reason. When this happens, the drive will trip. The driver must be reset in order to re-run. When an alarm happens, LCP displays "E.XX" (XX is alarm code).

When some alarms happen, the drive will lock itself. These alarms are called trip-lock alarm. The Trip-lock alarm offers additional protection, the default setting is that the main power should be cut off before resetting the alarm. But by setting parameter C14.23 = 0, the trip-lock alarm can be reset without cutting the main power off. But there is a risk of accident when choosing this function. Before using this function, it is important to be familiar with the drive and the whole system in order to be safe when dealing with the drive.

Error means the drive is in a state and unable to carry out an operation. When an error happens, LCP display "Er.XX" (XX is error code).

Warning	Alarm	Error	Fault Description	Reason analysis
A.02	E.02		Live Zero Error	Please refer to C06.0 Live Zero Timeout Time.
A.03	E.03		Motor Loss	<ol> <li>Motor cable connection problems;</li> <li>The drive power is greater than the motor power;</li> </ol>
A.04	E.04*		Mains Phase Loss	<ol> <li>Missing phase on supply side;</li> <li>Too high voltage imbalance.</li> </ol>
A.07	E.07		Over Voltage	<ol> <li>The input voltage is too high;</li> <li>An external force drives the motor during acceleration or deceleration;</li> <li>The deceleration time is too short;</li> <li>The braking unit and braking resistor are not installed.</li> </ol>
A.08	E.08		Under Voltage	<ol> <li>Instantaneous power failure occurs on the input power supply;</li> <li>The drive's input voltage is not within the allowable range;</li> <li>The rectifier bridge and buffer resistor are faulty.</li> </ol>

Warning	Alarm	Error	Fault Description	Reason analysis
A.09	E.09		Drive Overload	<ol> <li>The load is too heavy or lockedrotor occurs on the motor;</li> <li>The drive model is of too small power class;</li> <li>C01.** is set improperly.</li> </ol>
A.10	E.10		Motor Overload	<ol> <li>C01.24 is set improperly;</li> <li>The load is too heavy or lockedrotor occurs on the motor;</li> <li>The drive model is of too small power class;</li> <li>C01.** is set improperly.</li> </ol>
	E.11		Motor Over Temperature	Thermistor damage, uncorrectly installed or motor cooling equipment failure.
A.12	E.12*		Torque Limit	Torque exceeds the max. torque limit.
A.13	E.13*		Over Current	<ol> <li>The acceleration time is too short;</li> <li>Manual torque boost or V/F curve is not appropriate;</li> <li>The input voltage is too low;</li> <li>The startup operation is performed on the rotating motor;</li> <li>A sudden load is added during acceleration/ deceleration;</li> <li>The drive model is of too small power class.</li> </ol>
A.14	E.14*		Earth fault	Discharge from output phases to ground (22kW and below)
	E.16*		Short Circuit	Short circuit in motor or on motor terminals.
A.17	E.17		Control Word Timeout	Drive communication timeout, this alarm occurrs when C08.04 is set to 1 or 5.
A.24	E.24		Fan Fault	Too much dust on the fan or the fan is aging.
	E.25*		Brake resistor short- circuit	Brake resistor is short circuit, leading the brake function invalid.
	E.27		Brake transisitor short-circuit	Brake transistor is short circuit leading brake function invalid.
	E.28		Brake Detect	Brake resistor is not connected or working.
	E.30*		Motor phase U missing	Check the phase and motor.

Warning	Alarm	Error	Fault Description	Reason analysis
	E.31*		Motor phase V missing	Check the phase and motor.
	E.32*		Motor phase W missing	Check the phase and motor.
	E.38*		Internal Fault	Contact the local distributor or Holip Company.
	E.44*		Earth Fault	Discharge from output phases to ground (22KW or more).
	E.47*		24V Power Card Fault	24V voltage power card failure
	E.51		AMA check Unom and Inom	Motor voltage and motor current error setting.
	E.52		AMA Low Inom	Motor current is too low,check the settings.
	E.53		AMA Motor is too large	Motor configuration is too large to perform AMA.
	E.54		AMA Motor is too small	Motor configuration is too small , unable to perform AMA.
	E.55		AMA Paremeter Error	Motor parameter is out of the range
	E.56		AMA Interrupt	Interrupted by the user when running AMA.
	E.57		AMA Time-out	AMA takes too long to run.
A.58	E.58		AMA Internal Error	Contact Local distributor or Holip Company.
A.59			Current Limit	Current exceeds value set in C04.18.
	E.61		Encoder fault	
	E.63		Mechenical Brake Current Low	Actual motor current can not exceeds release brake current set in C02.20 within start delay time.
A.69	E.69*		IGBT Over Temperature	<ol> <li>The ambient temperature is too high;</li> <li>The air filter is blocked;</li> <li>The fan is damaged;</li> <li>The thermally sensitive resistor of the IGBT is damaged;</li> <li>The drive IGBT is damaged.</li> </ol>

Warning	Alarm	Error	Fault Description	Reason analysis
A.74	E.74		Rectifier Temperature Sensor Error	Rectifier Temperature Sensor Error
A.75	E.75		Rectifier Temperature High	<ol> <li>The ambient temperature is too high;</li> <li>The air filter is blocked;</li> <li>The fan is damaged.</li> </ol>
A.76	E.76		IGBT Temperature Sensor Error U	IGBT Temperature Sensor Error U
A.77	E.77		IGBT Temperature Sensor Error V	IGBT Temperature Sensor Error V
A.78	E.78		IGBT Temperature Sensor Error W	IGBT Temperature Sensor Error W
	E.80		Parameter Initialization	Make parameter initialized.
	E.83		Power Board Over Temperature	<ol> <li>The ambient temperature is too high;</li> <li>The air filter is blocked;</li> <li>The fan is damaged.</li> </ol>
	E.88*		24V Power Card Fault	24V Power Card Fault
		Er.84	LCP Connection with the drive failed	No communication between LCP and the drive.
		Er.85	Button is disabled	Refer to parameter group C00.4*.
		Er.89	Parameter read-only	Try to write read-only parameter.
		Er.91	Parameter value is invalid	Invalid parameter value to write.
		Err	Unchangbale	Parameter is freezed or can't be changed during running.

Note: Trip-lock alarm is with \*.



## Chapter 9 Maintenance

#### 9.1 Note

Confirm the main circuit power supply has been turned off, and the display has disappeared before carry out inspection and maintenance. Make sure the system is in dynamic state, please pay attention to the following:

- Check whether the power supply voltage matches to the rated voltage of the drive;
- Check whether the motor makes unexpected noises or abnormal vibration when running;
- Check whether there are abnormal heating;
- Check whether the drive output voltage, output current, output frequency, and monitor display is greater than the value commonly used.
- Check whether the cooling fan installed at the lower part of the drive runs normally;
- Check whether the ambient temperature is too high and whether there is dust, iron filings, corrosive fluid in the drive;
- Check whether the ambient temperature of the drive is between -10 C  $\sim 40$  C , and whether the humidity is between 5%-85% (95% is without condensation), phenomenon of water droplets is not allowed;
- The drive should be discarded as industrial waste. It is forbidden to burn it;

#### 9.2 Storage and Transport

The drive must be kept in its original package box before installation. Pay attention to the followings when keeping it in storage if the drive is not used for the time being:

- It must be stored in a dry place without rubbish or dust;
- The suitable temperature for storage is between -25  $^\circ$ C ~65  $^\circ$ C ;
- The relative humidity required is 5%~95% without condensation;
- There is no corrosive gas or liquid in the storage ambience;
- It is better to lay the drive on a rack and keep it in a proper package;
- The ambient temperature for transport is between -25  $^\circ\!C\,$  ~70  $^\circ\!C\,$  ;
- $\bullet$  The relative humidity of transport ambience must be less than 95% (Ambient temperature is 40  $\rm \check{C}\,$  ).

Attention: It is better not to store the drive for long time. Long time storage of the drive will lead to the deterioration of electrolytic capacity. If it needs to be stored for a long time make sure to power it up one time within a year and the power-up time should be at least above five hours. When powering up, supply voltage must be increased slowly with a voltage regulator to the rated voltage value.



## Appendix A Modbus Communication Specification

The drive provide RS485 communication interface. It adopts international standard Modbus communication protocol to perform master-slave communication. The user can realize centralized control through PC/PLC to adapt specific application requirements.


## 1. Application Mode

#### 1.1 Interface Mode


The communication interface is RS485. RS485 works on semiduplex and its data signal applies differential transmission which is called balance transmission too.

#### 1.2 Networking Mode

The drive has two networking modes: single master/multiple slaves networking and single master/ single slave networking.



Single master/single slave networking diagram



Single master/multiple slaves networking diagram

Specification:

- 1. No matter which mode, the drive is used as a slave in communication. When master sends commands using broadcast address, the slave does not respond;
- 2. It is recommended to use shield cables in multiple connection. The basic parameter of the devices, such as baud rate and digital check bit in RS485 should be the same as slave device's and there should be no repeated addresses in slave devices.


## 2. Protocol Format

Modbus protocol supports both RTU and ASCII mode.

#### 2.1 RTU Mode

RTU data frame format is shown as the figure below:






Specification:

Start	at least 3.5 idle characters	
Slave address	Address: 0-247 (0 is broadcast address)	
Function code	Modbus function code	
Data (N-1)		
Data (N-2)		
	- 2 * N data	
Data 0		
CRC CHK high-8-bit	CRC check	
CRC CHK low-8-bit		
End	at least 3.5 idle characters	

#### 2.2 ASCII Mode

ASCII data frame format is shown as the figure below:



Specification:

- 1. Frame header is "0x3A" while the default frame end is "0x0D" "0x0A";
- 2. In ASCII mode, all data bytes other than frame header and end are sent in the form of ASCII code; high-4-bit byte and low-4-bit byte are sent successively;
- 3. In ASCII mode, the data is 7-bit long. For 'A'~'F', their uppercase ASCII codes are used;
- Data is subjected to LRC check which covers the information portion from slave address to data;

#### 3. Function Code

Function code supported by the drive Modbus protocol are as shown in the table below:

Function code	Description	Meaning
0x03	Read Holding Registers	Read drive functional parameters and running status parameters
0x06	Preset Single Register	Over-write individual drive functional parameters
0x10	Preset Multiple Regs	Over-write multiple drive functional parameters

## HOLIP

## 4. Register Address Definition

All the following register addresses are started from 0.

### 4.1 The Rules of Register Address of the Parameter Number

The parameters can be mapping to register address. The rules of register address of the parameter number are shown below:

Register address =  $PNU \times 10 - 1$ 

For example:

The register address of C03.03 is  $303 \times 10 - 1 = 3029$  (0x0BD5)

The register address of C16.13 is  $1613 \times 10 - 1 = 16129$  (0x3F01)

#### 4.2 Other Register Addresses Specification

In addition to parameter number is mapped to Modbus registers, there are some additional registers within the drive which can be used to control the drive, monitor the drive's status.

Register address	Specification	R/W
6	The internal error code of last communication error	R
7	Register address of last occurred communication error	R
8*	Parameter index	R,W
51000*	Control command	W
51001*	Frequency command	W
51002*	Communication reference	W
51100*	State	R
51101*	Warning/Alarm code	R
51102	Output frequency (0~Fmax, unit: 0.1Hz)	R
51103	Output current (unit: 0.01A)	R
51104	Output voltage (unit: 1V)	R
51105	Output power (unit: 0.01kW)	R
51106	Motor speed (unit: 1rpm)	R
51107	DC bus voltage (unit: 1V)	R
51108	Reference	R
51109	Feedback	R

\* Reg. 8 specification

Reg 8 is parameter index register. The drive has some array type parameters. When accessing these



parameters, it should be set index first.

For example, write value into C03.10[2]. It should write 2 into Reg 8 first, then write value into 3099 (the register address of C03.10 is  $310 \times 10$ -1=3099, hexadecimal is 0x0C1B).

\* Reg. 51000 specification

Bit	Explain
	0x00: No function
	0x01: Run forward
	0x02: Reverse
Bit 7~0	0x03: Jog
Dit 7~0	0x04: Jog reverse
	0x05: Stop
	0x06: Coast
	0x07: Reset
	0000B: master speed C03.10[0]
	0001B: 1st step speed C03.10[1]
Bit 11~8	0010B: 2nd step speed C03.10[2]
DR 11*0	0011B: 3rd step speed C03.10[3]
	1111B: 7th step speed C03.10[15]
	00B: Ramp 1
Bit 13~12	01B: Ramp 2
Dit 15-12	10B: Ramp 3
	11B: Ramp 4
Bit 14	Reserved
Bit 15	1B: Enable Bit8~13 function
Dit 15	0B: Disable Bit8~13 function

\* Reg. 51001 specification

When using communication to control the drive, you can set the frequency directly by writing register 51001. The register value is in the range of 0.00 ~ C04.19, unit 0.01Hz.

\* Reg. 51002 specification

Communication reference is the reference value when C03.15~C03.16 selects [11] local bus. 0.00% corresponds to 0, 100.00% corresponds to C03.03, -100.00% corresponds to -C03.03.

\* Reg. 51100 specification

Bit	Explain
Bit 0	0B: None 1B: Warning

Bit	Explain
Bit 1	0B: None
DIL I	1B: Alarm
	00B: Stop
Bit 3~2	01B: Run forward
Dit 5~2	10B: Reverse
	11B: Reserved
Bit 7~4	Reserved
	0000B: Using master speed
	0001B: Using 1st step speed
Bit 11~8	0010B: Using 2nd step speed
Dit 11~0	0011B: Using 3rd step speed
	1111B: Using 15th step speed
Bit 15~12	Reserved

#### \* Reg. 51101 specification

Register 51101 is used to store the drive fault information, it has two warning/alarm modes (selected by C08.29).

Bit	Explain
	Warning bit:
	Bit0: Mains Phase Loss (A.04)
	Bit1: Over Voltage (A.07)
	Bit2: Under Voltage (A.08)
	Bit3: Drive Overload (A.09)
	Bit4: Over Current (A.13)
	Bit5: Fan Fault (A.24)
	Bit6: Current Limit (A.59)
Bit mode	Bit7~15: Reserved
Bit 15~0	Alarm bit:
BIT 13~0	Bit0: Internal Fault (E.38)
	Bit1: Over Current (E.13)
	Bit2: Earth fault (E.14)
	Bit3: Short Circuit (E.16)
	Bit4: Mains Phase Loss (E.04)
	Bit5: Drive Overload (E.09)
	Bit6: Drive Over Temperature (E.69/E.75/E.83)
	Bit7: Motor Phase Missing (E.30/E.31/E.32)
	Bit8~15: Reserved



Bit	Explain
Code mode Bit 15~0	Warning/Alarm code For example: When the drive occurs E.13 alarm, the value of register 51101 is 13.

#### 5. Communication ratio values

The Communication data is expressed by hexadecimal in actual application and there is no radix point in hexadecimal. For example, If you want to set C03.10[0] = 60.34, 60.34 can be magnified by 100 times into 6034. So hex 0x1792 (6034) can be used to express 60.34.


A non-integer can be timed by a multiple to get an integer and the integer can be called communication ratio values.

The communication ratio values are refered to the radix point of the setting range of default value in the functional parameter list. If there are radix point n, then the communication ratio value m is  $10^{n}$ .

#### 6. Error message

There may be errors in the communication process, for example, some parameters are read-only, but the PC/PLC sends a written directive, the drive will return an error message.

Error message data frame format is shown as the figure below:



Error message function code = requirements function code + 0x80

Error code	Specification
0x01	Function code error, the drive does not support this kind of function code.
0x02	Defined parameters can not be written.
0x03	The value exceeds the upper limit of the parameter
0x04	Operation error.

#### 7. Examples

#### 7.1 Read Holding Registers (0x03)

#### 7.1.1 Read Output Frequency

Read the Reg. 51102 to get the output frequency.

Transmit: 01 03 C7 9E 00 01 D8 90 (Hexadecimal)

#### Receive: 01 03 02 01 F4 B8 53 (Hexadecimal) Transmit data specification:

Field	Description
01	Address
03	Function
C7 9E	Register address: 51102 (0xC79E)
00 01	The number of read registers is 1
D8 90	CRC check

Receive data specification:

Field	Description
01	Address
03	Function
02	The byte number of received data
01 F4	0x01F4 converts to decimal number is 500. So the value of Reg. 51102 is 500 / $10=50.0$
B8 53	CRC check

Read the value of C16.13 to get the output frequency.

Transmit: 01 03 3F 01 00 02 99 DF (Hexadecimal)

Receive: 01 03 04 00 00 01 F4 FA 24 (Hexadecimal)

Transmit data specification:

Field	Description
01	Address
03	Function
3F 01	Register address (ADDRH ADDRL). The register address of C16.13 is 1613*10- 1=16129 (0x3F01)
00 02	The number of read registers is 2
99 DF	CRC check

Receive data specification:

Fi	eld	Description
C	)1	Address
C	)3	Function



Field	Description
04	The byte number of received data
00 00 01 F4	0x000001F4 converts to decimal number is 500. So the value of C16.13 is 500 / 10 = 50.0
FA 24	CRC check

Note: The data type of C16.13 is UINT32, so it needs read 2 registers.

#### 7.1.2 Read Drive Status

Read the Reg. 51100 and 51101 to get the drive status.

Transmit: 01 03 C7 9C 00 02 39 51 (Hexadecimal)

Receive: 01 03 00 02 00 0D 25 CF (Hexadecimal)

Transmit data specification:

Field	Description
01	Address
03	Function
C7 9C	Register address: 51100 (0xC79C)
00 02	The number of read registers is 2
39 51	CRC check

Receive data specification:

Field	Description	
01	Address	
03	Function	
04	The byte number of received data	
00 02 00 0D	The value of Reg. 51100 is 0x0002. Note: Bit 0 is 0B, that is No warning; Bit 1 is 1B, that is Alarm; Bit 3~2 is 00B, that is Stop; Bit 11~8 is 0000B, that is Using master speed; The value of Reg. 51101 is 0x000D (13). The drive has E.13 over current alarm.	
25 CF	CRC check	

### 7.2 Write Single Register (0x06)

#### 7.2.1 Control the drive running at 1<sup>st</sup> step speed.

Write 51000 to control the drive.

Transmit: 01 06 C7 38 81 01 94 E3 (Hexadecimal)

Receive: 01 06 C7 38 81 01 94 E3 (Hexadecimal)

Transmit data specification:

Field	Description
01	Address
06	Function
C7 38	Register address: 51000 (0xC738)
81 01	Control command is 0x8101. Note: Bit 7~0 is 0x01, that is Run forward; Bit 11~8 is 0001B, that is Using 1st step speed C03.10[1]; Bit 13~12 is 00B, that is Using ramp 1; Bit 15 is 1B, that is Enable bit 13~8;
94 E3	CRC check

#### Receive data specification:

Field	Description
01	Address
06	Function
C7 38	Register address: 51000 (0xC738)
81 01	Control command
94 E3	CRC check

#### 7.2.2 Set parameter C03.10[0]

Set C03.10[0] to 40.00%

Transmit: 01 06 0C 1B 0F A0 FF 15 (Hexadecimal) Receive: 01 06 0C 1B 0F A0 FF 15 (Hexadecimal)



#### Transmit data specification:

Field	Description	
01	Address	
06	Function	
0C 1B	The register address of C03.10 is 310 *10-1=3099 (0x0C1B).	
0F A0	The value which will be written into C03.10[0] is 40.00% (Decimal: 4000, Hexadecimal: 0x0FA0).	
FF 15	CRC check	

Receive data specification:

Field	Description	
01	Address	
06	Function	
0C 1B	Register address	
0F A0	The value which has be written into C03.10[0] is 40.00%	
	(Decimal: 4000, Hexadecimal: 0x0FA0).	
FF 15	CRC check	

#### 7.3 Write Multiple Registers (0x10)

Start the drive and set Drive output frequency.

Write register 51000 to control the drive running and write register 51001 to set the drive output frequency.

Transmit: 01 10 C7 38 00 02 04 00 01 13 88 DB BE (Hexadecimal)

Receive: 01 10 C7 38 00 02 FD 71 (Hexadecimal)

Transmit data specification:

Field	Description
01	Address
10	Function
C7 38	Register address: 51000 (0xC738)
00 02	The number of write registers is 2
04	The byte number of write data is 4



Field	Description	
00 01 13 88	Reg. 51000 = 0x0001 Note: Bit 7~0 is 0x01, that is Run forward; Bit 11~8 is 0000B, that is Using master speed C03.10[0]; Bit 13~12 is 00B, that is Using ramp 1; Bit 15 is 0B, that is Disable bit 13~8; Reg. 51001 = 0x1388 (5000, So the output frequency is 5000 / 100 = 50.00Hz)	
DB BE	CRC check	

#### Receive data specification:


Field	Description
01	Address
10	Function
C7 38	Register address: 51000 (0xC738)
00 02	The number of write registers is 2
FD 71	CRC check



## Appendix B Copy Card Specification


Copy Card can copy parameters from one drive to another.

#### 1. Copy Card Interface



#### 2. Installation

Use netcable to connect the copy card and the drive. Plug one terminal into the copy card RJ45 port which is placed on the back and plug the other terminal into drive RJ45 port. As shown in the following figure:



## HOLIP

## 3. Operation

### 3.1 Upload

- 1) Connect copy card and drive according to 2. Installation;
- After the drive power on, Power indicator on the copy card will be ON. If the connection between copy card and drive is not OK, Fail indicator will be ON;
- 3) Press Upload key, parameters in drive begin copying to copy card. Trans indicator will be blinking during transfer.
- If an error occurs during transfer, Fail indicator will be ON; If data upload success, Trans indicator will be OFF;

#### 3.2 Download

- 1) Connect copy card and drive according to 2. Installation;
- After the drive power on, Power indicator on the copy card will be ON. If the connection between copy card and drive is not OK, Fail indicator will be ON;
- 3) Press Download key, parameters in copy card begin copying to drive. Trans indicator will be blinking during transfer.
- 4) If an error occurs during transfer, Fail indicator will be ON; If data download success, Trans indicator will be OFF;

#### 3.3 Part Download

Part download is similar to download, use Part key instead of Download key. It copies parameters from copy card to drive except motor data.

	®
1	HOLIP





	®
1	HOLIP
